



# Master Gear Fit List

December 18, 2018

**Gear Dimensions Chart**

Chart Name	Product Name	Dimensions w x h x d (in)	Dimensions w x h x d (cm)
D-Micro	Soft Pouch-Digital D-Series, D-Micro	4.5"x 2.5" x 2"	11.4 x 6.4 x 5.1
D-Mini	Soft Pouch-Digital D-Series, D-Mini	4.5"x 3" x 2"	11.4 x 7.6 x 5.1
D-Small	Soft Pouch-Digital D-Series, D-Small	4.5"x 3" x 3.25"	11.4 x 7.6 x 8.3
D-Compact	Soft Pouch-Digital D-Series, D-Compact	4.8"x 3.5" x 3"	12.2 x 8.9 x 7.6
D-Shortie	Soft Pouch-Digital D-Series, D-Shortie	4.75"x 3" x 3.75"	12.1 x 7.6 x 9.5
D-M 4/3	Soft Pouch-Digital D-Series, D-M 4/3	4.75"x 3" x 5"	12.1 x 7.6 x 12.7
D-Offset	Soft Pouch-Digital D-Series, D-Offset	4.9"x 3.5" x 4.6"	12.4 x 8.9 x 11.7
D-Midsize	Soft Pouch-Digital D-Series, D-Midsize	5.25"x 3.75" x 6"	13.3 x 9.5 x 15.2
D-Midsize Zoom	Soft Pouch-Digital D-Series, D-Midsize Zoom	5.25"x 3.75" x 8"	13.3 x 9.5 x 20.3
D-Midsize Pro	Soft Pouch-Digital D-Series, D-Midsize Pro	5.25"x 5.75" x 3"	13.3 x 14.6 x 7.6
D-SLR	Soft Pouch-Digital D-Series, D-SLR	6"x 4.5" x 6"	15.2 x 11.4 x 15.2
D-SLR Zoom	Soft Pouch-Digital D-Series, D-SLR Zoom	6"x 4.5" x 8"	15.2 x 11.4 x 20.3
D-SLR Tele	Soft Pouch-Digital D-Series, D-SLR Tele	6"x 4.5" x 11"	15.2 x 11.4 x 27.9
D-Pro	Soft Pouch-Digital D-Series, D-Pro	6"x 6.5" x 6"	15.2 x 16.5 x 15.2
D-Pro Zoom	Soft Pouch-Digital D-Series, D-Pro Zoom	6"x 6.5" x 8"	15.2 x 16.5 x 20.3
D-Pro Tele	Soft Pouch-Digital D-Series, D-Pro Tele	6"x 6.5" x 11"	15.2 x 16.5 x 27.9
Rangefinder	Soft Pouch-SLR Rangefinder	5.75"x 3.1" x 4"	14.6 x 7.9 x 10.2
Rangefinder Tele	Soft Pouch-SLR Rangefinder Telephoto	5.75"x 3.1" x 6"	14.6 x 7.9 x 15.2
SLR AF-Pro	Soft Pouch-SLR AF-Pro	6"x 6" x 6"	15.2 x 15.2 x 15.2
SLR AF-Zoom	Soft Pouch-SLR AF-Zoom	6.1"x 3.5" x 6.25"	15.5 x 8.9 x 15.9
SLR Auto	Soft Pouch-SLR Auto	6.1"x 3.5" x 4.9"	15.5 x 8.9 x 12.4
SLR Manual	Soft Pouch-SLR Manual	5.5"x 3" x 3.75"	14 x 7.6 x 9.5
Euro Mini	Soft Pouch-Euro-Mini	2"x 3.5" x 0.75"	5.1 x 8.9 x 1.9
Euro Small	Soft Pouch-Euro-Small	2"x 4" x 5"	5.1 x 10.2 x 12.7
Euro Medium	Soft Pouch-Euro-Medium	2.5"x 4.5" x 5"	6.4 x 11.4 x 12.7
P/E Mini	Soft Pouch-Photo/Electronic-Mini	2.5"x 4" x 1"	6.4 x 10.2 x 2.5
P/E Large	Soft Pouch-Photo/Electronic-Large	4"x 7" x 1.5"	10.2 x 17.8 x 3.8
P/E WB-Mini	Soft Pouch-Photo/Electronic-Wide Body Mini	2.75"x 4.5" x 1.25"	7 x 11.4 x 3.2
P/E WB-S	Soft Pouch-Photo/Electronic-Wide Body Small	3"x 4" x 2.25"	7.6 x 10.2 x 5.7
P/E WB-Med	Soft Pouch-Photo/Electronic-Wide Body Medium	3"x 5" x 2.5"	7.6 x 12.7 x 6.4
PDA Macro	Soft Pouch-PDA/Cam-Macro	3.75"x 5.75" x 1"	9.5 x 14.6 x 2.5
PDA Micro	Soft Pouch-PDA/Cam-Micro	3.375"x 5.25" x 1"	8.6 x 13.3 x 2.5
PDA Milli	Soft Pouch-PDA/Cam-Milli	3"x 4.75" x 0.75"	7.6 x 12.1 x 1.9
Snap-S	Soft Pouch-Snappez Small	2"x 3.5" x 0.75"	5.1 x 8.9 x 1.9
Snap-M	Soft Pouch-Snappez Medium	2.5"x 3.75" x 1.25"	6.4 x 9.5 x 3.2
Snap-L	Soft Pouch-Snappez Large	2.5"x 4.5" x 1.5"	6.4 x 11.4 x 3.8
Snap-H-M	Soft Pouch-Snappez Horizontal Medium	3.75"x 2.5" x 0.75"	9.5 x 6.4 x 1.9
Snap-H-L	Soft Pouch-Snappez Horizontal Large	4.5"x 2.5" x 0.75"	11.4 x 6.4 x 1.9
Snap-HW-M	Soft Pouch-Snappez Horizontal Wide Body Medium	3.75"x 2.5" x 1.25"	9.5 x 6.4 x 3.2
Snap-HW-L	Soft Pouch-Snappez Horizontal Wide Body Large	4.5"x 2.5" x 1.25"	11.4 x 6.4 x 3.2
EZ-Close-321	Soft Pouch-EZ Close 321	3.75"x 2.5" x 1.25"	9.5 x 6.4 x 3.2
EZ-Close-421	Soft Pouch-EZ Close 421	4.5"x 2.5" x 1.25"	11.4 x 6.4 x 3.2
EZ-Close-532	Soft Pouch-EZ Close 532	5"x 3" x 2"	12.7 x 7.6 x 5.1
Zip-S	Soft Pouch-Zippez-Small	4"x 2.75" x 1"	10.2 x 7 x 2.5
Zip-M	Soft Pouch-Zippez-Medium	4.5"x 3" x 1.5"	11.4 x 7.6 x 3.8
Zip-L	Soft Pouch-Zippez-Large	5.5"x 3.5" x 1.75"	14 x 8.9 x 4.4
Hip-S	Hipster Pouch-Small	4"x 3" x 1"	10.2 x 7.6 x 2.5
Hip-M	Hipster Pouch-Medium	4.5"x 3" x 1.5"	11.4 x 7.6 x 3.8
Hip-L	Hipster Pouch-Large	5.5"x 3.5" x 1.75"	14 x 8.9 x 4.4
Hip-XL	Hipster Pouch-Extra Large	6"x 4" x 2.5"	15.2 x 10.2 x 6.4
B Cover-Manual	Manual Body Cover	5.75"x 3" x 2"	14.6 x 7.6 x 5.1
B Cover-Auto	Auto Body Cover	6"x 4.5" x 3"	15.2 x 11.4 x 7.6
B Cover-Mid	Body Cover Midsize	5.25"x 3.75" x 3"	13.3 x 9.5 x 7.6
B Cover-Mid-Pro	Body Cover Midsize Pro	5.25"x 5.75" x 3"	13.3 x 14.6 x 7.6
B Cover-Pro	AF-Pro Body Cover	6"x 6.5" x 3"	15.2 x 16.5 x 7.6
S-SL 324	Smart Sleeve 324	3.25" x 4.5"	8.3 x 11.4
S-SL 335	Smart Sleeve 335	3.3" x 5.3"	8.4 x 13.5
S-SL 355	Smart Sleeve 355	3.5" x 5"	8.9 x 12.7

CAMERAS & ELECTRONICS

OP/TECH USA Master Gear Fit List

S-SL 356	Smart Sleeve 356	3.5" x 6"	8.9 x 15.2
S-SL 376	Smart Sleeve 376	3.7" x 6.4"	9.4 x 16.3
S-SL 387	Smart Sleeve 387	3.88" x 7.0"	9.9 x 17.8
S-SL 528	Smart Sleeve 528	5.25" x 8"	13.3 x 20.3
S-SL 598	Smart Sleeve 598	5.88" x 8.5"	14.9 x 21.6
S-SL 751	Smart Sleeve 751	7.5" x 11.25"	19.1 x 28.6
S-SL 770	Smart Sleeve 770	7.75" x 10"	19.7 x 25.4
S-SL 802	Smart Sleeve 802	8" x 12.4"	20.3 x 31.5
S-SL 841	Smart Sleeve 841	8.4" x 11.5"	21.3 x 29.2
S-Sling-CK i5S	Smart Sling Cover Kit iPhone 5S	3.5" x 6"	8.9 x 15.2
S-Sling-CK i6	Smart Sling Cover Kit iPhone 6	3.5" x 6"	8.9 x 15.2
S-Sling-CK i6+	Smart Sling Cover Kit iPhone 6 Plus	3.88" x 7"	9.9 x 17.8
S-Sling-CK GS5	Smart Sling Cover Kit Samsung Galaxy S5	3.5" x 6"	8.9 x 15.2
S-Sling-CK GN4	Smart Sling Cover Kit Samsung Galaxy Note 4	3.88" x 7"	9.9 x 17.8
Computer-S 8	Computer Sleeve 8"	8.25" x 5.5"	21 x 14
Computer-S 9	Computer Sleeve 9"	9.25" x 7"	23.5 x 17.8
Computer-S 10	Computer Sleeve 10"	10.25" x 8"	26 x 20.3
Computer-S 11.5	Computer Sleeve 11.5"	11.75" x 9"	29.8 x 22.9
Computer-S 13	Computer Sleeve 13"	13.25" x 10"	33.7 x 25.4
Computer-S 15	Computer Sleeve 15"	15.5" x 12"	39.4 x 30.5
Computer-S 17	Computer Sleeve 17"	17" x 12.75"	43.2 x 32.4

LENSES & HOODS

H Hat - PK Micro	Hood Hat - PK Micro (For Pancake lenses)	2.5" Diameter x1" Deep	6.35 x 2.56
H Hat - PK Mini	Hood Hat - PK Mini (For Pancake lenses)	3" Diameter x1" Deep	7.6 x 2.56
H Hat - Micro	Hood Hat - Micro	2" - 2.5" Diameter	5.1 - 6.35
H Hat - Mini	Hood Hat - Mini	2.5" - 3" Diameter	6.4 - 7.6
H Hat - S	Hood Hat - Small	3" - 3.5" Diameter	7.6 - 8.9
H Hat - M	Hood Hat - Medium	3.5" - 4" Diameter	8.9 - 10.2
H Hat - L	Hood Hat - Large	4" - 4.5" Diameter	10.2 - 11.4
H Hat - XL	Hood Hat - X-Large	4.5" - 5" Diameter	11.4 - 12.7
H Hat - XXL	Hood Hat - XX-Large	5" - 5.75" Diameter	12.7 - 14.6
H Hat - XXXL	Hood Hat - XXX-Large	5.75" - 6.5" Diameter	14.6 - 16.5
H Hat - XXXXL	Hood Hat - XXXX-Large	7.25" - 8" Diameter	18.4 - 20.3
Snoot - Mini	Snoot Boot - Mini	3" Diameter x 4" Length	7.6 x 10.2
Snoot - S	Snoot Boot - Small	3.2" Diameter x 6" Length	8.1 x 15.2
Snoot - M	Snoot Boot - Medium	3.5" Diameter x 8" Length	8.9 x 20.3
Snoot - L	Snoot Boot - Large	3.6" Diameter x 9" Length	9.1 x 22.9
Snoot - WB-S	Snoot Boot - WB Small	4" Diameter x 5" Length	10.2 x 12.7
Snoot - WB-M	Snoot Boot - WB Medium	4.5" Diameter x 6.5" Length	11.4 x 16.5
Snoot - WB-L	Snoot Boot - WB Large	4.5" Diameter x 8" Length	11.4 x 20.3
Snoot - WB-XL	Snoot Boot -WB XL	4.5" Diameter x 10" Length	11.4 x 25.4
Snoot - WB-XXL	Snoot Boot - WB XXL	5.3" Diameter x 12" Length	13.5 x 30.4
L/Filter - S	Lens/Filter Pouch - Small	4" Diameter x 5" Length	10.2 x 14
L/Filter - M	Lens/Filter Pouch - Medium	4.5" Diameter x 7" Length	11.4 x 17.8
L/Filter - L	Lens/Filter Pouch - Large	4.5" Diameter x 9" Length	11.4 x 22.9
L Sleeve - 3"	Lens Sleeve - 3"	2.9" Diameter x 3" Length	7.36 x 7.6
L Sleeve - 4"	Lens Sleeve - 4"	3" Diameter x 4" Length	7.62 x 10.2
L Sleeve - 5"	Lens Sleeve - 5"	3.09" Diameter x 5" Length	7.84 x 12.7
L Sleeve - 6"	Lens Sleeve - 6"	3.18" Diameter x 6" Length	8.07 x 15.2
FOP 251	Fold-Over Pouch 251	2.5" Diameter x 1.5" Deep	6.4 x 3.84
FOP 253	Fold-Over Pouch 253	2.5" Diameter x 3" Deep	6.4 x 7.68
FOP 254	Fold-Over Pouch 254	2.5" Diameter x 4.5" Deep	6.4 x 11.43
FOP 301	Fold-Over Pouch 301	3" Diameter x 1.5" Deep	7.68 x 3.84
FOP 303	Fold-Over Pouch 303	3" Diameter x 3" Deep	7.68 x 7.68
FOP 304	Fold-Over Pouch 304	3" Diameter x 4" Deep	7.68 x 10.16
FOP 306	Fold-Over Pouch 306	3" Diameter x 6" Deep	7.68 x 15.24
FOP 354	Fold-Over Pouch 354	3.5" Diameter x 4" Deep	8.89 x 10.16
FOP 356	Fold-Over Pouch 356	3.5" Diameter x 6" Deep	8.89 x 15.24

TRIPODS

Tripod - 1"	Tripod Leg Wraps - 1"	1" Diameter x 17" Length	2.5 x 43.2
Tripod - 1.25"	Tripod Leg Wraps - 1.25"	1.25" Diameter x 17" Length	3.2 x 43.2
Tripod - 1.5"	Tripod Leg Wraps - 1.5"	1.5" Diameter x 17" Length	3.8 x 43.2

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	Bronica	ETR and some ETRC	na
Camera	CANON	ELPH 110 HS	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	ELPH 115 IS	Snap-H-M, Zip-S, Hip-S, P/E-Mini, EZ-Close-321
Camera	CANON	Elph 130	Zip-S, Hip-S, P/E-Mini, EZ-Close-321
Camera	CANON	ELPH 160	SL-355, Snap-HW-M, Zip-S, Hip-S, PE-Mini, EZ-Close-321
Camera	CANON	ELPH 170 IS	SL-355, Snap-HW-L, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	CANON	ELPH 180	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-321
Camera	CANON	ELPH 190 IS	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	CANON	ELPH 310 HS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	CANON	ELPH 320 HS	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	ELPH 330 HS	Snap-H-M, Zip-S, Hip-S, P/E-Mini, S-SL-335, EZ-Close-421
Camera	CANON	ELPH 340 HS	S-SL-355, SNAP-HW-M, ZIP-S, HIP-S, PE-MINI, EZ-Close-421
Camera	CANON	ELPH 350 HS	S-SL 355, Snap-HW-L, Zip-S, Hip-S, P/E-Mini, EZ-Close-421
Camera	CANON	ELPH 360 HS	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	CANON	ELPH 510 HS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	ELPH 520 HS	Zip-S, Hip-S, Snap-H-M
Camera	CANON	ELPH 530 HS	Zip-S, Hip-S, Snap H-M, S-SL 324
Camera	CANON	EOS 1000D / Rebel XS	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 100D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 10D/ 20D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 1100D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 1200D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 1300D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 1D Mark II / 1Ds Mark II / 1D Mark II N/ Mark III	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	CANON	EOS -1D X	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	CANON	EOS 1Ds Mark III/ Mark IV	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	CANON	EOS 20Da	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 3	D-SLR
Camera	CANON	EOS 300D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 30D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 4000D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 400D/ Digital Rebel XTi	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 40D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 450D/ Rebel XSi	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 500D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 50D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 550D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 5D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 5D Mark II	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 5D Mark II (With Battery Grip)	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	CANON	EOS 5D Mark III	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 5D Mark IV	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 5DS	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 5DS R	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 600D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 60D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 650D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 6D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 6D Mark II	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 70D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 750D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 760D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	CANON	EOS 77D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 7D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 7D Mark II	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS 8000D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS 80D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS D30/D60	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS Digital Rebel	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CANON	EOS Digital Rebel XT	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS ELAN 7 / 7E, 7N / 7NE	SLR Auto, SLR AF Zoom, D-SLR
Camera	CANON	EOS M	D-Small
Camera	CANON	EOS M10	D-Small
Camera	CANON	EOS M100	D-Small
Camera	CANON	EOS M3	D-Small
Camera	CANON	EOS M5	D-Shortie
Camera	CANON	EOS M50	D-Shortie
Camera	CANON	EOS M6	D-Small
Camera	CANON	EOS R	D-Midsize, D-Midsize-Zoom, B-Cover-Mid
Camera	CANON	EOS REBEL 2000	SLR Auto
Camera	CANON	EOS REBEL G, G11	SLR Auto
Camera	CANON	EOS REBEL K2	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel SL1	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel SL2	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS REBEL T1i	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS REBEL T2	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T2i	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T3	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T3i	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T4i	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T5	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T5i	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T6	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T6i	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T6s	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T7	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS Rebel T7i	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS REBEL Ti	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	EOS-1D X Mark II	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	CANON	EOS-1Ds	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	CANON	EOS-1V / 1VHS	D-SLR
Camera	CANON	G7 X	Zip-M, Hip-M
Camera	CANON	IXUS 1000 HS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	Ixus 105	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	IXUS 110 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	IXUS 1100 HS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	Ixus 115 HS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	IXUS 120 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	IXUS 125 HS	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324, EZ-Close-321

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	CANON	Ixus 130	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	CANON	IXUS 165	SL-355, Snap-HW-M, Zip-S, Hip-S, PE-Mini, EZ-Close-321
Camera	CANON	IXUS 200 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	Ixus 210	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	IXUS 230 HS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	CANON	IXUS 240 HS	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	Ixus 300 HS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	Ixus 310 HS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	Ixus 430	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	IXUS 500 HS	Zip-S, Hip-S, Snap-H-M, S-SL-324
Camera	CANON	IXUS 510 HS	Zip-S, Hip-S, Snap H-M, S-SL 324
Camera	CANON	IXUS 990 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	Kiss X8i	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	CANON	PowerShot 500 HS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot 530 HS	Zip-S, Hip-S, Snap H-M, S-SL 324
Camera	CANON	PowerShot A100 HS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A1000 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355, EZ-Close-421
Camera	CANON	PowerShot A1100 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A1300	P/E WB-Mini, Zip-S, Hip-S, Snap HW-M, S-SL 324
Camera	CANON	PowerShot A1400	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, P/E-WB-Mini, EZ-Close-321
Camera	CANON	PowerShot A2000 IS	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	CANON	PowerShot A2300	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A2400 IS	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A2500	Snap-H-M, Zip-S, Hip-S, P/E-Mini, EZ-Close-421
Camera	CANON	PowerShot A2600	Snap-H-M, Zip-S, Hip-S, P/E-Mini, EZ-Close-421
Camera	CANON	PowerShot A3000 IS/ A3100 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot A3000/ A3100	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot A3200 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A3300 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A3400 IS	P/E Mini, Zip-S, Hip-S, S-SL-324, EZ-Close-321
Camera	CANON	PowerShot A40	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	CANON	PowerShot A4000 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A410	P/E WB-Mini, Zip-M, Hip-M, S-SL 355
Camera	CANON	PowerShot A420/ 430	P/E WB-Mini, Zip-M, Hip-M, S-SL 355
Camera	CANON	PowerShot A450/ A460	P/E WB-Mini, Zip-M, Hip-M, S-SL 355
Camera	CANON	PowerShot A470	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	CANON	PowerShot A480	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A490/ A495	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot A510/ A520	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	CANON	PowerShot A530/ A540/ A550/ A560/ A570IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	CANON	PowerShot A580/ A590 IS	P/E WB-Mini, Zip-M, Hip-M
Camera	CANON	PowerShot A610 / A620	P/E WB-Small, Zip-M, Hip-M
Camera	CANON	PowerShot A630/ A640	Zip-M, Hip-M
Camera	CANON	PowerShot A650 IS/ A720 IS	P/E WB-Small, Zip-M, Hip-M
Camera	CANON	PowerShot A700	P/E WB-Small, Zip-M, Hip-M
Camera	CANON	PowerShot A710IS	P/E WB-S, Zip-M, Hip-M
Camera	CANON	PowerShot A80/ A85/ A95	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	CANON	PowerShot A810	P/E WB-Mini, Zip-S, Hip-S, Snap HW-M
Camera	CANON	PowerShot D10	P/E WB-Small, Zip-M, Hip-M
Camera	CANON	PowerShot D20	Zip-M, Hip-M
Camera	CANON	PowerShot E1	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	CANON	PowerShot G1 X	D-Compact
Camera	CANON	PowerShot G1 X Mark II	D-Shortie
Camera	CANON	PowerShot G1 X Mark III	D-Mini
Camera	CANON	PowerShot G10	D-Mini,
Camera	CANON	PowerShot G11	D-Mini,

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	CANON	PowerShot G12	D-Mini,
Camera	CANON	PowerShot G15	D-Mini
Camera	CANON	PowerShot G16	D_Mini
Camera	CANON	PowerShot G3 X	D-M4/3
Camera	CANON	PowerShot G5 X	D-Mini,
Camera	CANON	PowerShot G6	D-Small
Camera	CANON	PowerShot G6 w/ extended lens	D-Offset
Camera	CANON	PowerShot G7	P/E WB-Small, Zip-M, Hip-M
Camera	CANON	PowerShot G7 X Mark II	D-Micro
Camera	CANON	PowerShot G9	D-Mini, Hip-M, Zip-L
Camera	CANON	PowerShot G9 X	D-Micro, Zip-M, Hip-M
Camera	CANON	PowerShot G9 X Mark II	D-Micro, Zip-M, Hip-M
Camera	CANON	PowerShot N	Zip-M, Hip-M, EZ-Close-321
Camera	CANON	PowerShot N Facebook	Zip_S, Hip_S, EZ-Close-321
Camera	CANON	PowerShot N100	S-SL-355, Zip-M, Hip-M, PE-WB-Mini
Camera	CANON	PowerShot N2	Zip-M, Hip-M,
Camera	CANON	PowerShot Pro1	D-Offset
Camera	CANON	PowerShot Pro90 IS	D-Offset
Camera	CANON	PowerShot S1 IS	D-Small
Camera	CANON	PowerShot S100	P/E Mini, Zip-S, Hip-S, Snap-HW-M, S-SL 355, EZ-Close-421
Camera	CANON	PowerShot S110	S-SL-355, H-WB-Med, Zip-S, Hip-S, PE-WB-Mini, EZ-Close-421
Camera	CANON	PowerShot S120	S_SL_355,Snap_HW_L,Zip_S,Hip_S,PE_WB_Mini, EZ-Close-421
Camera	CANON	PowerShot S2 IS/ S3 IS	D-Small
Camera	CANON	PowerShot S5 IS	D-Compact
Camera	CANON	PowerShot S60/ S70/ S80	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	CANON	PowerShot S90	P/E Mini, Zip-S, Hip-S, Snap-HW-M, S-SL 355, EZ-Close-421
Camera	CANON	PowerShot S95	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M, S-SL 355, EZ-Close-421
Camera	CANON	PowerShot SD 1000/ IXUS 70	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD 750/ IXUS 75	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD1200 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD1300 IS	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD1400 IS	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	CANON	PowerShot SD20, SD200	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CANON	PowerShot SD30/ SD40/ IXUS i7	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CANON	PowerShot SD300/ SD400 /SD450/ SD500	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD3500 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot SD4000 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot SD430	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 324 , EZ-Close-421
Camera	CANON	PowerShot SD4500 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot SD550	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD600/ IXUS 60	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD630/ IXUS 65	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD700 IS / IXUS800 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD770	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD780 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M, S-SL 324
Camera	CANON	PowerShot SD790	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD800 IS/ IXUS 850 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD850 IS/ IXUS 950 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD870 IS	Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD880 IS/ IXUS 870 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD890 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot SD900 / IXUS 900 Ti	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	PowerShot SD950 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	CANON	PowerShot SD960 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot SD970 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CANON	PowerShot SD990 IS/ IXUS 980 IS	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	CANON	PowerShot SX10 IS/ SX1 IS	D-Offset

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	CANON	PowerShot SX100 IS	Zip-M, Hip-M
Camera	CANON	PowerShot SX110 IS	P/E WB-Small, Hip-M, D-Mini, Zip-L
Camera	CANON	PowerShot SX120 IS	P/E WB-Small, Hip-M, D-Mini, Zip-L
Camera	CANON	PowerShot SX130 IS	P/E WB-Small, Hip-M, D-Mini, Zip-L
Camera	CANON	PowerShot SX150 IS	P/E WB-Small, Hip-M, D-Mini, Zip-L
Camera	CANON	PowerShot SX160 IS	D-Mini, Hip-M, Zip-M
Camera	CANON	PowerShot SX170 IS	D Mini
Camera	CANON	PowerShot SX20 IS	D-Offset
Camera	CANON	PowerShot SX200 IS	P/E Mini, Zip-S, Hip-S, Snap-H-M
Camera	CANON	PowerShot SX210 IS	Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	CANON	PowerShot SX220 HS	Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	CANON	PowerShot SX230 HS	Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	CANON	PowerShot SX240 HS	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	CANON	PowerShot SX260 HS	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	CANON	PowerShot SX280 HS	S-SL-355, Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	CANON	PowerShot SX30 IS	D-Offset
Camera	CANON	PowerShot SX40 HS	D-Offset
Camera	CANON	PowerShot SX400 IS	D-Small
Camera	CANON	PowerShot SX410 IS	D-Small
Camera	CANON	PowerShot SX420 IS	D-Small
Camera	CANON	PowerShot SX50 HS	D-Offset,
Camera	CANON	PowerShot SX500 IS	D-Small
Camera	CANON	PowerShot SX510 HS	D-Small
Camera	CANON	PowerShot SX520 HS	D-Offset
Camera	CANON	PowerShot SX530 HS	D-Shortie
Camera	CANON	PowerShot SX540 HS	D-Shortie
Camera	CANON	PowerShot SX60 HS	D-Offset
Camera	CANON	PowerShot SX600 HS	S-SL-355, SNAP-H-WB-L, ZIP-M, HIP-M, PE-MINI, EZ-Close-421
Camera	CANON	PowerShot SX610 HS	Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini, EZ-Close-421
Camera	CANON	PowerShot SX620 HS	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	CANON	PowerShot SX70 HS	D-Midsize
Camera	CANON	PowerShot SX710 HS	D-Micro, Zip-M, Hip-M
Camera	CANON	PowerShot SX720 HS	D-Micro, Zip-M, Hip-M
Camera	CANON	PowerShot SX730 HS	D-Micro, Zip-M, Hip-M, EZ-Close-532
Camera	CANON	PowerShot SX740 HS	D-Micro, Zip-M, EZ-Close-532
Camera	CANON	PowerShot TX1	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CANON	XC10	NA
Camera	CASIO	EX-F1	D-Offset
Camera	CASIO	EX-FC100	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-FH10	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-FH100	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	CASIO	EX-FH20	D-Compact
Camera	CASIO	EX-FH25	D-Compact
Camera	CASIO	EX-FS10	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	CASIO	EX-G1	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-H10	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-H15	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	CASIO	EX-H20G	Zip-M, Hip-M, S-SL 355
Camera	CASIO	EX-H30	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	CASIO	EX-H5	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	CASIO	EX-M2, EX-S2	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CASIO	EX-M20U, S20U	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CASIO	EX-P505	Zip-M, Hip-M
Camera	CASIO	EX-P600 / EX-P700	P/E WB-S, Zip-M, Hip-M
Camera	CASIO	EX-QVR52	P/E Mini, Zip-M, Hip-M, Snap-M, Snap-H-M
Camera	CASIO	EX-S10	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CASIO	EX-S100	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-S12	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-S200	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	CASIO	EX-S3	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CASIO	EX-S5	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	CASIO	EX-S500/ EX-S600D	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-S600	P/E WB-S, Zip-M, Hip-S
Camera	CASIO	EX-S7	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324, EZ-Close-421



OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	CASIO	EX-S880	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-V7/ V8	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-X1050	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-Z10/ EX-Z110/ EX-Z120	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	CASIO	EX-Z100/ Z200	Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CASIO	EX-Z1000	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-Z1080	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-Z1200/ EX-Z1200SR	Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	CASIO	EX-Z16	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z2000	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	CASIO	EX-Z2300	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z250	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z270	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z280	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z29	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z30/ EX-Z4U	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CASIO	EX-Z300	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z33	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-Z35	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z40 / EX-Z50 / EX-Z55 / EX-Z57	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-Z400	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z450	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z5/ EX-Z70	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z500/ EX-Z700	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	CASIO	EX-Z550	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z60	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	CASIO	EX-Z600/ EX-Z750/ EX-Z850	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-Z75	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-Z77	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	CASIO	EX-Z80	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CASIO	EX-Z800	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-Z85	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CASIO	EX-Z9	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-Z90	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	CASIO	EX-ZR10	Zip-M, Hip-M, S-SL 355
Camera	CASIO	EX-ZR100	P/E WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	CASIO	EX-ZR15	P/E WB-Mini, Zip-S, Hip-S, Snap-H-WB-L, S-SL-355, EZ-Close-421
Camera	CASIO	EX-ZR200	P/E WB-Mini, Zip-M, Hip-M, Snap-H-WB-L, S-SL-355, EZ-Close-421
Camera	CASIO	EX-ZR300	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	CASIO	EX-ZR800	S-SL-356, Snap-H-WB-L, Zip-M, Hip-M, PE-WB-Mini, EZ-Close-421
Camera	CASIO	EX-ZS10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	CASIO	EX-ZS12	Not yet published
Camera	CASIO	EX-ZS15	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-ZS150	Not yet published
Camera	CASIO	EX-ZS20	Not yet published
Camera	CASIO	EX-ZS5	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	CASIO	EX-ZS6	Not yet published
Camera	CASIO	QV-R40/ QV-R41/ QV-R51/ QV-R62	P/E Mini, Zip-M, Hip-M, Snap-M, Snap-H-M
Camera	CONCORD	4042	P/E WB-Mini, Zip-M, Hip-M, S-SL 355
Camera	CONCORD	5040	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 324, EZ-Close-421
Camera	CONCORD	5042	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	CONCORD	5062 AF	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 355, EZ-Close-421
Camera	CONCORD	5340z	P/E Mini, Zip-S, Hip-S
Camera	CONCORD	6340z	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 355
Camera	CONCORD	642 VGA/ 642	P/E Mini, Zip-S, Hip-S, EZ-Close-421
Camera	CONCORD	Duo LCD	P/E WB-Mini, Zip-M, Hip-M
Camera	CONCORD	DVx	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	CONCORD	ES500z/ ES510z	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 355, EZ-Close-421
Camera	CONCORD	Go LCD	P/E Mini, Zip-S, Hip-S, Snap-M

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	CONCORD	Q 1000	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CONCORD	Q DVO 2000	P/E WB-Mini, Zip-M, Hip-M, S-SL 355
Camera	CONCORD	Q Go 2000	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	CONCORD	Q Go 2CD	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	CONCORD	Q Mini	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	CONCORD	Q-2040	P/E WB-Mini, Zip-L, Hip-L, EZ-Close-532
Camera	CONCORD	Q-3040 AF	P/E Mini, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	CONCORD	Q-3340z	P/E WB-Mini, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	CONCORD	Q-3341z	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 355, EZ-Close-421
Camera	CONCORD	Q-4060 AF	P/E WB-Mini, Zip-M, Hip-M
Camera	CONCORD	Q-5345z	P/E Mini, Zip-M, Hip-M, Snap-M
Camera	CONTAX	Aria	SLR Manual
Camera	CONTAX	G2	Rangefinder
Camera	CONTAX	I4R	Zip-S, Hip-S, Snap-S
Camera	CONTAX	N1	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CONTAX	NX	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	CONTAX	RTS III	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	CONTAX	SL300R T*	P/E Mini, Snap-M / HW-M, S-SL 324
Camera	CONTAX	U4R	P/E WB-Mini, Zip-M, Hip-M, Snap-H-L, S-SL 324
Camera	DXO	One	SS-324
Camera	EPSON	3000 Zoom/ 3100 Zoom	D-Small
Camera	EPSON	L-200/ L-300/ L-400/ L-410	PDA Milli, Zip-S, Hip-S, Snap-M, S-SL 355
Camera	EPSON	L-500V	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	EPSON	RD-1/ RD-1s	Rangefinder
Camera	FUJIFILM	2650	P/E WB-S, Zip-M, Hip-M
Camera	FUJIFILM	2800/ 3800	Zip-L, Hip-L
Camera	FUJIFILM	3D W1	PDA Micro, Zip-L, Hip-L
Camera	FUJIFILM	A100	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	A101	WB Mini, Zip-M, Hip-M, Snap-M
Camera	FUJIFILM	A150	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	A170 / A220	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	A203	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355
Camera	FUJIFILM	A205/ A210	P/E WB-S, Zip-M, Hip-M
Camera	FUJIFILM	A303	P/E Mini, P/E WB-Mini. Snap-H-L, S-SL 355, EZ-Close-421
Camera	FUJIFILM	A310/ A330/ A340	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	FUJIFILM	A345/ A350	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	A400/ A500/ A600/ A700	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	A800 / A820 / A850	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	A800/ A610	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-H-M, S-SL 355, EZ-Close-421
Camera	FUJIFILM	A820/ A900	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-H-M, S-SL 355
Camera	FUJIFILM	A920	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-H-M, S-SL 355
Camera	FUJIFILM	AX200 / AX205	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	AX250	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	AX650	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, P/E-WB-Mini, EZ-Close-321
Camera	FUJIFILM	E500/ E510/ E550/ E900	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	FUJIFILM	F10/ F20/ F30/ F31fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	F100fd	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	F200 EXR	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	F300EXR/ F305EXR	P/E Mini, P/E WB-Mini, Zip-M, Snap-WB-L, S-SL 355
Camera	FUJIFILM	F40fd	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	F410	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	FUJIFILM	F440/ F450	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	FUJIFILM	F460/ F470	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	F480	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	F50fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	FUJIFILM	F600 EXR	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	FUJIFILM	F600 Zoom	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	F60fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	F650 Zoom	P/E Mini, P/E WB-Mini, Snap-H-L, S-SL 355, EZ-Close-421
Camera	FUJIFILM	F660 EXR	P/E WB-Mini, Snap-HW-L, S-SL 355
Camera	FUJIFILM	F700	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	FUJIFILM	F70EXR	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	F770 EXR	Zip-M, Hip-M
Camera	FUJIFILM	F800EXR	Zip-M, Hip-M
Camera	FUJIFILM	F80EXR / F85EXR	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	F900EXR	Zip-M, Hip-M, PE-WB-Mini
Camera	FUJIFILM	FinePix XP120	Zip-M, Hip-M, PE-WB-Mini
Camera	FUJIFILM	GFX 50R	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	FUJIFILM	GFX 50S	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto, System Connector-A
Camera	FUJIFILM	HS10 / HS11	D-Midsize,
Camera	FUJIFILM	HS20 / HS22	D-Midsize,
Camera	FUJIFILM	HS30 EXR	D-Midsize,
Camera	FUJIFILM	HS35 EXR	D-Midsize,
Camera	FUJIFILM	HS50 EXR	na
Camera	FUJIFILM	instax mini 8	NA
Camera	FUJIFILM	Instax Wide 300	NA
Camera	FUJIFILM	IS-1	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	FUJIFILM	IS-Pro	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	FUJIFILM	J10/ J50	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	J100/ J110W/ J120/ J150W	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	J20/ J20fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	FUJIFILM	J250	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	J30 / J38	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	JX280	Euro Mini, Zip-S, Hip-S, Snap-S, EZ-Close-321
Camera	FUJIFILM	JX370	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	JX500 / JX550	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	FUJIFILM	JX530	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	JZ100 / JZ200	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	FUJIFILM	JZ310	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	S1	D-Midsize,
Camera	FUJIFILM	S1000fd	D-Midsize,
Camera	FUJIFILM	S100fs	D-Midsize,
Camera	FUJIFILM	S1500/ S1500fd	D-Small, Zip-L, Hip-L
Camera	FUJIFILM	S1600 / S1770	D-Small
Camera	FUJIFILM	S1730	D-Small
Camera	FUJIFILM	S2 Pro	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	FUJIFILM	S20 Pro	D-Offset
Camera	FUJIFILM	S2000HD	D-Small
Camera	FUJIFILM	S200EXR	D-Midsize,
Camera	FUJIFILM	S2500HD	D-Small
Camera	FUJIFILM	S2500HD / S2600HD	D-Small
Camera	FUJIFILM	S2900HD	D-Small
Camera	FUJIFILM	S3 Pro	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	FUJIFILM	S3000, S3100	D-Small
Camera	FUJIFILM	S3300 / S3350	D-Offset
Camera	FUJIFILM	S4000 / S4050	D-Offset
Camera	FUJIFILM	S4200 / S4500	D-M4/3
Camera	FUJIFILM	S4800	D-Offset
Camera	FUJIFILM	S5 Pro	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	FUJIFILM	S5000, S5100	D-Small
Camera	FUJIFILM	S5200	D-Offset
Camera	FUJIFILM	S5800	D-Small
Camera	FUJIFILM	S602	D-Offset
Camera	FUJIFILM	S6500fd	D-Midsize,

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	FUJIFILM	S700	D-Small
Camera	FUJIFILM	S7000	D-Offset
Camera	FUJIFILM	S8000fd/ S810fd	D-Small
Camera	FUJIFILM	S8200 / S8300	D-Offset
Camera	FUJIFILM	S8500	D-Offset
Camera	FUJIFILM	S8600	D-Shortie
Camera	FUJIFILM	S9000	D-Midsize,
Camera	FUJIFILM	S9200	D-Offset
Camera	FUJIFILM	S9400W	D-Offset
Camera	FUJIFILM	S9600/ S9100	D-Midsize,
Camera	FUJIFILM	S9800	D-Offset
Camera	FUJIFILM	S9900w	D-Offset
Camera	FUJIFILM	SL1000	D-Midsize,
Camera	FUJIFILM	SL240 / SL300	D-Offset
Camera	FUJIFILM	T400	P/E-WB-Mini, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	FUJIFILM	T500	S-SL-335, Snap-HW-Med, Zip-S, Hip-S, P/E-Mini, EZ-Close-421
Camera	FUJIFILM	T550	S-SL-335, Snap-HW-Med, Zip-S, Hip-S, P/E-Mini, EZ-Close-421
Camera	FUJIFILM	V10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	X10	D-Mini
Camera	FUJIFILM	X100	D-Compact
Camera	FUJIFILM	x100F	EZ-Close 532, Body Cover Manual, PE-WB-Med
Camera	FUJIFILM	X100S	Body Cover Manual, PE-WB-MED
Camera	FUJIFILM	X100T	Body Cover Manual, PE-WB-MED, D-Compact
Camera	FUJIFILM	X20	D-Mini
Camera	FUJIFILM	X30	D-Shortie
Camera	FUJIFILM	X70	D-Micro,
Camera	FUJIFILM	X-A1	D-Compact, D-Shortie, D-M 4/3
Camera	FUJIFILM	X-A10	D-Compact, D-Shortie, D-M 4/3
Camera	FUJIFILM	X-A2	D-Compact, D-Shortie, D-M 4/3
Camera	FUJIFILM	X-A3	D-Compact, D-Shortie, D-M 4/3
Camera	FUJIFILM	X-A5	D-Compact, D-Shortie, D-M 4/3
Camera	FUJIFILM	X-E1	Rangefinder, Rangefinder-Tele
Camera	FUJIFILM	X-E2	Rangefinder, Rangefinder-Tele
Camera	FUJIFILM	X-E2S	Rangefinder, Rangefinder-Tele
Camera	FUJIFILM	X-E3	D-Mini
Camera	FUJIFILM	XF1	Zip-M, Hip-M, PE-WB-Mini
Camera	FUJIFILM	XF10	D-Micro
Camera	FUJIFILM	X-H1	D-Midsize, B-Cover-Mid,
Camera	FUJIFILM	X-M1	D-Compact, D-Shortie, D-M 4/3
Camera	FUJIFILM	XP10 / XP11	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	XP100 / XP150	P/E-WB Mini,
Camera	FUJIFILM	XP130	PE-WB-S,
Camera	FUJIFILM	XP50	P/E-WB-Mini, Zip-S, Hip-S, S-SL 355
Camera	FUJIFILM	XP60	S-SL-355, Snap-HW-L, Zip-S, Hip-S, P/E-WB-Mini
Camera	FUJIFILM	XP70	S-SL-355, H-WB-L, ZIP-M, HIP-M, PE-WB-MINI
Camera	FUJIFILM	XP80	S-SL-355, Snap-H-WB-L, Zip-M, Hip-M, PE-WB-Mini
Camera	FUJIFILM	XP90	S-SL-355, Snap-H-WB-L, Zip-M, Hip-M, PE-WB-Mini
Camera	FUJIFILM	X-Pro1	Rangefinder
Camera	FUJIFILM	XQ1	Zip-S, Hip-S, Snap HW M, PE WB Mini
Camera	FUJIFILM	XQ2	Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	FUJIFILM	X-S1	D-Midsize,
Camera	FUJIFILM	X-T1	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	FUJIFILM	X-T1 IR	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	FUJIFILM	X-T10	D-M4/3
Camera	FUJIFILM	X-T100	D-M4/3
Camera	FUJIFILM	X-T2	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	FUJIFILM	X-T20	D-M4/3
Camera	FUJIFILM	X-T3	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	FUJIFILM	Z1	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	FUJIFILM	Z1000 EXR	P/E-Mini, Snap-H-L
Camera	FUJIFILM	Z100fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	FUJIFILM	Z10fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z10fd/ Z20fd/ Z200fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	FUJIFILM	Z110	P/E-Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324, EZ-Close-421
Camera	FUJIFILM	Z3	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z30/ Z30fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z300	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z33WP	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z35 / Z37	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z5fd	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z70 / Z71	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z700EXR / Z707EXR	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z80/ Z81	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	FUJIFILM	Z800ERX/ Z808EXR	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	FUJIFILM	Z900EXR	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	GE	A1456W	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M, S-SL 355, EZ-Close-421
Camera	GE	A730/ A830	P/E WB-Mini, Zip-M, Hip-M, Snap-M
Camera	GE	C1433	Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M
Camera	GE	DV1	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	GE	E1050	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	GE	E1450W	P/E Mini, Zip-S, Hip-S, Snap-HW-M, Snap-M, S-SL 324, EZ-Close-421
Camera	GE	E1486TW	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	GE	E1680W	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	GE	E850/ E1030/ E1040/ E1240	P/E Mini, Zip-M, Hip-M, Snap-M, S-SL 324, EZ-CLOSE-421
Camera	GE	G1	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	GE	J1470S	P/E Mini, Zip-S, Hip-S, Snap-HW-M, Snap-M, S-SL 324, EZ-Close-421
Camera	GE	PJ1	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	GE	X1	D-Small
Camera	GE	X500	D-Small
Camera	Hasselblad	CFV-50	na
Camera	Hasselblad	H3D	na
Camera	Hasselblad	H3DII	na
Camera	Hasselblad	H4D	na
Camera	Hasselblad	H4X	na
Camera	Hasselblad	H5D	na
Camera	Hasselblad	H5X	na
Camera	Hasselblad	H6D	na
Camera	Hasselblad	Lunar	
Camera	Hasselblad	Hasselblad with Lugs	na
Camera	Hasselblad	X1D	
Camera	Hasselblad	XPan	
Camera	HP	PhotoSmart 120	P/E WB-Mini, Zip-M, Hip-M
Camera	HP	PhotoSmart 215	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart 315	Zip-L, Hip-L
Camera	HP	PhotoSmart 315xi	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart 318/ 318xi/ 320/ 320xi	Zip-M, Hip-M
Camera	HP	PhotoSmart 435 (Q3731A)/ 435xi	P/E WB-Mini, Zip-M, Hip-M, EZ-Close-532
Camera	HP	PhotoSmart 612/ 612xi	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart 618/ 618xi	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart 620/ 620xi	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart 635 (Q2224A)/ 635xi	Zip-M, Hip-M
Camera	HP	PhotoSmart 715/ 715xi	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart 720/ 720xi	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart 735 (Q2210A)/ 735xi	P/E WB-S, Zip-M, Hip-M
Camera	HP	PhotoSmart 812/ 812xi	P/E WB-S, Zip-M, Hip-M
Camera	HP	PhotoSmart 850/ 850xi	D-Small

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	HP	PhotoSmart 935 (Q2214A)/ 935xi	P/E WB-S, Zip-M, Hip-M
Camera	HP	PhotoSmart 945 (Q2200A)/ 945xi	D-Compact
Camera	HP	PhotoSmart C200/ C200xi	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart C500/ C500xi	P/E WB-Med, Zip-L, Hip-L
Camera	HP	PhotoSmart C912	SLR-Auto
Camera	HP	PhotoSmart E317/ E327	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355
Camera	HP	PhotoSmart E337	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355
Camera	HP	PhotoSmart M22/ M23	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	HP	PhotoSmart M307/ M407	P/E WB-Mini, Zip-M, Hip-M, S-SL 355
Camera	HP	PhotoSmart M417/ M517	P/E WB-Mini, Zip-M, Hip-M
Camera	HP	PhotoSmart M425/ M525/ M527	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	HP	PhotoSmart M437	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355, EZ-Close-421
Camera	HP	PhotoSmart M537	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355, EZ-Close-421
Camera	HP	PhotoSmart M607/ R607xi	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	HP	PhotoSmart M707/ R707xi	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 355
Camera	HP	PhotoSmart Mz67	P/E WB-Mini, Zip-M, Hip-M, Snap-M
Camera	HP	PhotoSmart R507	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	HP	PhotoSmart R607	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	HP	PhotoSmart R707	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 355
Camera	HP	PhotoSmart R717	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 355
Camera	HP	PhotoSmart R725/ R727	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	HP	PhotoSmart R742	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	HP	PhotoSmart R817/ R818	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	HP	PhotoSmart R837	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355, EZ-Close-421
Camera	HP	PhotoSmart R927/ R967	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	HP	PhotoSmart R937	PDA/Cam PDA Milli, Zip-M, Hip-M
Camera	Kiev	Kiev All	na
Camera	KODAK	Advantix T700	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M
Camera	KODAK	C143	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	C180/ C182 / C183	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	KODAK	C190/ C195	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	C300/ C310	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	KODAK	C330/ C340/ C360	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-HW-M
Camera	KODAK	C433	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-HW-M
Camera	KODAK	C513	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	KODAK	C530	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-HW-M
Camera	KODAK	C533	P/E WB-Mini, Zip-M, Hip-M
Camera	KODAK	C613/ C643	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-HW-M
Camera	KODAK	C653	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	C663	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-HW-M
Camera	KODAK	C743	P/E WB-Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	C763	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	KODAK	C875	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	CD1013	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	KODAK	CD80/ CD82	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	KODAK	CD90/ CD93	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	CX6200/ CX6230/ CX6330	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	KODAK	CX7220/ CX7300/ CX7330	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	KODAK	CX7430/ CX7530/ CX7525	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	KODAK	DX4530/ DX6340/ DX6440	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	KODAK	DX6490	D-Small
Camera	KODAK	DX7440	P/E WB-Mini, Zip-M, Hip-M
Camera	KODAK	DX7590	D-Small
Camera	KODAK	DX7630	P/E WB-S, Zip-M, Hip-M
Camera	KODAK	EasyShare-One	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	KODAK	LS443	Zip-L, Hip-L
Camera	KODAK	LS743/ LS753	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 335
Camera	KODAK	M1033	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	KODAK	M341/ M381	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	KODAK	M522	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	KODAK	M531	P/E WB-Mini, Zip-M, Hip-M, Snap-H-WB-L, S-SL-355, EZ-Close-421
Camera	KODAK	M590	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	KODAK	M753/ M853	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	M763/ M863	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	KODAK	M873/ M883	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	KODAK	M893 IS	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	KODAK	MD30	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	KODAK	MiniShot	PDA-Micro,
Camera	KODAK	P712	D-Small
Camera	KODAK	P850	D-Small
Camera	KODAK	P880	D-Offset
Camera	KODAK	PIXPRO AZ252	D-Small
Camera	KODAK	PIXPRO AZ401	D-Offset
Camera	KODAK	PIXPRO AZ421	D-Small
Camera	KODAK	PIXPRO AZ652	D-Offset
Camera	KODAK	PIXPRO AZ901	D-Midsize
Camera	KODAK	PIXPRO FZ201	D-Micro, Zip-M, Hip-M,
Camera	KODAK	PIXPRO FZ43	Snap-HW-M, Zip-S, Hip-S, S-SL-355, EZ-Close-321
Camera	KODAK	PIXPRO FZ53	P/E Mini, Zip-S, Hip-S, Snap-HW-M, S-SL-355, EZ-Close-321
Camera	KODAK	V1073/ V1273	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	KODAK	V1233	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	KODAK	V1253	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	KODAK	V530	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	KODAK	V550	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	KODAK	V570/ V705	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	KODAK	V603	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	KODAK	V610	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	KODAK	V803/ V1003	P/E WB-Mini, Zip-M, Hip-M, Snap-H-WB-L, S-SL-355, EZ-Close-421
Camera	KODAK	Z1012 IS	D-Small
Camera	KODAK	Z1085 IS/ Z1285/ Z8612	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	Z1275	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	Z1485 IS	P/E WB-Mini, Zip-M, Hip-M
Camera	KODAK	Z612	D-Small
Camera	KODAK	Z650	D-Small
Camera	KODAK	Z700	P/E WB-S, Zip-M, Hip-M
Camera	KODAK	Z705	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	KODAK	Z710 Zoom	D-Small
Camera	KODAK	Z712 IS	D-Small
Camera	KODAK	Z730/ Z760	P/E WB-Mini, Zip-M, Hip-M
Camera	KODAK	Z740	D-Small
Camera	KODAK	Z7590	D-Small
Camera	KODAK	Z812 IS	WB-M, Zip-L, D-Compact
Camera	KODAK	Z8612 IS	D-Small
Camera	KODAK	Z885	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	KODAK	Z915	P/E WB-Small, Zip-M, Hip-M, Snap-HW-L
Camera	KODAK	Z950	P/E WB-Small, Zip-M, Hip-M, Snap-HW-L
Camera	KODAK	Z980 IS	NA
Camera	KODAK	Z981	D-Offset
Camera	KODAK	ZD15	P/E WB-Small, Zip-M, Hip-M, Snap-HW-L
Camera	KODAK	ZD710	D-Small
Camera	KYOCERA	Dental Eye III	None available at this time.
Camera	KYOCERA	L3v	P/E WB-Mini, Zip-M, Hip-M
Camera	KYOCERA	L4v	P/E WB-Mini, Zip-M, Hip-M
Camera	KYOCERA	S5R	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	KYOCERA	SL300R	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	LEICA	C	Snap-HW-L, Zip-M, Hip-M, PE-WB-MiniSnap_HW_M, EZ-Close-421
Camera	LEICA	CL	D-Shortie, D-M 4/3
Camera	LEICA	C-Lux	D-Micro
Camera	LEICA	C-LUX 1	Euro P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-321
Camera	LEICA	C-Lux 3	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	LEICA	Digilux	P/E WB-Med, Zip-L, Hip-L
Camera	LEICA	Digilux 1	D-Compact
Camera	LEICA	Digilux 2	SLR Auto
Camera	LEICA	Digilux 3	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	LEICA	Digilux 4.3	Zip-M, Hip-M
Camera	LEICA	Digilux Zoom	Zip-M, Hip-M
Camera	LEICA	Digital Module R	D-Pro
Camera	LEICA	D-Lux	SLR Manual, S-SL 335
Camera	LEICA	D-LUX (Typ 109)	D-Micro
Camera	LEICA	D-LUX 2	Zip-M, Hip-M, S-SL 335, EZ-Close-421
Camera	LEICA	D-Lux 3	Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	LEICA	D-Lux 4	WB Mini, Zip-M, Hip-M, D-Micro, S-SL 355, EZ-Close-421

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	LEICA	D-Lux 6	D-Micro
Camera	LEICA	M (Typ 240)	Rangefinder
Camera	LEICA	M (Typ 262)	Rangefinder,
Camera	LEICA	M (Typ 262)	Rangefinder
Camera	LEICA	M10	Rangefinder
Camera	LEICA	M10-P	Rangefinder
Camera	LEICA	M3/ M6/ M6 TTL/ M7	Rangefinder
Camera	LEICA	M8/ M8.2/ M9	Rangefinder
Camera	LEICA	M-A (Typ 127) Rangefinder	SLR-Manual
Camera	LEICA	M-E Typ 220	Rangefinder
Camera	LEICA	M-Monochrom	P/E Large, Zip-L, Hip-L, B Cover-Manual
Camera	LEICA	M-Monochrom (Typ 246)	P/E Large, Zip-L, Hip-L, B Cover-Manual
Camera	LEICA	MP	Rangefinder
Camera	LEICA	Q (Typ 116)	D-Shortie, D-M 4/3
Camera	LEICA	R8/ R9	D-SLR
Camera	LEICA	S2	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	LEICA	SL (Typ 601)	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	LEICA	TL	Rangefinder, Rangefinder-Tele
Camera	LEICA	TL2	Rangefinder, Rangefinder-Tele
Camera	LEICA	V-LUX (Typ 114)	D-Midsized,
Camera	LEICA	V-Lux 1	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	LEICA	V-Lux 20	P/E WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	LEICA	V-Lux 3	D-Shortie
Camera	LEICA	V-Lux 30	P/E WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	LEICA	V-Lux 4	D-Offset
Camera	LEICA	V-Lux 40	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	LEICA	X (Typ 113) with Summilux 23mm f/1.7 ASPH	D-M Shortie
Camera	LEICA	X Vario	D-Shortie, D-M 4/3
Camera	LEICA	X1	Zip-L, Hip-L, D-Compact
Camera	LEICA	X2	P/E WB-Med, D-Shortie,
Camera	LEICA	X-E (Typ 102) with Elmarit 24mm f/2.8 ASPH	D-M Shortie
Camera	LEICA	X-U (Typ 113)	Rangefinder,
Camera	LG	PC389	na
Camera	MAMIYA	ZD	unkown
Camera	MAMIYA	Phase One XF	na
Camera	MAMIYA	645DF	na
Camera	MAMIYA	Mamiya with Lugs	na
Camera	MINOLTA	AF 35 Bigfinder/ AF 50 Bigfinder	P/E WB-Mini, Zip-M, Hip-M
Camera	MINOLTA	Diimage 2300	P/E WB-Mini, Zip-M, Hip-M
Camera	MINOLTA	Diimage 2330 Zoom	P/E WB-Med, Zip-L, Hip-L
Camera	MINOLTA	DiIMAGE 5	D-Offset
Camera	MINOLTA	DiIMAGE 7/ 7Hi/ 7i	D-Offset
Camera	MINOLTA	DiIMAGE A1/ A2/ A200	D-Offset
Camera	MINOLTA	DiIMAGE E201	P/E WB-Med, Zip-L, Hip-L
Camera	MINOLTA	DiIMAGE E223	P/E WB-Mini, Zip-M, Hip-M
Camera	MINOLTA	DiIMAGE E323	P/E WB-Mini, Zip-M, Hip-M, Snap-M, S-SL 355
Camera	MINOLTA	DiIMAGE EX1500 Wide	P/E WB-Med, Zip-L, Hip-L
Camera	MINOLTA	DiIMAGE EX1500 Zoom	P/E WB-Med, Zip-L, Hip-L
Camera	MINOLTA	DiIMAGE F100/ F200/ F300	P/E WB-Mini, Zip-M, Hip-M, S-SL 355
Camera	MINOLTA	DiIMAGE G400/ G500/ G530/ G600	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	MINOLTA	DiIMAGE RD 3000	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	MINOLTA	DiIMAGE S304/ S404/ S414	P/E WB-Med, Zip-L, Hip-L
Camera	MINOLTA	DiIMAGE X/ Xg/ Xi/ Xt/ Xt Biz	P/E Mini, Zip-S, Hip-S
Camera	MINOLTA	Diimage X1	P/E WB-Mini, Zip-M, Hip-M, Snap-M
Camera	MINOLTA	DiIMAGE X20/ X31/ X50	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	MINOLTA	DiIMAGE X60	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	MINOLTA	DiIMAGE Z1/ Z2/ Z3	D-Small
Camera	MINOLTA	DiIMAGE Z10/ Z20	D-Offset
Camera	MINOLTA	DiIMAGE Z5	D-Offset
Camera	MINOLTA	Diimage Z6	D-Offset
Camera	MINOLTA	Maxxum 3 Date	D-Midsized, D-Midsized-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	MINOLTA	Maxxum 4/ Maxxum 5	D-Midsized, D-Midsized-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	MINOLTA	Maxxum 5D	D-Midsized, D-Midsized-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	MINOLTA	Maxxum 7	SLR-Auto



OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	MINOLTA	Maxxum 70	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	MINOLTA	Maxxum 7D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	MINOLTA	Maxxum 9	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	MINOLTA	Maxxum HTsi Plus	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	MINOLTA	Maxxum Qtsi/ Stsi/ Xtsi	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	MINOLTA	Vectis S1	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	MINOLTA	Vectis S100	D-Compact
Camera	MINOLTA	X Series x 370s	SLR-Manual
Camera	MINOX	DC 1422	S-SL-324, Snap-H-M, Zip-S, Hip-S, P/E-Mini
Camera	MINOX	DCC 5.1	na
Camera	NIKON	1 AW1	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 J1	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 J2	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 J3	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 J4	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 J5	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 S1	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 S2	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 V1	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 V2	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	1 V3	D-Compact, D-Shortie, D-M 4/3
Camera	NIKON	COOLPIX 2000	WB Mini, Zip-M, Hip-M, Snap-HW-L
Camera	NIKON	COOLPIX 2100/ 2200	P/E WB-Mini, Zip-M, Hip-M
Camera	NIKON	COOLPIX 2500	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	NIKON	COOLPIX 3100/ 3200/ 4100	P/E WB-Mini, Zip-M, Hip-M
Camera	NIKON	COOLPIX 3500	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	NIKON	COOLPIX 3700	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX 4200	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M, S-SL 324
Camera	NIKON	COOLPIX 4300	P/E WB-Sm, Zip-M, Hip-M
Camera	NIKON	COOLPIX 4500	P/E WB-Med, Zip-L, Hip-L
Camera	NIKON	COOLPIX 4600/ 5600/ 7600	P/E WB-Mini, Zip-M, Hip-M
Camera	NIKON	COOLPIX 4800	P/E WB-Sm, Zip-M, Hip-M
Camera	NIKON	COOLPIX 5000	P/E WB-Med, Zip-L, Hip-L
Camera	NIKON	COOLPIX 5200	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M, S-SL 324
Camera	NIKON	COOLPIX 5400	WB-M, Zip-L, D-Compact
Camera	NIKON	COOLPIX 5700	D-Offset
Camera	NIKON	COOLPIX 5900/ 7900	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-HW-M
Camera	NIKON	COOLPIX 775	P/E WB-Mini, Zip-M, Hip-M
Camera	NIKON	COOLPIX 8400	D-Small
Camera	NIKON	COOLPIX 8700	D-Offset
Camera	NIKON	COOLPIX 880	P/E WB-S, Zip-M, Hip-M
Camera	NIKON	COOLPIX 8800	D-Offset
Camera	NIKON	COOLPIX 885	P/E WB-S, Zip-M, Hip-M
Camera	NIKON	COOLPIX 995	PDA Macro, Zip-L, Hip-L
Camera	NIKON	COOLPIX A	D-Micro, Zip-M, Hip-M
Camera	NIKON	COOLPIX A10	S-SL-355, Snap-H-WB-M, Zip-S, Hip-S, PE-WB-Mini, EZ-Close-421
Camera	NIKON	COOLPIX A10	S-SL-355, Snap-H-WB-M, Zip-S, Hip-S, PE-WB-Mini, EZ-Close-421
Camera	NIKON	COOLPIX A100	S-SL-324, Snap-H-M, Zip-S, Hip-S, P/E-Mini, EZ-Close-321
Camera	NIKON	COOLPIX A900	D-Micro, Zip-M, Hip-M
Camera	NIKON	COOLPIX AW100	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	NIKON	Coolpix AW110	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini
Camera	NIKON	COOLPIX AW120	Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	NIKON	Coolpix AW130	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini
Camera	NIKON	COOLPIX B500	D-Offset
Camera	NIKON	COOLPIX B700	D-Offset
Camera	NIKON	COOLPIX L1	P/E WB-Mini, Zip-M, Hip-M
Camera	NIKON	COOLPIX L10/ L11/ L12	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX L100	D-Offset
Camera	NIKON	COOLPIX L110	D-Offset

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	NIKON	COOLPIX L120	D-Offset
Camera	NIKON	COOLPIX L15/ L14	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX L16/ L18	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX L19	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	NIKON	COOLPIX L2/ L3	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX L20	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	NIKON	COOLPIX L21	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX L22	P/E WB-Mini, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	NIKON	COOLPIX L24	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	NIKON	COOLPIX L25	P/E WB-Mini, Zip-S, Hip-S, Snap-HW-M, EZ-Close-421
Camera	NIKON	COOLPIX L26	P/E WB-Mini, Zip-S, Hip-S, Snap-HW-M, EZ-Close-421
Camera	NIKON	Coolpix L28	S-SL-355, Snap-HW-M, Zip-M, Hip-M, P/E-WB-Mini, EZ-Close-421
Camera	NIKON	COOLPIX L31	S-SL 355, Snap-HW-M, Zip-S, Hip-S, PE-WB-Mini, EZ-Close-421
Camera	NIKON	COOLPIX L32	S-SL 355, Snap-HW-M, Zip-S, Hip-S, PE-WB-Mini, EZ-Close-321
Camera	NIKON	Coolpix L320	D-Small
Camera	NIKON	Coolpix L330	D-Small
Camera	NIKON	COOLPIX L340	D-Small
Camera	NIKON	COOLPIX L4	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M
Camera	NIKON	COOLPIX L5	P/E WB-S, Zip-M, Hip-M
Camera	NIKON	COOLPIX L6	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX L610	P/E WB-Mini, Zip-M, Hip-M
Camera	NIKON	COOLPIX L620	Zip_M, Hip_M, PE_WB_Mini
Camera	NIKON	COOLPIX L810	D-Small
Camera	NIKON	Coolpix L820	D-Small
Camera	NIKON	COOLPIX L830	NA
Camera	NIKON	Coolpix L840	NA
Camera	NIKON	COOLPIX P1/ P2	P/E Mini, Zip-S, Hip-S
Camera	NIKON	COOLPIX P100	D-Offset
Camera	NIKON	COOLPIX P1000	D-SLR-Zoom
Camera	NIKON	COOLPIX P3	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX P300	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	NIKON	COOLPIX P310	Snap-HW-L, S-SL 355
Camera	NIKON	Coolpix P330	Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	NIKON	COOLPIX P340	Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	NIKON	COOLPIX P50	P/E WB-S, Zip-M, Hip-M
Camera	NIKON	COOLPIX P500	D-Offset
Camera	NIKON	COOLPIX P5000	P/E WB-S, Zip-M, Hip-M
Camera	NIKON	COOLPIX P510	D-Offset
Camera	NIKON	COOLPIX P5100	P/E WB-S, Zip-M, Hip-M
Camera	NIKON	Coolpix P520	D-Offset
Camera	NIKON	COOLPIX P530	D-Offset
Camera	NIKON	COOLPIX P60	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M
Camera	NIKON	COOLPIX P600	D-Offset
Camera	NIKON	COOLPIX P6000	P/E WB-Sm, Zip-M, Hip-M
Camera	NIKON	Coolpix P610	D-Offset
Camera	NIKON	COOLPIX P7000	D-Mini, Hip-M, Zip-M
Camera	NIKON	COOLPIX P7100	P/E WB-Med, D-Mini
Camera	NIKON	COOLPIX P7700	D-Shortie, P/E WB-Med, B-Cover-Man
Camera	NIKON	COOLPIX P7800	D-Compact
Camera	NIKON	COOLPIX P80	D-Compact
Camera	NIKON	COOLPIX P90	D-Offset
Camera	NIKON	COOLPIX P900	D-SLR
Camera	NIKON	COOLPIX S01	EURO-MINI,
Camera	NIKON	COOLPIX S02	Euro_Mini, Zip_S
Camera	NIKON	COOLPIX S1/ S2/ S3	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S10	WB Mini, Zip-M, Hip-M, Snap-HW-L
Camera	NIKON	COOLPIX S100	WB Mini, Zip-M, Hip-M, S-SL 324
Camera	NIKON	COOLPIX S1000PJ	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	NIKON	COOLPIX S1100PJ	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	NIKON	COOLPIX S1200PJ	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	NIKON	COOLPIX S200/ S210	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	NIKON	COOLPIX S220	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	NIKON	COOLPIX S230	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S2900	S-SL 324, Snap-H-M, Zip-S, Hip-S, PE-Mini, EZ-Close-321
Camera	NIKON	COOLPIX S2900	S-SL 324, Snap-H-M, Zip-S, Hip-S, PE-Mini, EZ-Close-321
Camera	NIKON	COOLPIX S30	Zip-M, Hip-M
Camera	NIKON	COOLPIX S3000	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	NIKON	COOLPIX S31	Zip-M, Hip-M
Camera	NIKON	COOLPIX S3100	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	NIKON	COOLPIX S32	D-Micro, Zip-M, Hip-M
Camera	NIKON	COOLPIX S33	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini
Camera	NIKON	COOLPIX S3300	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S3500	Snap-H-M, Zip-S, Hip-S, EZ-Close-421
Camera	NIKON	COOLPIX S3600	S-SL-355, Snap-H-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	NIKON	COOLPIX S3700	S-SL 355, Snap-H-WB-M, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	NIKON	COOLPIX S4	WB Mini, Zip-M, Hip-M, Snap-HW-L
Camera	NIKON	COOLPIX S4000	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S4100	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S4300	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S5	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S500	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S51	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S510	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S5100	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S51c	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S52/ S52C	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S520	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S5200	S-SL-335, Snap-HW-M, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	NIKON	COOLPIX S5300	S-SL-355, Snap-H-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	NIKON	COOLPIX S560	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S570	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S6	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S60	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S600	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S6000	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 335, EZ-Close-421
Camera	NIKON	COOLPIX S610/ S610C	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S6100	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S620	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S6200	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S630	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S6300	Zip-S, Hip-S, Snap-HW-M, S-SL 324
Camera	NIKON	COOLPIX S640	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S6400	S-SL 355, SNAP-HW-M, ZIP-S, HIP-S, EZ-Close-321
Camera	NIKON	COOLPIX S6800	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	NIKON	COOLPIX S6900	S-SL 355, Snap-HW_M, Zip-S, Hip-S, P/E-WB-Mini, EZ-Close-421
Camera	NIKON	COOLPIX S70	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S700	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S7000	S-SL 355, Snap-HW_M, Zip-S, Hip-S, P/E-WB-Mini, EZ-Close-421
Camera	NIKON	COOLPIX S710	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S7c	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	NIKON	COOLPIX S80	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	NIKON	COOLPIX S8000	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	NIKON	COOLPIX S800c	S-SL 355, SNAP-HW-L, EZ-Close-421

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	NIKON	COOLPIX S8100	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S810c	P/E WB-Med, Zip-L, Hip-L, EZ-Close-421
Camera	NIKON	COOLPIX S8200	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	NIKON	COOLPIX S9	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	NIKON	COOLPIX S9100	WB Mini, Zip-M, Hip-M, Snap-HW-L
Camera	NIKON	COOLPIX S9300	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	NIKON	COOLPIX S9500	S-SL-356, Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini, EZ-Close-421
Camera	NIKON	COOLPIX S9700	Zip-M, Hip-M, PE-WB-Mini
Camera	NIKON	COOLPIX S9900	D-Micro, Zip-M, Hip-M
Camera	NIKON	COOLPIX SQ	None available at this time.
Camera	NIKON	Coolpix W100	S-SL-355, Snap-H-WB-L, Zip-M, Hip-M, PE-WB-Mini
Camera	NIKON	Coolpix W300	Snap-H-WB-L, Zip-M, Hip-M, PE-WB-M
Camera	NIKON	D100	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D1H/ D1X	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	NIKON	D200	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D2H/ D2Hs/ D2X/ D2Xs	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	NIKON	D3/ D3X/ D3s	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	NIKON	D300 / D300S	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D3000	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D3100	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D3200	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D3300	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D3400	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D3500	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D4	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	NIKON	D40/ D40X/ D60	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D4s	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	NIKON	D5	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	NIKON	D50	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D500	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D5000	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D5100	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D5200	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D5300	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D5500	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D5600	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D600	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D610	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D70	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D700	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D7000	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D70s	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D7100	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D7200	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D750	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D7500	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D80/ D90	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	D800/ D800E/ D810	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D810A	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	D850	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	NIKON	Df	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	DL18-50 f/1.8-2.8	D-Mini, Zip-M, Hip-M,
Camera	NIKON	DL24-500 f/2.8-5.6	D-Midsize,
Camera	NIKON	DL24-85 f/1.8-2.8	D-Mini, Zip-M, Hip-M,
Camera	NIKON	F100	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	F3HP	SLR Manual
Camera	NIKON	F5	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	NIKON	F6 Film SLR	D-SLR
Camera	NIKON	FM10/ FM2N/ FM3A	SLR Manual
Camera	NIKON	N55/ N75	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	NIKON	N60/ N70	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	N65/ N80	SLR Auto
Camera	NIKON	N90s	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	NIKON	Nikonos-V	SLR Auto
Camera	NIKON	Z6	D-Midsize
Camera	NIKON	Z7	D-Midsize,
Camera	OLYMPUS	Air A01	FOP-251
Camera	OLYMPUS	E-3	D-Pro, D-Pro-Zoom, D-Pro-Tele, Body Cover AF-Pro
Camera	OLYMPUS	E-30	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	OLYMPUS	E-330	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	OLYMPUS	E-400/ E-410/ E-420/ E-430 E-450	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	OLYMPUS	E-5	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	OLYMPUS	E-500	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	OLYMPUS	E-510/ E-520	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	OLYMPUS	E-620	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	OLYMPUS	E-M5	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	E-P1/ E-P2	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	E-P3	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	E-PL1/ E-PL1s	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	E-PL2	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	E-PL3	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	E-PL7	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	E-PL8	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	E-PM1	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	FE 4030/ 4040	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE 45	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE 47	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	OLYMPUS	FE 5030	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-100/ FE-110/ FE-115	WB Mini, Zip-M, Hip-M
Camera	OLYMPUS	FE-115	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-120	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	OLYMPUS	FE-130/ FE-140	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	OLYMPUS	FE-150	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-170	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-180	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-190	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	OLYMPUS	FE-20	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	FE-200	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	FE-210	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-240/ FE-250/ FE-230	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	OLYMPUS	FE-26 / FE-46	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	OLYMPUS	FE-270	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-280	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-290	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	FE-300	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	OLYMPUS	FE-3000/ 3010	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-310	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-340	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	FE-350	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	FE-360/ FE370	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-4000 / FE-5020	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-4050	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	OLYMPUS	FE-5000/ 5010	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	FE-5050	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	OLYMPUS	Ferrari 2004	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-HW-M
Camera	OLYMPUS	IS1 / IS2	na
Camera	OLYMPUS	Mju 1040	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Mju 1050	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	mju 1060	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Mju 5010	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Mju 550WP / Stylus 550WP	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Mju 7000 / Stylus 7000	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Mju 7030	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Mju 7040	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Mju 9000 / Stylus 9000	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355, EZ-Close-421
Camera	OLYMPUS	Mju 9010	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Mju Tough 3000 / 6000 / 8000	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Mju Tough 6020	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	OLYMPUS	Mju Tough 8010	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	mju-7050	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	OM-D E-M1	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	OLYMPUS	OM-D E-M1 Mark II	D-Midsize
Camera	OLYMPUS	OM-D E-M10	D-Shortie, Zip-L, Hip-L, PE-WB-M
Camera	OLYMPUS	OM-D E-M10 II	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	OM-D E-M10 III	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	OM-D E-M5	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	OM-D E-M5 II	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	PEN E-P5	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	PEN E-PL5	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	PEN E-PL9	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	PEN E-PM2	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	PEN-F	D-Compact, D-Shortie, D-M 4/3
Camera	OLYMPUS	SH-21	WB Mini, Zip-M, Hip-M, Snap-HW-L, EZ-Close-421
Camera	OLYMPUS	SH-50 iHS	D-Micro, Zip-M, Hip-M
Camera	OLYMPUS	SP 320	WB Mini, Zip-M, Hip-M
Camera	OLYMPUS	SP 600 UZ	D-Offset
Camera	OLYMPUS	SP 800 UZ	D-Offset
Camera	OLYMPUS	SP-310/ SP-320/ SP-350	WB Mini, Zip-M, Hip-M
Camera	OLYMPUS	SP-500 UZ	WB-M, Zip-L, D-Compact
Camera	OLYMPUS	SP-510 UZ	D-Small
Camera	OLYMPUS	SP-550 UZ	D-Compact
Camera	OLYMPUS	SP-560 UZ	D-Compact
Camera	OLYMPUS	SP-565 UZ	D-Compact
Camera	OLYMPUS	SP-570 UZ	D-Compact
Camera	OLYMPUS	SP-590 UZ	D-Offset
Camera	OLYMPUS	SP-610UZ	D-Compact
Camera	OLYMPUS	SP-620 UZ	D-Compact
Camera	OLYMPUS	SP-700	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	SP-720UZ IHS	D-Compact

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	OLYMPUS	SP-810UZ	WB-M, Zip-L, D-Compact
Camera	OLYMPUS	SP-820UZ	D-Offset
Camera	OLYMPUS	Stylis 820	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus 1	D-Compact
Camera	OLYMPUS	Stylus 1000/ 1010/ 1020	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus 1030 SW / Tough	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus 1050 SW / Tough	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus 1200	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus 1s	D-Compact
Camera	OLYMPUS	Stylus 600	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus 700	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus 710/ 720SW/ 725SW	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus 730	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus 740/ 750	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus 760	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus 770 SW / Tough	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus 780	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus 790 SW / Tough	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus 800	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	OLYMPUS	Stylus 810	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus 830/ 840	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus 850 SW / Tough	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus SH-1	D Micro, Zip-M, Hip-M
Camera	OLYMPUS	Stylus SH-2	D Micro, Zip-M, Hip-M
Camera	OLYMPUS	Stylus SP-100	D-Midsize,
Camera	OLYMPUS	Stylus Tough TG-850 iHS	Snap-H-WB-L, Zip-M, Hip-M, PE-WB-Mini, EZ-Close-421
Camera	OLYMPUS	Stylus Tough TG-860	S-SL 376, Zip-L, Hip-L, EZ-Close-532
Camera	OLYMPUS	Stylus Tough TG-870	Snap-H-WB-L, Zip-M, Hip-M, PE-WB-Mini, EZ-Close-421
Camera	OLYMPUS	Stylus u 7010	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	Stylus u Tough 6010	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	Stylus Verve / Verve S	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	SZ-10	P/E WB-Sm, Zip-M, Hip-M
Camera	OLYMPUS	SZ-12	Zip-M, Hip-M
Camera	OLYMPUS	SZ-15	D-Micro, Zip-M, Hip-M
Camera	OLYMPUS	SZ-16 iHS	D-Micro, Zip-M, Hip-M
Camera	OLYMPUS	SZ-30MR	P/E WB-Sm, Zip-M, Hip-M
Camera	OLYMPUS	SZ-31MR iHS	Zip-M, Hip-M
Camera	OLYMPUS	T-100/ T-110	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	TG-1 iHS	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-M, S-SL-355
Camera	OLYMPUS	TG-2 iHS	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini
Camera	OLYMPUS	TG-310	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	TG-320	P/E Mini, Zip-S, Hip-S, Snap-HW-M, S-SL-324, EZ-Close-421
Camera	OLYMPUS	TG-610	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	OLYMPUS	TG-630 iHS	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, P/E-WB-Mini
Camera	OLYMPUS	TG-810	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	OLYMPUS	TG-820 iHS	P/E Mini, Zip-S, Hip-S, Snap-HW-M, S-SL 324, EZ-Close-421
Camera	OLYMPUS	TG-830 iHS	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini
Camera	OLYMPUS	Tough TG-3	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini
Camera	OLYMPUS	Tough TG-4	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini
Camera	OLYMPUS	Tough TG-5	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini
Camera	OLYMPUS	VG-110	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	OLYMPUS	VG-120	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324, EZ-Close-421
Camera	OLYMPUS	VG-160	P/E Mini, Zip-S, Hip-S, Snap H-M, S-SL-324, EZ-Close-421
Camera	OLYMPUS	VH-410	SL-355, PE-Mini, EZ-Close-421
Camera	OLYMPUS	VH-515	SL-355, PE-Mini, EZ-Close-421
Camera	OLYMPUS	VH-520	SL-355, PE-Mini, EZ-Close-421
Camera	OLYMPUS	VR-320	P/E WB-Sm, Zip-M, Hip-M
Camera	OLYMPUS	VR-330	P/E WB-Sm, Zip-M, Hip-M

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	OLYMPUS	VR-340	P/E Mini, Zip-S, Hip-S, Snap H-M, S-SL-324, EZ-Close-421
Camera	OLYMPUS	X-560 WP	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	OLYMPUS	XZ-1	Zip-L, Hip-L
Camera	OLYMPUS	XZ-10	Zip-M, Hip-M, PE-WB-Mini
Camera	OLYMPUS	XZ-2 iHS	D-Micro, PE-WB-Med
Camera	PANASONIC Lumix	DC-G9	D-Midsize, D-Midsize-Zoom, B-Cover-Mid
Camera	PANASONIC Lumix	DC-GH5 / DC-GH5S	D-SLR, D-SLR-Zoom, D-Pro, B-Cover-SLR, B-Cover-SLR-Pro
Camera	PANASONIC Lumix	DC-GX9	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DC-LX100 II	D-Micro, Zip-M
Camera	PANASONIC Lumix	DC-TS7 (FT7)	D-Mini,
Camera	PANASONIC Lumix	DC-ZS200	D-Micro, Zip-M, Hip-M
Camera	PANASONIC Lumix	DC-ZS70	D-Micro, Zip-M, Hip-M
Camera	PANASONIC Lumix	DMC-3D1	WB Mini, Zip-M, Hip-M, D-Micro, S-SL 335, EZ-Close-421
Camera	PANASONIC Lumix	DMC-F1K/ DMC-F1S	P/E Mini, Zip-S, Hip-S,Euro-S, S-SL 335, EZ-Close-421
Camera	PANASONIC Lumix	DMC-F5	Zip-S, Hip-S,P/E-Mini, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FH10	S-SL-324, Snap-H-M, Zip-S, Hip-S, P/E-Mini
Camera	PANASONIC Lumix	DMC-FH22	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FH6	P/E Mini, Zip-S, Hip-S, Snap H-M, S-SL-324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FH7	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	PANASONIC Lumix	DMC-FH8	P/E Mini, Zip-S, Hip-S, Snap H-M, S-SL-324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FP1/ DMC-FP2/ DMC-FP1	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	PANASONIC Lumix	DMC-FP8	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FS10/ FS11	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FS12	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FS25	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FS30/ FS33	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FS42	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FS5/ FS20	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FS6/ FS7/ FS15	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FS62	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FT1	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FT2	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FT20	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FT4	P/E WB-Mini, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX01/ FX07	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX1/ FX3/	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321



OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	PANASONIC Lumix	DMC-FX10/ FX12	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX100/ FX150	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX30	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX33/ FX35/ FX37	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX40	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX5	P/E Mini, Zip-M, Hip-M, Euro-S, S-SL 335, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX50	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX500	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX55	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX550	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX60 / FX65	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX66	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX7/ FX7K	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX70 / FX75	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX700	P/E Mini, Zip-M, Hip-M, Snap-HW-L, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FX8K/ FX8S/ FX9K/ FX9S	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PANASONIC Lumix	DMC-FX90	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-FZ100	D-Compact
Camera	PANASONIC Lumix	DMC-FZ1000	D-SLR, D-SLR-Zoom
Camera	PANASONIC Lumix	DMC-FZ10K/ DMC-FZ10S	SLR Auto
Camera	PANASONIC Lumix	DMC-FZ150	D-Offset
Camera	PANASONIC Lumix	DMC-FZ15K	SLR Manual
Camera	PANASONIC Lumix	DMC-FZ18	D-Offset
Camera	PANASONIC Lumix	DMC-FZ1K/ DMC-FZ1S	D-Small
Camera	PANASONIC Lumix	DMC-FZ200	D-Offset,
Camera	PANASONIC Lumix	DMC-FZ2000	D-SLR, D-SLR-Zoom
Camera	PANASONIC Lumix	DMC-FZ20K/ FZ20S	SLR Manual
Camera	PANASONIC Lumix	DMC-FZ2500	D-SLR, D-SLR-Zoom
Camera	PANASONIC Lumix	DMC-FZ28	D-Offset ??????
Camera	PANASONIC Lumix	DMC-FZ3/ FZ4/ FZ5/ FZ5K/ FZ5S/ FZ4S	D-Small
Camera	PANASONIC Lumix	DMC-FZ300	D-Midsize,
Camera	PANASONIC Lumix	DMC-FZ30K/ FZ30S/ FZ50	D-Midsize,
Camera	PANASONIC Lumix	DMC-FZ35 / FZ38	D-Offset ??????
Camera	PANASONIC Lumix	DMC-FZ40/ FZ45	D-Offset

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	PANASONIC Lumix	DMC-FZ47 / FZ48	D-Compact
Camera	PANASONIC Lumix	DMC-FZ60/ DMC-FZ62	D-Shortie,
Camera	PANASONIC Lumix	DMC-FZ70	D-Midsize,
Camera	PANASONIC Lumix	DMC-FZ70	D-Midsize,
Camera	PANASONIC Lumix	DMC-FZ7K/ FZ7S	D-Small
Camera	PANASONIC Lumix	DMC-FZ8	D-Small
Camera	PANASONIC Lumix	DMC-FZ80	D-Midsize,
Camera	PANASONIC Lumix	DMC-G1 / G2 / G10	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-G3	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-G5	Zip-M, Hip-M
Camera	PANASONIC Lumix	DMC-G6	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-G7	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-G85	D-Midsize
Camera	PANASONIC Lumix	DMC-GF1	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GF2	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GF3	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GF5	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GF7	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GH1	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-GH2	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-GH3	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-GH4	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-GH5	D-SLR, D-SLR-Zoom, D-Pro, B-Cover-SLR, B-Cover-SLR-Pro
Camera	PANASONIC Lumix	DMC-GM1	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GM5	D-Small
Camera	PANASONIC Lumix	DMC-GX1	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GX7	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GX8	D-Midsize
Camera	PANASONIC Lumix	DMC-GX85/ GX80/ GX7	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-GX850	D-Compact, D-Shortie, D-M 4/3
Camera	PANASONIC Lumix	DMC-L1	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	PANASONIC Lumix	DMC-L10	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-LC1	Rangefinder
Camera	PANASONIC Lumix	DMC-LC33/ DMC-LC43/ DMC-LC50	WB Mini, Zip-M, Hip-M

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	PANASONIC Lumix	DMC-LC5K/ DMC-LC5S	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PANASONIC Lumix	DMC-LC70/ DMC-LC80	WB Mini, Zip-M, Hip-M
Camera	PANASONIC Lumix	DMC-LF1	P/E WB-Mini, Snap-HW-L, Zip-M, Hip-M, EZ-Close-421
Camera	PANASONIC Lumix	DMC-LS1	Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, EZ-Close-321
Camera	PANASONIC Lumix	DMC-LS2S	Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-LS5	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	PANASONIC Lumix	DMC-LS60/ LS70/ LS75	PDA Milli, Zip-S, Hip-S, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-LS80	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-LS85	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	PANASONIC Lumix	DMC-LX10	D-Micro
Camera	PANASONIC Lumix	DMC-LX100	D-Compact
Camera	PANASONIC Lumix	DMC-LX1K/ LX1S/ LX2/ LX3	Zip-M, Hip-M, D-Micro, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-LX5	P/E WB-Mini, Zip-M, Hip-M
Camera	PANASONIC Lumix	DMC-LX7	D-Micro,
Camera	PANASONIC Lumix	DMC-LZ1/ LZ2	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355
Camera	PANASONIC Lumix	DMC-LZ20	D-Shortie,
Camera	PANASONIC Lumix	DMC-LZ30	D-Offset
Camera	PANASONIC Lumix	DMC-LZ3S/ LZ5K/ LZ5S	WB Mini, Zip-M, Hip-M
Camera	PANASONIC Lumix	DMC-LZ6/ LZ7/ LZ8/ LZ10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355
Camera	PANASONIC Lumix	DMC-S2	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-SZ1	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-SZ10	S-SL 355, Snap-HW-M, Zip-s, Hip-S, PE-WB-Mini, EZ-Close-421
Camera	PANASONIC Lumix	DMC-SZ3	Zip-S, Hip-S,P/E-Mini, EZ-Close-321
Camera	PANASONIC Lumix	DMC-SZ5	P/E Mini, EZ-Close-421
Camera	PANASONIC Lumix	DMC-SZ7	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-TS10	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-TS20	P/E Mini, Zip-S, Hip-S, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-TS25	S-SL-335, Snap-H-L, P/E-Mini, EZ-Close-421
Camera	PANASONIC Lumix	DMC-TS3	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-TS30	S-SL 355, Snap-H-L, PE-Mini, EZ-Close-421
Camera	PANASONIC Lumix	DMC-TS4	P/E WB-Mini, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-TS5	Zip-M, Hip-M
Camera	PANASONIC Lumix	DMC-TS6	Zip-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	PANASONIC Lumix	DMC-TZ1	Zip-M, Hip-M

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	PANASONIC Lumix	DMC-TZ100	D-Micro,
Camera	PANASONIC Lumix	DMC-TZ2/ TZ3	WB Mini, Zip-M, Hip-M, Snap-WB-L
Camera	PANASONIC Lumix	DMC-TZ25	Snap-HW-L, S-SL 355
Camera	PANASONIC Lumix	DMC-TZ30	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-TZ4/ TZ5/ TZ50	WB Mini, Zip-M, Hip-M, Snap-WB-L, S-SL 355
Camera	PANASONIC Lumix	DMC-TZ7	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	PANASONIC Lumix	DMC-TZ70	D-Mini
Camera	PANASONIC Lumix	DMC-TZ8	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	PANASONIC Lumix	DMC-XS1	Snap-H-M, Zip-S, Hip-S, Euro-S
Camera	PANASONIC Lumix	DMC-ZR3	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PANASONIC Lumix	DMC-ZS100	D-Micro,
Camera	PANASONIC Lumix	DMC-ZS15	Snap-HW-L, S-SL 355
Camera	PANASONIC Lumix	DMC-ZS20	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	PANASONIC Lumix	DMC-ZS30	Snap-HW-L, Zip-M, Hip-M, P/E-WB-Mini, EZ-Close-421
Camera	PANASONIC Lumix	DMC-ZS40	Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	PANASONIC Lumix	DMC-ZS45	Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	PANASONIC Lumix	DMC-ZS50	Snap-HW-L, Zip-M, Hip-M, PE-WB-Mini
Camera	PANASONIC Lumix	DMC-ZS60	D-Micro,
Camera	PANASONIC Lumix	DMC-ZX1	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	PANASONIC Lumix	DMC-ZX1	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	PANASONIC Lumix	DMC-ZX3	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PENTAX	645	na
Camera	PENTAX	*ist	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	*ist D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	*ist DS/ *ist DL/ *istDL2	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	645Z	NA
Camera	PENTAX	6X7	na
Camera	PENTAX	Efina	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PENTAX	K-01	D-Shortie
Camera	PENTAX	K-1 MARK II	D-Midsize, B-Cover-Mid,
Camera	PENTAX	K100D/ K110D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K10D	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	PENTAX	K20D/ K200D	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-3	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-3 II	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-30	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-5	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-5 II	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	PENTAX	K-5 IIs	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-50	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-500	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-7	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-m 2000 / K2000	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	KP	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-r	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-S1	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-S2	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	K-x	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	PENTAX	LX	na
Camera	PENTAX	M60	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	MX-1	D-Mini, EZ-Close-532
Camera	PENTAX	MZ-S	SLR-Auto
Camera	PENTAX	Optio 30	P/E WB-Mini, Zip-S, Hip-S, Snap-M, S-SL 355
Camera	PENTAX	Optio 33L	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	PENTAX	Optio 33LF	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	PENTAX	Optio 33WR	P/E WB-S
Camera	PENTAX	Optio 430RS	P/E WB-Mini, Zip-S, Hip-S, Snap-M
Camera	PENTAX	Optio 43WR	P/E WB-S
Camera	PENTAX	Optio 450/ 550/ 555	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	PENTAX	Optio 50	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio 60	P/E WB-Mini, Zip-S, Hip-S
Camera	PENTAX	Optio 750Z	P/E WB-Mini, Zip-M, Hip-M
Camera	PENTAX	Optio A10/ A20	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio A30	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio A40	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio E10/ E20	P/E WB-Mini, Zip-M, Hip-M, Snap-M, Snap-H-M
Camera	PENTAX	Optio E30	P/E WB-Mini, Zip-S, Hip-S, Snap-M, S-SL 355
Camera	PENTAX	Optio E40	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio E50	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio E60	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio E70	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio E70L	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	PENTAX	Optio E80	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio E90	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio H90	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio LS465	Euro Small
Camera	PENTAX	Optio M10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio M30	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	PENTAX	Optio M40	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	PENTAX	Optio M50	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio M90	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio MX4	P/E WB-S, Zip-M, Hip-M
Camera	PENTAX	Optio P80	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio RS1000	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio RS1500	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio RZ10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M, S-SL 355

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	PENTAX	Optio RZ18	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-M, S-SL 355
Camera	PENTAX	Optio S	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S1	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S12	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S30	P/E WB-Mini, Zip-S, Hip-S, Snap-M, S-SL 355
Camera	PENTAX	Optio S4/ S4i	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S40/ S45/ S55	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S50	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S5i	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S5Z	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio S6/ S7	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	PENTAX	Optio S60	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio SV	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio T10/ T20/ T30	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio V10	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	PENTAX	Optio VS20	Zip-M, Hip-M, D-Micro
Camera	PENTAX	Optio W10/ W20/ W30	P/E WB-Mini, Zip-M, Hip-M, Euro-S, EZ-Close-421
Camera	PENTAX	Optio W80 / W90	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio WG-2/ GPS	Zip-L, Hip-L, PR-Shortie, EZ-Close-532
Camera	PENTAX	Optio WP	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio WPI	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	PENTAX	Optio WS80	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio X	Zip-M, Hip-M, Snap-H-L
Camera	PENTAX	Optio Z10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	PENTAX	Optio-i-10	Zip-M, Hip-M, S-SL 355
Camera	PENTAX	P70	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-421
Camera	PENTAX	PC-330/ PC-550	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L
Camera	PENTAX	PZ-1P	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	PENTAX	Q	D-Shortie, D-M 4/3, EZ-Close-321
Camera	PENTAX	Q10	D-Shortie, D-M 4/3
Camera	PENTAX	Q7	D-Shortie, D-M 4/3
Camera	PENTAX	Q-S1	D-Shortie, D-M 4/3
Camera	PENTAX	X 70	D-Offset
Camera	PENTAX	X-5	D-Midsize,
Camera	PENTAX	XG-1	D-Offset
Camera	PENTAX	ZX-7/ ZX-5N/ ZX-50/ ZX-60/ ZX-L	SLR-Auto
Camera	PENTAX	ZX-M	SLR-Manual
Camera	POLAROID	PDC-2075	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	POLAROID	PDC-2077	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	POLAROID	PDC-3030/ 3070	P/E Mini, Zip-S, Hip-S
Camera	POLAROID	PDC-4055/ 4355/ 5355	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	POLAROID	PDC-4370/ 5370	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	RICOH	Caplio R10	PDA Milli, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	RICOH	Caplio RR730	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324
Camera	RICOH	Caplio 500g Wide/ 500SE	D-Compact
Camera	RICOH	Caplio G3	PDA Milli, Zip-L, Hip-L, EZ-Close-532
Camera	RICOH	Caplio GX8	P/E WB-Mini, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	RICOH	Caplio R1V	PDA Milli, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	RICOH	Caplio R2	PDA Milli, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	RICOH	Caplio R3/ R4/ R5	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	RICOH	Caplio R30/ R40	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	RICOH	Caplio R6/ R7/ R8	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	RICOH	Caplio RR1	PDA Micro, Zip-L, Hip-L
Camera	RICOH	Caplio RR1	PDA Micro, Zip-L, Hip-L
Camera	RICOH	Caplio RR211	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	RICOH	Caplio RR30	PDA Milli, Zip-L, Hip-L, EZ-Close-532
Camera	RICOH	Caplio RR530	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	RICOH	Caplio RR770	P/E WB-Mini, Zip-S, Hip-S, Snap-M
Camera	RICOH	Caplio RX	P/E WB-Mini, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	RICOH	CX1	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355, EZ-Close-421

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	RICOH	CX2	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355, EZ-Close-421
Camera	RICOH	CX3	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355, EZ-Close-421
Camera	RICOH	CX4	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355, EZ-Close-421
Camera	RICOH	CX5	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355, EZ-Close-421
Camera	RICOH	CX6	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 355, EZ-Close-421
Camera	RICOH	G600	P/E WB-Mini, Zip-L, Hip-L
Camera	RICOH	GR Digital	PDA Milli, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	RICOH	GR Digital II	PDA Milli, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	RICOH	GR Digital III	PDA Milli, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	RICOH	GR II	Zip-L, Hip-L
Camera	RICOH	GR III	D-Micro, Zip-M,
Camera	RICOH	GX200	P/E WB-Mini, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	RICOH	GXR w/24-72 Lens	Zip-L, Hip-L
Camera	RICOH	GXR w/28-300 Lens	Zip-L, Hip-L
Camera	RICOH	GXR w/A12 28mm Lens	Zip-L, Hip-L
Camera	RICOH	GXR w/A12 50mm Lens	Zip-L, Hip-L
Camera	RICOH	PX	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	RICOH	R10	P/E Mini, Zip-S, Hip-S, Snap-M, S-SL 324, EZ-Close-421
Camera	RICOH	RDC-200G	None available at this time.
Camera	RICOH	RDC-4300	Zip-L, Hip-L
Camera	RICOH	RDC-5000	Zip-L, Hip-L
Camera	RICOH	RDC-5300	P/E WB-Med, Zip-L, Hip-L
Camera	RICOH	RDC-6000	P/E WB-Mini, Zip-M, Hip-M
Camera	RICOH	RDC-7	Micro, Zip-L, Hip-L
Camera	RICOH	RDC-i500	Zip-L, Hip-L
Camera	RICOH	RDC-i700	Hip-XL
Camera	RICOH	RDC-i700	PDA Macro
Camera	RICOH	WG-20	S-SL-356, Snap-H-WB-L, Zip-M, Hip-M, EZ-Close-421
Camera	RICOH	WG-30 / WG-30W	S-SL-356, Zip-L, Hip-L, EZ-Close-532
Camera	RICOH	WG-4	S-SL-376, Zip-L, Hip-L, EZ-Close-532
Camera	RICOH	WG-4 GPS	S-SL-376, Zip-L, Hip-L, EZ-Close-532
Camera	RICOH	WG-5 GPS	Zip-L, Hip-L,
Camera	RICOH	WG-50	S-SL-376, Zip-L, Hip-L, EZ-Close-532
Camera	Rollei	Rollie ALL	na
Camera	SAMSUNG	CL65	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	CL80	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	Digimax 530	P/E WB-Mini, Zip-M, Hip-M
Camera	SAMSUNG	Digimax A7/ A6/ A5	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	SAMSUNG	Digimax i6	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	Digimax L50/ L60	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	SAMSUNG	Digimax L85	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	Digimax S500/ S600/ S800	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	Digimax V700/ V600/ V800	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	DV150F	Snap-H-M, Zip-S, Hip-S, P/E-Mini, S-SL-324
Camera	SAMSUNG	DV300F	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324
Camera	SAMSUNG	ES10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	ES15	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	ES20	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	ES25 / ES28	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	ES73	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	EX1	P/E WB-Med, Zip-L, Hip-L
Camera	SAMSUNG	EX2F	Snap-HW-L, Zip-M, D-Compact, S-SL-355, EZ-Close-421
Camera	SAMSUNG	Galaxy 2	S-SL 356, Zip-L, Hip-L
Camera	SAMSUNG	Galaxy 3G/4G	S-SL 335
Camera	SAMSUNG	Galaxy NX	D-Compact, D-Shortie, D-M 4/3
Camera	SAMSUNG	GX-10	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SAMSUNG	GX-15/ GX 1L	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SAMSUNG	GX-20	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SAMSUNG	HZ10W/ HZ15W	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	SAMSUNG	HZ30W/ HZ35W	P/E-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	i7	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	SAMSUNG	i70	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	i8/ i85	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	IT100	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	L100/ L110/ L210	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	SAMSUNG	L201	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	L301	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	L310W	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	L700	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	L73/ L77	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	L730/ L830	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	L83T	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SAMSUNG	MV800	P/E Mini, Zip-S, Hip-S, Snap-S
Camera	SAMSUNG	NV OPS	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	NV10/ NV20/ NV15/ NV8	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	NV100HD	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	NV11	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	NV24HD	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	NV3/ NV30	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	NV4/ NV40	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	NV9	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	NX Mini	D-Micro, EZ-Close-421
Camera	SAMSUNG	NX1	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SAMSUNG	NX10	D-Compact, D-Shortie, D-M 4/3
Camera	SAMSUNG	NX100	D-Compact, D-Shortie, D-M 4/3
Camera	SAMSUNG	NX1000	D-Compact, D-Shortie, D-M 4/3
Camera	SAMSUNG	NX20	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SAMSUNG	NX200 / NX210	D-Compact, D-Shortie, D-M 4/3
Camera	SAMSUNG	NX2000	D-Compact, D-Shortie, D-M 4/3
Camera	SAMSUNG	NX30	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SAMSUNG	NX300	D-Shortie, D-M 4/3
Camera	SAMSUNG	NX3000	D-Shortie, D-M 4/3
Camera	SAMSUNG	NX5	D-Compact, D-Shortie, D-M 4/3
Camera	SAMSUNG	NX500	D-Compact, D-Shortie, D-M 4/3
Camera	SAMSUNG	PL100/ 150	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	PL20	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	PL200	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	PL210	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	PL50/ PL55/ PL65 / PL70	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	PL80/ PL90	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	PRO815	D-Midsize,
Camera	SAMSUNG	S1050	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	S1070	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	S630/ S730	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	S760/S860	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	S830/ S1030	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	S85	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	S850	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	SL102	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	SL201	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	SL202	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321



OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	SAMSUNG	SL30	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	SL310W	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	SL420	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	SL502 / SL720	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	SL620	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	SL630	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	SL820	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SAMSUNG	ST100/ ST600	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	ST1000	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	ST150F	S-SL-324, Snap-H-M, Zip-S, Hip-S, P/E-Mini
Camera	SAMSUNG	ST200F	Not Yet published
Camera	SAMSUNG	ST30	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	SAMSUNG	ST50	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SAMSUNG	ST500/ ST550	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	ST5000/ 5500	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	ST60/ 70	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	ST65	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SAMSUNG	ST6500	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	ST66 / ST76	Not Yet published
Camera	SAMSUNG	ST80	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SAMSUNG	ST90	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SAMSUNG	ST93	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SAMSUNG	ST95	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SAMSUNG	TL100	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SAMSUNG	TL105/ 110	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	TL205/ 210	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	TL220/ TL225	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SAMSUNG	TL240	PE-Mini, Zip-S, Hip-S,, EZ-Close-421
Camera	SAMSUNG	TL320	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	TL34HD	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	TL500	P/E WB-Med, Zip-L, Hip-L
Camera	SAMSUNG	TL9	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	WB1100F	D-Offset
Camera	SAMSUNG	WB150F	Not Yet published
Camera	SAMSUNG	WB2000	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	WB210	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	WB2100F	D-Compact
Camera	SAMSUNG	WB2200F	NA
Camera	SAMSUNG	WB250F	S-SL-355, Snap-HW-L, P/E-WB-Mini, EZ-Close-421
Camera	SAMSUNG	WB30F	Snap-H-M, Zip-S, Hip-S, P/E-Mini
Camera	SAMSUNG	WB350F	S-SL-356, Snap-H-WB-L, Zip-M, Hip-M, PE-WB-Mini
Camera	SAMSUNG	WB35F	S-SL-355, Snap-H-WB-L, Zip-S, Hip-S, PE-WB-Mini, EZ-Close-421
Camera	SAMSUNG	WB500	PDA Milli, Zip-S, Hip-S, Snap-M, S-SL 355
Camera	SAMSUNG	WB5000	D-Compact
Camera	SAMSUNG	WB50F	S-SL-355, Zip-S, Hip-S, PE-WB-Mini
Camera	SAMSUNG	WB600/ 650	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	WB700	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SAMSUNG	WB750	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SAMSUNG	WB800F	Euro-M,
Camera	SAMSUNG	WB850F	Not Yet published
Camera	SAMSUNG	WP10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SANYO	DSC-AZ1	PDA Micro, Zip-M, Hip-M, Snap-HW-L
Camera	SANYO	DSC-J1	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-421
Camera	SANYO	DSC-MZ1	PDA Micro, Zip-M, Hip-M, Snap-HW-L
Camera	SANYO	DSC-S1	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355, EZ-Close-421
Camera	SANYO	VPC-E6U	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SANYO	VPC-S5	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	SANYO	Xacti A5	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	SANYO	Xacti DSC-S3 / S4	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	SANYO	Xacti E6	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SANYO	Xacti E60 / S60	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SIGMA	DP0 Quattro	NA
Camera	SIGMA	DP1	P/E WB-Mini, Zip-M, Hip-M
Camera	SIGMA	DP1 Merrill	P/E WB-Med
Camera	SIGMA	DP1 Quattro	NA
Camera	SIGMA	DP2	P/E WB-Mini, Zip-M, Hip-M
Camera	SIGMA	DP2 Merrill	P/E WB-Med
Camera	SIGMA	DP2 Quattro	NA
Camera	SIGMA	DP2m	P/E WB-Med
Camera	SIGMA	DP2X	P/E WB-Mini, Zip-M, Hip-M
Camera	SIGMA	DP3	P/E WB-Med
Camera	SIGMA	SA7 SLR	SLR Auto
Camera	SIGMA	SA9 SLR	SLR Auto
Camera	SIGMA	sd Quattro H / sd Quattro	D-SLR, D-SLR-Zoom, D-SLR-Tele, Body-Cover-Auto
Camera	SIGMA	SD1	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SIGMA	SD1 Merrill	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SIGMA	SD10	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SIGMA	SD14	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SIGMA	SD15	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SIGMA	SD9	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	Alpha 7	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	Alpha 7 II	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	Alpha 7R	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	Alpha 7R II	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	Alpha 7S	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	Alpha A100 / A200 / A290	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	Alpha A230/ A330/ A380 / A390	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	Alpha A300 / A350	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	Alpha A3000	D-Offset
Camera	SONY	Alpha A450/ A500/ A550/ A580	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	Alpha A5000	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	Alpha A5100	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	Alpha A600/ A6000	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	Alpha a6300	D-Shortie, D-M 4/3
Camera	SONY	Alpha a6500	D-Shortie, D-M 4/3
Camera	SONY	Alpha a68	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	Alpha a7 III	D-Midsize, B-Cover-Mid,
Camera	SONY	Alpha A700	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	Alpha a7R III	D-Midsize, D-Midsize-Zoom, B-Cover-Mid
Camera	SONY	Alpha a7S II	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	Alpha A850	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	Alpha a9	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	Alpha A900	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	Alpha a99 II	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	Alpha NEX-5R	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	Alpha NEX-5T	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	Alpha NEX-6	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	DSC-F707	D-Midsize,
Camera	SONY	DSC-F717	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	DSC-F77	WB Mini, Zip-M, Hip-M
Camera	SONY	DSC-F828	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	DSC-F88	P/E WB-Mini, Zip-M, Hip-M
Camera	SONY	DSC-G1	P/E WB Mini, Zip-M, Hip-M
Camera	SONY	DSC-G3	P/E WB Mini, Zip-M, Hip-M
Camera	SONY	DSC-H1	D-Small
Camera	SONY	DSC-H10	P/E WB-Mini, Zip-M, Hip-M
Camera	SONY	DSC-H20	P/E WB-Mini, Zip-M, Hip-M
Camera	SONY	DSC-H200	D-Shortie

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	SONY	DSC-H3	P/E WB-Mini, Zip-M, Hip-M
Camera	SONY	DSC-H300	D-Offset
Camera	SONY	DSC-H400	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	DSC-H5/ DSC-H2	D-Offset
Camera	SONY	DSC-H50	D-Offset
Camera	SONY	DSC-H55	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SONY	DSC-H7/ H9	D-Offset
Camera	SONY	DSC-H70	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SONY	DSC-HX1	D-Offset
Camera	SONY	DSC-HX100V / DSC-HX200V	D-Offset
Camera	SONY	DSC-HX300	D-Offset
Camera	SONY	DSC-HX350	D-Offset
Camera	SONY	DSC-HX400V	D-Offset
Camera	SONY	DSC-HX5	P/E WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SONY	DSC-HX50V	D_Micro, Zip-M, Hip-M
Camera	SONY	DSC-HX7V	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 355, EZ-Close-421
Camera	SONY	DSC-HX80	D-Micro, Zip-M, Hip-M, Snap-HW-L
Camera	SONY	DSC-HX90V	D-Micro, Snap-HW-L
Camera	SONY	DSC-HX9V	WB Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 355
Camera	SONY	DSC-L1	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	SONY	DSC-M1	P/E WB-Mini, Zip-M, Hip-M, S-SL 355, EZ-Close-421
Camera	SONY	DSC-M2	PDA Milli, Zip-L, Hip-L,, EZ-Close-532
Camera	SONY	DSC-N1/ N2	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSC-P10	P/E Mini, Zip-M, Hip-M, S-SL 355
Camera	SONY	DSC-P100/ DSC-P150	P/E Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 335, EZ-Close-421
Camera	SONY	DSC-P200/R / P200	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSC-P31	P/E WB Mini, Zip-M, Hip-M, Snap-HW-L
Camera	SONY	DSC-P32/ DSC-P41	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-HW-L, S-SL 355
Camera	SONY	DSC-P52	P/E WB-Med
Camera	SONY	DSC-P71	PDA Micro, Zip-L, Hip-L, EZ-Close-532
Camera	SONY	DSC-P72	P/E WB-Mini, Zip-L, Hip-L, Snap-HW-L, EZ-Close-532
Camera	SONY	DSC-P73	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 335, EZ-Close-532
Camera	SONY	DSC-P8/ DSC-P10	P/E Mini, Zip-M, Hip-M, S-SL 355
Camera	SONY	DSC-P92	P/E WB-Mini, Zip-L, Hip-L, Snap-HW-L, EZ-Close-532
Camera	SONY	DSC-P93	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 335, EZ-Close-532
Camera	SONY	DSC-QX10	FOP-251
Camera	SONY	DSC-QX100	FOP-253
Camera	SONY	DSC-QX30	NA
Camera	SONY	DSC-R1	None available at this time.
Camera	SONY	DSC-RX1	D-Shortie
Camera	SONY	DSC-RX10	Midsize,
Camera	SONY	DSC-RX10 II	Midsize,
Camera	SONY	DSC-RX10 III	Midsize,
Camera	SONY	DSC-RX10 IV	Midsize,
Camera	SONY	DSC-RX100	D-Micro, Zip-M
Camera	SONY	DSC-RX100	D-Micro, Zip-M
Camera	SONY	DSC-RX100 II	D-Micro, Zip-M
Camera	SONY	DSC-RX100 III	D-Micro, Zip-M
Camera	SONY	DSC-RX100 IV	D-Micro, Zip-M
Camera	SONY	DSC-RX100 V	D-Micro, Zip-M
Camera	SONY	DSC-RX100 V(A)	D-Micro
Camera	SONY	DSC-RX100 VI	D-Micro, Zip-M
Camera	SONY	DSC-RX1R	D-Shortie
Camera	SONY	DSC-RX1R II	D-Shortie
Camera	SONY	DSC-S2100	P/E Mini, Zip-S, Hip-S, Snap-HW-L, EZ-Close-421
Camera	SONY	DSC-S40	P/E WB-Mini, Zip-S, Hip-S, Snap-M, S-SL 355
Camera	SONY	DSC-S60/ S90	P/E WB-Mini, Zip-M, Hip-M, Snap-HW-L, S-SL 335, EZ-Close-532
Camera	SONY	DSC-S600	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 355
Camera	SONY	DSC-S650/ S700/ S730/ S800	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-S750/ S780	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	SONY	DSC-S930	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-S950	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSC-S980	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSC-T1/ T3/ T7/ T33/ T5	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-T10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-T100/ T20	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-T110	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SONY	DSC-T2	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-T200	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-T30/ T50	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSC-T300	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-T500	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSC-T700/ T77	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SONY	DSC-T9/ T99	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	SONY	DSC-T90/ T900	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SONY	DSC-TF1	S-SL-355, Snap-HW-L, P/E-mini, EZ-Close-421
Camera	SONY	DSC-TX1/ TX5	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SONY	DSC-TX10	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SONY	DSC-TX100V	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SONY	DSC-TX200V	P/E Mini, Zip-S, Hip-S, Snap-H-M, S-SL 324
Camera	SONY	DSC-TX55	Euro Mini, Zip-S, Hip-S, Snap-S
Camera	SONY	DSC-TX7/ TX9	P/E Mini, Zip-S, Hip-S, Snap-H-L, S-SL 324
Camera	SONY	DSC-U30	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	SONY	DSC-U40/ DSC-U50	P/E Mini, Zip-S, Hip-S, Euro-S
Camera	SONY	DSC-U60	P/E WB-Mini, Zip-M, Hip-M
Camera	SONY	DSC-V1	P/E WB-Med, Zip-L, Hip-L
Camera	SONY	DSC-V3	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	DSC-W1/ W5/ W7	P/E Mini, Zip-S, Hip-S
Camera	SONY	DSC-W100	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W120/ W130	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W150/ W170	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W180/ W190	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324
Camera	SONY	DSC-W210/ W220	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSC-W230/ W270/ W290	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSC-W30/ W50	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W300	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W35/ W55	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W380	Euro Mini, Zip-S, Hip-S, Snap-S, EZ-Close-321
Camera	SONY	DSC-W510	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	SONY	DSC-W530	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	SONY	DSC-W560	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	SONY	DSC-W570	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324
Camera	SONY	DSC-W620/ W610	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-421
Camera	SONY	DSC-W650	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W70	P/E Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W710	Snap-H-M, Zip-S, Hip-S, P/E-Mini, EZ-Close-421
Camera	SONY	DSC-W730	Zip-S, Hip-S, P/E-Mini, EZ-Close-321
Camera	SONY	DSC-W80/ W90/ W200	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-W800	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	SONY	DSC-W810	S-SL-355, Snap-H-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	SONY	DSC-W830	S-SL-355, Snap-HW-Med, Zip-S, Hip-S, PE-Mini, EZ-Close-321

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Camera	SONY	DSC-WX1/ WX5	Euro Mini, Zip-S, Hip-S, Snap-S, S-SL 324, EZ-Close-321
Camera	SONY	DSC-WX10	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M
Camera	SONY	DSC-WX220	S-SL-324, Zip-S, Hip-S, Euro-Small, EZ-Close-321
Camera	SONY	DSC-WX30	P/E Mini, Zip-S, Hip-S, Snap-M, Snap-H-M, S-SL 324, EZ-Close-321
Camera	SONY	DSC-WX350	S-SL-355, Snap-WB-M, Zip-S, Hip-S, PE-Mini, EZ-Close-421
Camera	SONY	DSC-WX50	Euro Small, S-SL 324, EZ-Close-321
Camera	SONY	DSC-WX500	D-Micro, Snap-HW-L
Camera	SONY	DSC-WX70	Euro Small, S-SL 324, EZ-Close-321
Camera	SONY	DSC-WX80	S-SL-324, Zip-S, Hip-S, Euro-Small, EZ-Close-321
Camera	SONY	DSC-WX9	P/E Mini, Zip-S, Hip-S, Snap-HW-L, S-SL 324, EZ-Close-421
Camera	SONY	DSLR-A200	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	NEX-3 / NEX-5	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	NEX-7	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	NEX-C3	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	NEX-F3	D-Compact, D-Shortie, D-M 4/3
Camera	SONY	SLT A37	D-Offset
Camera	SONY	SLT A55 / A35 / A33	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	SLT A57	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	SLT A65	D-Midsize, D-Midsize-Zoom, D-Mid-Pro, B-Cover-Mid, B-Cover-Mid-Pro
Camera	SONY	SLT A77	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	SLT A77 MARK II	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	SLT-A68	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	SONY	SLT-A99	D-SLR, D-SLR-Zoom, D-SLR-Tele, B-Cover-Auto
Camera	TOSHIBA	PDR-3310	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	TOSHIBA	PDR-3330	Zip-M, Hip-M
Camera	TOSHIBA	PDR-4300	P/E WB-Med, Zip-L, Hip-L
Camera	TOSHIBA	PDR-5300	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	TOSHIBA	PDR-M1	Zip-L, Hip-L
Camera	TOSHIBA	PDR-M11	Zip-M, Hip-M
Camera	TOSHIBA	PDR-M21	Zip-M, Hip-M
Camera	TOSHIBA	PDR-M25	P/E WB-S, Zip-M, Hip-M
Camera	TOSHIBA	PDR-M3	P/E WB-Med, Zip-L, Hip-L
Camera	TOSHIBA	PDR-M4	P/E WB-Mini, Zip-M, Hip-M
Camera	TOSHIBA	PDR-M5	D-Compact
Camera	TOSHIBA	PDR-M60	P/E WB-Med, Zip-L, Hip-L
Camera	TOSHIBA	PDR-M61	P/E WB-Med, Zip-L, Hip-L
Camera	TOSHIBA	PDR-M65	P/E WB-Med, Zip-L, Hip-L
Camera	TOSHIBA	PDR-M70	P/E WB-Med, Zip-L, Hip-L
Camera	TOSHIBA	PDR-M71	P/E WB-Mini, Zip-M, Hip-M
Camera	TOSHIBA	PDR-M81	P/E WB-Mini, Zip-M, Hip-M
Camera	TOSHIBA	PDR-T10	P/E Mini, Zip-S, Hip-S, Snap-M
Camera	Vivitar	F126	No Dimensions Listed
Camera	Vivitar	ViviCam iTwist S124	No Dimensions Listed
Camera	Vivitar	ViviCam T016	No Dimensions Listed
Camera	ZEISS	ZX1	Zip-L,
Camera Kit	CANON	EOS R Mirrorless Digital Camera with 24-105mm Lens	D-Midsize, Snoot-WB-M, H-Hat-S, L-Filter-S, Filter-Pack
Camera Kit	FUJIFILM	X-T3 with 18-55 Lens	D-Midsize, FOP-303, Snoot-Mini, L-Filter-S, Filter-Pack
Camera Kit	NIKON	D3500 DSLR Camera with 18-55mm and 70-300mm Lenses	D-Midsize, D-Midsize-Zoom, Snoot-WB-M, H-Hat-S, L-Filter-M
Camera Kit	NIKON	D3500 DSLR Camera with 18-55mm Lens	D-Midsize, FOP-253, Snoot-Mini, H-Hat-Mini, L-Filter-S
Camera Kit	NIKON	Z6 with 24-70mm Lens	D-Midsize, FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Filter-Pack
Camera Kit	NIKON	Z7 with 24-70mm Lens	D-Midsize, FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Filter-Pack
Cinema Lens	BOWER	14mm T3.1	FOP-354, Snoot-WB-S, H-Hat-S
Cinema Lens	BOWER	16mm T2.2	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77
Cinema Lens	BOWER	24mm T1.5	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Cinema Lens	BOWER	35mm T1.5	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77
Cinema Lens	BOWER	85mm T1.5	FOP-303, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-72
Cinema Lens	BOWER	8mm T/3.8 Fisheye	FOP-303, Snoot-WB-S, H-Hat-S
Cinema Lens	Canon	CN-E 135mm T2.2 L F	H-Hat-XL,
Cinema Lens	Canon	CN-E 14.5-60mm T2.6 L S	H-Hat-3XL,
Cinema Lens	Canon	CN-E 14mm T3.1 L F	H-Hat-XL,
Cinema Lens	Canon	CN-E 24mm T1.5 L F	H-Hat-XL,
Cinema Lens	Canon	CN-E 30-300mm T2.95-3.7 L S	H-Hat-4XL,
Cinema Lens	Canon	CN-E 35mm T1.5 L F	H-Hat-XL,
Cinema Lens	Canon	CN-E 50mm T1.3 L F	H-Hat-XL,
Cinema Lens	Canon	CN-E 85mm T1.3 L F	H-Hat-XL,
Cinema Lens	Canon	CN-E15.5-47mm T2.8 L S	H-Hat-XXL,
Cinema Lens	Canon	CN-E30-105mm T2.8 L SP	H-Hat-XXL,
Cinema Lens	Cooke	100mm T1.4 5/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	100mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	100mm T2.8 miniS4/i	Snoot-WB-L, H-Hat-M
Cinema Lens	Cooke	12mm T2 S4/i	H-Hat-3XL
Cinema Lens	Cooke	135mm T1.4 5/i	H-Hat-XXL
Cinema Lens	Cooke	135mm T2 S4/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	135mm T2.8 miniS4/i	Snoot-L, H-Hat-S,
Cinema Lens	Cooke	14mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	16mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	18mm T1.4 5/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	18mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	18mm T2.8 miniS4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	65mm T2 S4/i SF	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	21mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	21mm T2.8 miniS4/i	Snoot-M, H-Hat-S,
Cinema Lens	Cooke	25mm T1.4 5/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	150mm T2 S4/i	H-Hat-XXL
Cinema Lens	Cooke	180mm T2 S4/i	H-Hat-XXL
Cinema Lens	Cooke	300mm T2 S4/i	H-Hat-XXL
Cinema Lens	Cooke	15-40mm T2 S4/i	H-Hat-XXL
Cinema Lens	Cooke	25mm T2 S4/i	Snoot-WB-L, H-Hat-L

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Cinema Lens	Cooke	25mm T2.8 miniS4/i	Snoot-M, H-Hat-S,
Cinema Lens	Cooke	27mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	32mm T1.4 5/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	32mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	32mm T2.8 miniS4/i	Snoot-M, H-Hat-S,
Cinema Lens	Cooke	35mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	40mm T1.4 5/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	40mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	40mm T2.8 miniS4/i	Snoot-M, H-Hat-S,
Cinema Lens	Cooke	50mm T1.4 5/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	50mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	50mm T2.8 miniS4/i	Snoot-M, H-Hat-S,
Cinema Lens	Cooke	65mm T1.4 5/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	65mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	65mm T2.8 miniS4/i	Snoot-M, H-Hat-S,
Cinema Lens	Cooke	75mm T1.4 5/i	Snoot-WB-XL, H-Hat-L
Cinema Lens	Cooke	75mm T2 S4/i	Snoot-WB-L, H-Hat-L
Cinema Lens	Cooke	75mm T2.8 miniS4/i	Snoot-M, H-Hat-S,
Cinema Lens	Fujinon	14.5-45mm T2.0 Premier PL Zoom	H-Hat-XXL
Cinema Lens	Fujinon	14-35mm T2.9 Cabrio Premier PL	H-Hat-XL
Cinema Lens	Fujinon	18-85mm T2.0 Premier PL Zoom	H-Hat-XXL
Cinema Lens	Fujinon	19-90mm T2.9 Cabrio Premier PL	H-Hat-XL
Cinema Lens	Fujinon	24-180mm T2.6 Premier PL Zoom	H-Hat-XXL
Cinema Lens	Fujinon	25-300mm T3.5 to 3.85 Cabrio Premier PL	H-Hat-XXL
Cinema Lens	Fujinon	75-400mm T2.8-3.8 Premier PL	H-Hat-XXL
Cinema Lens	Fujinon	85-300mm T2.9-4.0 ZK Lightweight Zoom	H-Hat-XL
Cinema Lens	GL Optics	100mm T3 Macro	H-Hat-M, Snoot-WB-L
Cinema Lens	GL Optics	11-16mm T3.0 MKII	H-Hat-M, Snoot-WB-M
Cinema Lens	GL Optics	11-20mm T3.0	H-Hat-M, Snoot-WB-M
Cinema Lens	GL Optics	135mm f/2	H-Hat-M, Snoot-WB-M
Cinema Lens	GL Optics	16-28mm f/2.8	H-Hat-M, Snoot-WB-L
Cinema Lens	GL Optics	18-35mm T2 Super Speed Zoom	H-Hat-M, Snoot-WB-L
Cinema Lens	GL Optics	300mm f/2.8	H-Hat-M, Snoot-WB-XL
Cinema Lens	GL Optics	70-200mm f/2.8	H-Hat-M, Snoot-WB-XL

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Cinema Lens	GL Optics	Canon 200mm F2.8	H-Hat-M, Snoot-WB-L
Cinema Lens	GL Optics	Canon 200mm F4 Macro	H-Hat-M, Snoot-WB-XXL
Cinema Lens	GL Optics	Sigma 35/50mm F1.4	H-Hat-M, Snoot-WB-S
Cinema Lens	Rokinon	10mm T3.1 Cine	H-Hat-S, Snoot-WB-M
Cinema Lens	Rokinon	24mm T1.5 Cine DS	H-Hat-S, Snoot-WB-M
Cinema Lens	Rokinon	35mm T1.5 Cine AS UMC	H-Hat-S, Snoot-WB-M
Cinema Lens	Rokinon	50mm T1.5 AS UMC Cine DS	H-Hat-S, Snoot-WB-M
Cinema Lens	Rokinon	85mm T1.5 Cine	H-Hat-S, Snoot-WB-M
Cinema Lens	Rokinon	8mm T/3.8 Fisheye Cine	H-Hat-S, Snoot-WB-M
Cinema Lens	Rokinon	135mm T2.2 Cine	H-Hat-S, Snoot-WB-M
Cinema Lens	Rokinon	100mm T3.1 Macro Cine	H-Hat-S, Snoot-WB-M
Laptop	Apple	MacBook Air 11"	S-SL 802
Laptop	Apple	MacBook Air 13"	Computer-S 13
Laptop	Apple	MacBook Pro 13"	Computer-S 13
Laptop	Apple	MacBook Pro 15"	Computer-S 15
Laptop	Apple	MacBook Pro 17"	Computer-S 17
Laptop	Dell	Inspiron 15z Ultrabook	Computer-S 15
Laptop	Dell	XPS 12 Converible Ultrabook	Computer-S 13
Laptop	HP	2000z Series	Computer-S 15
Laptop	HP	ENVY 14 Beats Edition Series	
Laptop	HP	ENVY 14 Series	
Laptop	HP	ENVY 15 Series	Computer-S 15
Laptop	HP	ENVY 17 3D Series	Computer-S 17
Laptop	HP	ENVY 17 Series	Computer-S 17
Laptop	HP	ENVY Touchsmart Ultrabook 4t-1100	
Laptop	HP	ENVY Touchsmart Ultrabook dv4-5220us	
Laptop	HP	Folio 13 Series	Computer-S 13
Laptop	HP	Pavilion dm1z Series	
Laptop	HP	Pavilion dm4t Beats Edition Series	
Laptop	HP	Pavilion dm4t Entertainment PC Series	
Laptop	HP	Pavilion dv4t Series	
Laptop	HP	Pavilion dv6t Quad Edition Series	Computer-S 15
Laptop	HP	Pavilion dv6t Select Edition Series	Computer-S 15
Laptop	HP	Pavilion dv6t Series	Computer-S 15
Laptop	HP	Pavilion dv6z Quad Edition series	Computer-S 15
Laptop	HP	Pavilion dv7t Quad Edition Series	Computer-S 17
Laptop	HP	Pavilion dv7t Series	Computer-S 17
Laptop	HP	Pavilion g4t Series	
Laptop	HP	Pavilion g6t Series	Computer-S 15
Laptop	HP	Pavilion g6x Series	Computer-S 15
Laptop	HP	Pavilion g7t Series	Computer-S 17
Laptop	Lenovo	ThinkPad T420	
Laptop	Lenovo	ThinkPad T420s	
Laptop	Lenovo	ThinkPad T520	Computer-S 15
Laptop	Lenovo	ThinkPad X1	
Laptop	Lenovo	ThinkPad X120e	Computer-S 11.5
Laptop	Lenovo	ThinkPad X130e AMD	Computer-S 13
Laptop	Lenovo	ThinkPad X130e Intel	Computer-S 13
Laptop	Lenovo	ThinkPad X220	
Lens	BOWER	14mm F2.5 Ultra Fisheye	
Lens	BOWER	14mm F2.8 Ultra Wide Angle	
Lens	BOWER	35mm T/1.5 FOR VIDEO SLR	
Lens	BOWER	500mm F6.3 Mirror	Snoot-WB-M
Lens	BOWER	500mm F8.0 Mirror	Snoot-WB-S
Lens	BOWER	500mm F8.0 Preset Telephoto	
Lens	BOWER	650-1300 F8.0 Long Range Zoom	
Lens	BOWER	800mm F8.0 Mirror	Snoot-WB-M
Lens	BOWER	85mm F1.4	Snoot-WB-S



OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	BOWER	8mm F3.5 Ultra Fisheye	FOP-303, Snoot-S
Lens	BOWER	8mm T/3.8 FOR VIDEO SLR	
Lens	CANON	EF 100-300mm f/4.5-5.6	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_58mm,Fast_Cap_58mm
Lens	CANON	EF 100-400mm f/4.5-5.6 IS	Snoot-WB-XL, H-Hat-M
Lens	CANON	EF 100-400mm f/4.5-5.6 IS II USM	Snoot-WB-XL, H-Hat-M
Lens	CANON	EF 100mm f/2	FOP-303, H-Hat-Mini, F-Cap-58,
Lens	CANON	EF 100mm f/2.8 PDA Macro	FOP_354,Snoot-WB-M,H_Hat_M,L_Filter_M,Cap-58
Lens	CANON	EF 100mm f/2.8L PDA Macro IS USM	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-67
Lens	CANON	EF 11-24mm f/4L	Snoot-WB-M, H-Hat-L, L-Filter-M
Lens	CANON	EF 1200mm f/5.6	na
Lens	CANON	EF 135mm f/2	FOP_354,Snoot-WB-M,H_Hat_S,L_Filter_M,Cap-72
Lens	CANON	EF 135mm f/2.8	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-52
Lens	CANON	EF 14mm f/2.8	FOP-303, Snoot-WB-S, H-Hat-Mini
Lens	CANON	EF 15mm f/2.8 Fisheye	Snoot-Mini, FOP-303
Lens	CANON	EF 16-35mm f/2.8	FOP_354, Snoot-WB-M, H_Hat_S, L_Filter_M, Filter_Cap-77
Lens	CANON	EF 16-35mm f/2.8 III USM	FOP-356, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	CANON	EF 16-35mm f/4L IS USM	FOP_354, Snoot-WB-M, H_Hat_S, L_Filter_M, Filter_Cap-77
Lens	CANON	EF 17-35mm f/2.8L USM	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77
Lens	CANON	EF 17-40mm f/4	FOP_354,Snoot-WB-S,H_Hat_S,L_Filter_S,Filter_Cap-77
Lens	CANON	EF 180mm f/3.5 PDA Macro	H Hat-M, Snoot-M
Lens	CANON	EF 18-55mm f/3.5-5.6	H Hat-Mini, Snoot-Mini, FOP-303
Lens	CANON	EF 200-400mm f/4L IS USM Extender 1.4x	MSC-3, H-Hat-XXL, LMC-C
Lens	CANON	EF 200mm f/2.8	FOP-356, H Hat-M, Snoot - WB-M
Lens	CANON	EF 200mm f/2L IS USM	FOP-356, H Hat-XXL
Lens	CANON	EF 20-35mm f/3,5-4.5	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S, Cap-77
Lens	CANON	EF 20mm f/2.8	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S, Cap-72
Lens	CANON	EF 24-105mm f/4L IS II USM	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	CANON	EF 24-105mm f/4L IS USM	FOP-354,Snoot-WB-M, H Hat-L, L-Filter-M, LMC-Canon
Lens	CANON	EF 24-70mm f/2.8	FOP_354,Snoot-WB-M,H_Hat_M,L_Filter_M,Cap-77
Lens	CANON	EF 24-70mm f/2.8 II USM	FOP_354,Snoot-WB-M,H_Hat_M,L_Filter_M
Lens	CANON	EF 24-70mm f/4L IS USM	FOP_354,Snoot-WB-S,H_Hat_S,L_Filter_S,Filter_Cap-77
Lens	CANON	EF 24-85mm f/3.5-4.5	H Hat-S, Snoot-Mini, FOP-303
Lens	CANON	EF 24mm f/1.4	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S, Cap-77
Lens	CANON	EF 24mm f/2.8	FOP-301, Snoot-Mini, H Hat-Mini, Filter-Cap-58, Fast-Cap-58,
Lens	CANON	EF 24mm f/2.8 IS USM	Snoot-Mini, Cap-58, FOP-303
Lens	CANON	EF 28-105mm f/3.5-4.5	H Hat-Mini, Snoot-Mini, FOP-303
Lens	CANON	EF 28-105mm f/4.5-5.6	H Hat-S, FOP-303
Lens	CANON	EF 28-135mm f/3.5-5.6 IS	FOP_354,Snoot-WB-S,H_Hat_S,L_Filter_S,Filter_Cap-72
Lens	CANON	EF 28-200mm f/3.5-5.6	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S, Cap-72
Lens	CANON	EF 28-300mm f/3.5-5.6	H Hat-M, Snoot-L
Lens	CANON	EF 28-80mm f/3.5-5.6	H Hat-Mini, FOP-303
Lens	CANON	EF 28-90mm f/4-5.6	H Hat-Mini, FOP-303
Lens	CANON	EF 28mm f/1.8	H Hat-Mini, FOP-303
Lens	CANON	EF 28mm f/2.8	Snoot-Mini, FOP-301, Fast_Cap-52, Filter-Cap-52, H-Hat-Mini
Lens	CANON	EF 28mm f/2.8 II USM	FOP-301, Snoot-Mini, H Hat-Mini, Filter-Cap-58, Fast-Cap-58,
Lens	CANON	EF 300mm f/2.8 IS	H Hat-XXL, Snoot-WB-XXL, MSC-3
Lens	CANON	EF 300mm f/4 IS	H Hat-M, LS-6, Snoot-WB-XL
Lens	CANON	EF 300mm f/4L IS USM	H Hat-S, Snoot-L
Lens	CANON	EF 35-80mm f/4-5.6	FOP-303, Snoot-Mini, H Hat-Mini, Cap-52,
Lens	CANON	EF 35mm f/1.4	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S, Cap-72
Lens	CANON	EF 35mm f/2	Snoot-Mini, FOP-301, Fast_Cap-52, Filter-Cap-52, H-Hat-Mini
Lens	CANON	EF 35mm f/2 IS USM	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S, Cap-67
Lens	CANON	EF 35mm F1.4 II USM	FOP-345, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	CANON	EF 400mm f/2.8L IS II USM	MSC-1
Lens	CANON	EF 400mm f/2.8L IS III USM	H-Hat-4XL,
Lens	CANON	EF 400mm f/2.8L IS USM	MSC-1
Lens	CANON	EF 400mm f/2.8L IS USM	H-Hat-XXXL, MSC-2, LMC-C
Lens	CANON	EF 400mm f/4 IS	H-Hat-XL, LS-6, Snoot-WB-XL, MSC-3
Lens	CANON	EF 400mm f/4 DO IS II USM	Snoot-WB-XXL, H-Hat-XXL, MSC-3
Lens	CANON	EF 400mm f/5.6	H Hat-S, Snoot-WB-XXL, MSC-3
Lens	CANON	EF 40mm f/2.8	Snoot-Mini, FOP-301, Fast_Cap-52, Filter-Cap-52, H-Hat-Mini
Lens	CANON	EF 500mm f/4 IS	H Hat-XXXL, MSC-2
Lens	CANON	EF 50mm f/2.5 Compact PDA Macro	FOP-303, Snoot-Mini, H Hat-Mini, Cap-52,

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	CANON	EF 50mm f/1.2L USM	FOP-354, Snoot-WB-S, H Hat-M, L-Filter-S, Cap-72
Lens	CANON	EF 50mm f/1.4	FOP-301, Snoot-Mini, H Hat-Mini, Filter-Cap-58, Fast-Cap-58,
Lens	CANON	EF 50mm f/1.8	Snoot-Mini, FOP-301, Fast_Cap-52, Filter-Cap-52, H-Hat-Mini
Lens	CANON	EF 50mm f/1.8 STM	FOP-301, Snoot-Mini, H-Hat-Mini, Cap-49
Lens	CANON	EF 55-200mm f/4.5-5.6	H-Hat-S, LS-6, Snoot-WB-XL
Lens	CANON	EF 600mm f/4 IS	H-Hat-XXXXL, MSC-1, LMC-C
Lens	CANON	EF 600mm f/4.0L IS II USM	MSC-1
Lens	CANON	EF 600mm f/4.0L IS USM	MSC-1
Lens	CANON	EF 600mm f/4L IS III USM	H-Hat-4XL,
Lens	CANON	EF 70-200mm f/2.8L IS II USM	Snoot-L, L/Filter-L, H Hat-M,
Lens	CANON	EF 70-200mm f/2.8L IS USM	Snoot-L, L/Filter-L, H Hat-M,
Lens	CANON	EF 70-200mm f/2.8L USM	Snoot-L, L/Filter-L, H Hat-M,
Lens	CANON	EF 70-200mm f/4 IS USM	Snoot-M, H-Hat-S, L-Filter-L, Cap-67, LMC-Canon
Lens	CANON	EF 70-200mm f/2.8L IS III USM	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	CANON	EF 70-200mm f/4L IS II USM	Snoot-WB-XL, H-Hat-S, L-Filter-L
Lens	CANON	EF 70-300mm f/4.5-5.6	FOP_354,Snoot-S,H Hat_S,L_Filter_S,Filter_Cap-58
Lens	CANON	EF 70-300mm f/4-5.6 IS II USM	FOP-356, Snoot-M, H-Hat-S
Lens	CANON	EF 75-300mm f/4-5.6	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_58mm,Fast_Cap_58mm
Lens	CANON	EF 75-300mm f/4-5.6 IS	H Hat-M,
Lens	CANON	EF 75-300mm f/4-5.6 III	FOP-304, Snoot-WB-M, H-Hat-Mini, L-Filter-M, Cap-58, LMC-Canon
Lens	CANON	EF 75-300mm f/4-5.6 III USM	FOP-304, Snoot-WB-M, H-Hat-Mini, L-Filter-M, Cap-58, LMC-Canon
Lens	CANON	EF 800mm f/5.6L IS USM	H-Hat-3XL, MSC-1
Lens	CANON	EF 80-200mm f/4.5-5.6	H Hat-S, FOP-303
Lens	CANON	EF 8-15mm f/4 Fisheye USM	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S,
Lens	CANON	EF 85mm f/1.2	FOP-354, Snoot-WB-S, H Hat-M, L-Filter-S, Cap-72
Lens	CANON	EF 85mm f/1.8	FOP-303, H-Hat-Mini, F-Cap-58,
Lens	CANON	EF 85mm f/1.4L IS USM Lens	Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	CANON	EF-M 11-22mm f/4-5.6 IS STM	FOP-253, H-Hat-Pk-Micro
Lens	CANON	EF-M 15-45mm f/3.5-6.3 IS STM	FOP-251, H Hat-PK-Micro,
Lens	CANON	EF-M 18-150mm f/3.5-6.3 IS STM	FOP-303, Snoot-S, H-Hat-Mini
Lens	CANON	EF-M 18-55mm f3.5-5.6 IS SMT	FOP-253, H-Hat-Pk-Micro
Lens	CANON	EF-M 22mm f2 STM	FOP-251, H Hat-PK-Micro,
Lens	CANON	EF-M 28mm f/3.5 Macro IS STM	FOP-251, H Hat-PK-Micro,
Lens	CANON	EF-M 32mm f/1.4 STM	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	CANON	EF-M 55-200mm f/4.5-6.3 IS STM	Snoot-S, L/Filter-M, H Hat-Mini, FOP-253,
Lens	CANON	EF-S 10-18mm f/4.5-5.6 IS STM	FOP-303, Snoot-WB-S, H-Hat-S, LF-S, Cap-72
Lens	CANON	EF-S 10-22mm f/3/5-4.5	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S, Cap-77
Lens	CANON	EF-S 15-85mm f/3.5-5.6 IS USM	FOP-354, H-Hat-S, Snoot-WB-S, L-Filter-S, Cap-72
Lens	CANON	EF-S 17-55mm f/2.8 IS USM	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M
Lens	CANON	EF-S 17-85mm f/4-5.6	FOP_354,Snoot WB_S,H Hat_S,L_Filter_S,Filter-Cap-67
Lens	CANON	EF-S 18-135mm f/3.5-5.6 IS	FOP-304, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-67, LMC-Canon
Lens	CANON	EF-S 18-135mm f/3.5-5.6 IS STM	FOP-304, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-67, LMC-Canon
Lens	CANON	EF-S 18-135mm f/3.5-5.6 IS USM	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-67
Lens	CANON	EF-S 18-200mm f/3.5-5.6 IS	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-72
Lens	CANON	EF-S 18-55mm f/4-5.6 IS STM	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	CANON	EF-S 35mm f/2.8 Macro IS STM	FOP-303, Snoot-Mini, H-hat-mini, L-Filter-S
Lens	CANON	EF-S 55-250mm f/4-5.6 IS	FOP-304, Snoot-WB-M, H-Hat-Mini, L-Filter-M, Cap-58, LMC-Canon
Lens	CANON	EF-S 55-250mm f/4-5.6 IS STM	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_58mm,Fast_Cap_58mm
Lens	CANON	EF-S 60mm f/2.8 PDA Macro USM	FOP-354, H-Hat-S, Snoot-WB-S, L-Filter-S, Cap-52
Lens	CANON	EF-S 65mm f/2.8 PDA Macro	H Hat-M, Snoot-S, FOP-303
Lens	CANON	Extender EF 1.4x II	FOP-301
Lens	CANON	Extender EF 1.4x III	FOP-301
Lens	CANON	Extender EF 2x II	FOP-303
Lens	CANON	Extender EF 2x III	FOP-303
Lens Hood	Canon	ET-78B	H-Hat-S
Lens	CANON	RF 24-105mm f/4L IS USM	Snoot-WB-M, H-Hat-S, L-Filter-S
Lens	CANON	RF 28-70mm f/2L USM	Snoot-WB-L, H-Hat-L, L-Filter-M
Lens	CANON	RF 35mm f/1.8 IS Macro STM	Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	CANON	RF 50mm f/1.2L USM	Snoot-WB-M, H-Hat-M, L-Filter-M

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	CANON	TS-E 135mm f/4L Macro Tilt-Shift Lens	Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	CANON	TS-E 17mm f/4L	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M
Lens	CANON	TS-E 24mm f/3.5	FOP-354, H-Hat-S, Snoot-WB-S, L-Filter-S, Cap-72
Lens	CANON	TS-E 45mm f/2.8	FOP-354, H-Hat-S, Snoot-WB-S, L-Filter-S, Cap-72
Lens	CANON	TS-E 50mm f/2.8L Macro Tilt-Shift Lens	Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	CANON	TS-E 90mm f/2.8	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-58
Lens	CANON	TS-E 90mm f/2.8L Macro Tilt-Shift Lens	Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	FUJIFILM	Fujinon MKX 18-55mm T2.9	H-Hat-M, Snoot-WB-XL, L-Filter-L,
Lens	FUJIFILM	Fujinon MKX 50-135mm T2.9	H-Hat-M, Snoot-WB-XL, L-Filter-L,
Lens	FUJIFILM	GF 110mm f/2 R LM WR	Snoot-WB-Medium, H-Hat-M, L-Filter-M
Lens	FUJIFILM	GF 23mm f/4 R LM WR	Snoot-WB-Medium, H-Hat-M, L-Filter-M
Lens	FUJIFILM	GF 32-64mm f/4 R LM WR	Snoot-WB-Medium, H-Hat-M, L-Filter-M
Lens	FUJIFILM	GF 45mm F2.8 R WR	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	FUJINON	MK 18-55mm T2.9	Snoot-WB-XL, L-Filter-L,
Lens	FUJINON	MK 50-135mm T2.9	Snoot-WB-XL, L-Filter-L,
Lens	FUJIFILM	XC 15-45mm F3.5-5.6 OIS PZ	FOP-301, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	FUJIFILM	XC 16-50mm f/3.5-5.6 OIS	Snoot-Mini, L-Filter-S, H-Hat-Mini, Fast-Cap-49, Filter-Cap-49, FOP-253
Lens	FUJIFILM	XC 50-230mm f4.5-6.7 OIS	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_58mm,Fast_Cap_58mm
Lens	FUJIFILM	XC 50-230mm f4.5-6.7 OIS II	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_58mm,Fast_Cap_58mm
Lens	FUJIFILM	XC-16-50mm F3.5-5.6 OIS II	Snoot-Mini, L-Filter-S, H-Hat-Mini, Fast-Cap-49, Filter-Cap-49, FOP-253
Lens	FUJIFILM	XF 100-400mm f/4.5-5.6 R LM OIS WR	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	FUJIFILM	XF 10-24mm F4 R OIS	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Fast_Cap_72mm
Lens	FUJIFILM	XF 16-55mm F2.8 R LM WR	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M
Lens	FUJIFILM	XF 18-135mm F3.5-5.6 R LM OIS WR	FOP-304, Snoot-S, L-Filter-M, H-Hat-S, Fast-Cap-72
Lens	FUJIFILM	XF 18mm f2 R	FOP-301, H-Hat-Pk-Micro
Lens	FUJIFILM	XF 200mm F2 R LM OIS WR	Snoot-WB-XXL, H-Hat-XL
Lens	FUJIFILM	XF 23mm f1.4 R	FOP_303,Snoot_Mini,H_Hat_Mini,L_Filter_S,Filter_Cap_62mm, Fast_Cap_62mm,Filter_Pack
Lens	FUJIFILM	XF 23mm f2 R WR	FOP-253, Snoot-Mini, H-Hat-Mini,
Lens	FUJIFILM	XF 27mm f2.8	FOP-251, H Hat-PK-Micro,
Lens	FUJIFILM	XF 35mm F1.4 R	FOP-303, H-Hat-Pk-Micro
Lens	FUJIFILM	XF 50-140mm f/2.8 R LM OIS WR	Snoot-L, H-Hat-M, L-Filter-L,
Lens	FUJIFILM	XF 50mm f/2 R WR	FOP-253, H-hat-Mini
Lens	FUJIFILM	XF 55-200mm F3.5-4.8R LM OIS	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_62mm,Fast_Cap_62mm
Lens	FUJIFILM	XF 56mm f/1.2 R APD	FOP-303, Snoot-Mini, H-Hat-S, L-Filter-S,
Lens	FUJIFILM	XF 56mm F1.2 R	FOP-303, Snoot-Mini, H Hat-Mini, L-Filter-S, Cap-62
Lens	FUJIFILM	XF 60mm F2.4 Macro	FOP-253, H-Hat-Pk-Micro
Lens	FUJIFILM	XF 80mm F2.8 R LM OIS WR Macro	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-S
Lens	FUJIFILM	XF 8-16mm F2.8 R LM WR	FOP-356, Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	FUJIFILM	XF 90mm f/2 R LM WR	FOP_354,Snoot-WB-M,H_Hat_S,L_Filter_M,Filter_Cap-62
Lens	HASSELBLAD	100mm f/2.2 HC AF	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77
Lens	HASSELBLAD	120mm f/4 II HC Macro	Snoot-WB-L, H-Hat-M, L-Filter-L, Cap-67
Lens	HASSELBLAD	150mm f/3.2 HC AF	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M, Cap-77
Lens	HASSELBLAD	210mm f/4 HC AP	FOP-356, Snoot-M, H-Hat-S, L-Filter-L, Cap-77
Lens	HASSELBLAD	24mm f/2.8 HCD	Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	HASSELBLAD	28mm f/4.0 HCD	Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	HASSELBLAD	300mm f/4.5 HC AF	H-Hat-M, L-Filter-L
Lens	HASSELBLAD	35-90mm f/4-5.6 HCD Aspherical Zoom	Snoot-WB-L, H-Hat-M, L-Filter-L
Lens	HASSELBLAD	35mm f/3.5 HC AF	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	HASSELBLAD	50-110mm f/3.5-4.5 HC AF	H-Hat-M, L-Filter-M
Lens	HASSELBLAD	50mm f/3.5 HC II AF	Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-77
Lens	HASSELBLAD	80mm f/2.8 HC AF	Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-67
Lens	IRIX	11mm f/4	Snoot-WB-M, H-Hat-XL,
Lens	IRIX	15mm f/2.4	Snoot-WB-M, H-Hat-XL,
Lens	Kenko	Extension Tube Set	FOP-303
Lens	Kenko	TELEPLUS HD DGX 1.4x	FOP-301
Lens	Kenko	Teleplus MC4 AF 1.4 DGX	FOP-301
Lens	Kenko	Teleplus MC4 AF 2.0 DGX	FOP-301
Lens	Kenko	Teleplus MC7 AF 2.0 DGX	FOP-301
Lens	Kenko	Teleplus Pro 300 AF DG 3.0x	FOP-303
Lens	Kenko	Teleplus Pro 300 AF DGX 1.4x	FOP-301
Lens	Kenko	Teleplus Pro 300 AF DGX 2.0x	FOP-303
Lens	Kenko	Uniplus Tube DG 25	FOP-301
Lens	LEICA	120mm f/5.6 TS-APO-Elmar-S ASPH	Snoot-WB-L, H-Hat-L, L-Filter-L

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	LEICA	24mm f/3.5 Super-Elmar-S ASPH	Snoot-WB-M, H-Hat-L, L-Filter-M
Lens	LEICA	30-90mm f/3.5-5.6 Vario-Elmar-S ASPH	Snoot-WB-M, H-Hat-L, L-Filter-M
Lens	LEICA	APO ELMAR-S 1:3,5/180 mm	Snoot-M
Lens	LEICA	APO ELMAR-S 1:3,5/180 mm (CS)	Snoot-M
Lens	LEICA	APO PDA Macro SUMMARIT-S 1:2,5/120 mm	Snoot-WB-M
Lens	LEICA	APO PDA Macro SUMMARIT-S 1:2,5/120 mm (CS)	Snoot-WB-M
Lens	LEICA	APO-Macro-Summarit-S 120mm f/2.5	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	LEICA	APO-Macro-Summarit-S 120mm f/2.5 CS	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	LEICA	APO-Summicron-SL 75mm F2 ASPH	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	LEICA	APO-Summicron-SL 90mm F2 ASPH	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	LEICA	APO-Tele-Elmar-S 180mm f/3.5	FOP-356, Snoot-M, H-Hat-M, L-Filter-L
Lens	LEICA	APO-Tele-Elmar-S 180mm f/3.5 CS	FOP-356, Snoot-M, H-Hat-M, L-Filter-L
Lens	LEICA	APO-Vario-Elmarit-SL 90-280 mm F2.8-4	na
Lens	LEICA	APO-Vario-Elmar-T 55-135mm f/3.5-4.5 ASPH	FOP-303, H-hat-Mini, Snoot-S,
Lens	LEICA	D SUMMILUX 25mm F1.4ASPH	
Lens	LEICA	Elmarit-S 30mm f/2.8 ASPH	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	LEICA	Elmarit-S 30mm f/2.8 ASPH CS	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	LEICA	Elmarit-S 45mm f/2.8 ASPH	FOP-356, Snoot-M, H-Hat-M, L-Filter-M
Lens	LEICA	Elmarit-S 45mm f/2.8 ASPH CS	FOP-356, Snoot-M, H-Hat-M, L-Filter-M
Lens	LEICA	Elmarit-TL 18mm F2.8 ASPH	H-Hat-PK-Micro,
Lens	LEICA	ELMAR-M 24 mm f/3.8 ASPH	Snoot-Mini
Lens	LEICA	M 135mm f/3.4	FOP-254, Snoot-S, H-Hat-Micro
Lens	LEICA	M 21mm f/2.8	FOP-251, H Hat-PK-Micro,
Lens	LEICA	M 24mm f/2.8	FOP-251, H Hat-PK-Micro,
Lens	LEICA	M 28-35-50mm f/4	Fast-Cap-55, Filter-Cap-55, FOP-253
Lens	LEICA	M 28mm f/2.8	FOP-251, H Hat-PK-Micro,
Lens	LEICA	M 35mm f/1.4	FOP-251, H Hat-PK-Micro,
Lens	LEICA	M 35mm f/2	FOP-251, H Hat-PK-Micro,
Lens	LEICA	M 50mm f/1	Snoot-Mini, FOP-303
Lens	LEICA	M 50mm f/1.4	FOP-251, H Hat-PK-Micro,
Lens	LEICA	M 50mm f/2	FOP-251, H Hat-PK-Micro,
Lens	LEICA	M 50mm f/2.8	FOP-251, H Hat-PK-Micro,
Lens	LEICA	M 75mm f/1.4	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	LEICA	M 90mm f/2	Fast-Cap-55, Filter-Cap-55, FOP-253
Lens	LEICA	M 90mm f/2.8	FOP-253
Lens	LEICA	Noctilux-M 50mm f/0.95 ASPH	FOP-303, H-hat-Mini, Snoot-S,
Lens	LEICA	Noctilux-M 75mm F1.25 ASPH	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	LEICA	PDA Macro-ELMAR-M 90 mm f/4	Snoot-Mini
Lens	LEICA	R 100mm f/2.8	FOP-304, Snoot-S, LFilter-M, H-Hat-S,
Lens	LEICA	R 105-280mm f/4.2	H Hat-M, LS-6, Snoot-WB-XL
Lens	LEICA	R 15mm f/3.5	FOP_354,Snoot_WB_S,H_Hat_S,L_Filter_S
Lens	LEICA	R 16mm f/2.8	Snoot-Mini, FOP-303
Lens	LEICA	R 180mm f/2	
Lens	LEICA	R 180mm f/2.8	FOP-306,Snoot-WB-M, L/Filter-M, H Hat-S, FC-67, Flt-Cap-67,
Lens	LEICA	R 19mm f/2.8	Snoot-Mini, FOP-303
Lens	LEICA	R 24mm f/2.8	Snoot-Mini, FOP-301
Lens	LEICA	R 280mm f/2.8	H-Hat-L,
Lens	LEICA	R 280mm f/4	H Hat-M, LS-6, Snoot-WB-XL
Lens	LEICA	R 28-70mm f/3.5-4.5	FOP-303
Lens	LEICA	R 28mm f/2.8	FOP-301, Snoot-Mini, H-Hat-Mini, Filter-Cap-55, Fast-Cap-55
Lens	LEICA	R 35-70mm f/3.8	FOP-356,
Lens	LEICA	R 35-70mm f/4	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	LEICA	R 35mm f/1.4	FOP-303, H-Hat-Mini, F-Cap-67,
Lens	LEICA	R 35mm f/2	Snoot-Mini, FOP-303
Lens	LEICA	R 400mm f/2.8	
Lens	LEICA	R 400mm f/4	
Lens	LEICA	R 50mm f/1.4	FOP-301, Snoot-Mini, H-Hat-Mini, Filter-Cap-55, Fast-Cap-55
Lens	LEICA	R 50mm f/2	FOP-301, Snoot-Mini, H-Hat-Mini, Filter-Cap-55, Fast-Cap-55
Lens	LEICA	R 560mm f/4	
Lens	LEICA	R 560mm f/5.6	
Lens	LEICA	R 60mm f/2.8	Snoot-Mini, FOP-303, Cap-55, H-Hat-Mini
Lens	LEICA	R 70-180mm f/2.8	
Lens	LEICA	R 800mm f/5.6	
Lens	LEICA	R 80-200mm f/4	FOP-306,Snoot-M, L/Filter-L, H Hat-Mini,
Lens	LEICA	R 80mm f/1.4	FOP-303, Cap-67

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	LEICA	R 90mm f/2	Snoot-Mini, FOP-303, Cap-55, H-Hat-Mini
Lens	LEICA	R PC SUPER 28mm f/2.8	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	LEICA	SUMMARIT-M 35 mm f/2.5	Snoot-Mini
Lens	LEICA	Summarit-M 35mm f/2.4 ASPH	FOP-251,
Lens	LEICA	Summarit-M 50mm f/2.4	FOP-251,
Lens	LEICA	SUMMARIT-M 75 mm f/2.5	Snoot-Mini
Lens	LEICA	Summarit-M 75mm f/2.4	FOP-251,
Lens	LEICA	Summarit-M 90mm f/2.4	FOP-253,
Lens	LEICA	SUMMARIT-S 1:2,5/35 mm ASPH	Snoot-WB-M
Lens	LEICA	SUMMARIT-S 1:2,5/35 mm ASPH. (CS)	Snoot-WB-M
Lens	LEICA	SUMMARIT-S 1:2,5/70 mm ASPH	Snoot-WB-S
Lens	LEICA	SUMMARIT-S 1:2,5/70 mm ASPH. (CS)	Snoot-WB-S
Lens	LEICA	Summarit-S 35mm f/2.5 ASPH	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	LEICA	Summarit-S 35mm f/2.5 ASPH CS	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	LEICA	Summarit-S 70mm f/2.5 ASPH	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	LEICA	Summarit-S 70mm f/2.5 ASPH CS	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	LEICA	SUMMICRON-M 28 mm f/2 ASPH	Snoot-Mini
Lens	LEICA	Summicron-S 100mm f/2 ASPH	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	LEICA	SUMMILUX-M 21 mm f1.4 ASPH	Snoot-Mini
Lens	LEICA	SUMMILUX-M 24 mm f/1.4 ASPH	Snoot-Mini
Lens	LEICA	Summilux-M 35mm f/1.4 ASPH	FOP-251,
Lens	LEICA	Summilux-SL 50mm f/1.4 ASPH	Not published yet
Lens	LEICA	SUPER-ELMAR-M 18 mm f/3.8 ASPH	Snoot-Mini
Lens	LEICA	Super-Vario-Elmar-T 11-23mm f/3.5-4.5 ASPH	FOP-303, H-Hat-Mini, Snoot-S,
Lens	LEICA	Thambar-M 90mm F2.2	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	LEICA	TRI-ELMAR-M 16-18-21 mm f/4 ASPH	Snoot-Mini
Lens	LEICA	VARIO-ELMARIT-R 28-90 mm f/2.8-4.5	
Lens	LEICA	Vario-Elmarit-SL 24-90mm F2.8-4 ASPH	FOP-356, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	LENSBABY	Burnside 35mm f2.8	FOP-303, Snoot-Mini, H-hat-Mini, L-Filter-S, LMC-Canon
Lens	LENSBABY	Composer Special Effects SLR Lens	Snoot-Mini
Lens	LENSBABY	Control Freak Special Effects SLR Lens	Snoot-Mini
Lens	LENSBABY	Muse Special Effects SLR Lens	Snoot-Mini
Lens	LENSBABY	Scout Mount W/ Fisheye	Snoot-Mini
Lens	LENSBABY	Sol 22	FOP-301, H-Hat-PK-Mini,
Lens	LENSBABY	Sol 45 (DSLR)	FOP-301, H-Hat-PK-Mini,
Lens	LENSBABY	Sol 45 (Mirrorless)	FOP-303, H-Hat-Mini,
Lens	LENSBABY	Trio 28mm f/3.5	FOP-301, H-Hat-PK-Mini
Lens	LENSBABY	Velvet 85mm f/1.8	FOP-303, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	MAMIYA	Sekor 55mm F2.8 LS D	Snoot-WB-S
Lens	MAMIYA	Sekor AF 110mm F2.8 LS D	Snoot-WB-S
Lens	MAMIYA	Sekor AF 28mm F4.5 D Aspherical	Snoot-WB-M
Lens	MAMIYA	Sekor AF 45mm F2.8 D	Snoot-Mini
Lens	MAMIYA	Sekor AF 80mm F2.8 D	Snoot-WB-S
Lens	MAMIYA	Sekor AF 80mm F2.8 LS D	Snoot-WB-S
Lens	MAMIYA	Sekor PDA Macro MF 120mm F4 D	Snoot-S
Lens	MAMIYA	Sekor Zoom AF 75-150mm F4.5 D	Snoot-M
Lens	Meyer-Optik-Gorlitz	AP0-Makro-Plasmat 105mm f/2.7	FOP-254, Snoot-Mini, H-Hat-Micro,
Lens	Mitakon	135mm f/2.8 Full Frame	
Lens	Mitakon	35mm f/2.8 Sony E Mount	
Lens	Mitakon	50mm f/0.95 Sony E Mount	
Lens	Mitakon	85mm f/2 Full Frame	
Lens	NIKON	1 Nikkor 10mm f2.8	FOP-251, H Hat-PK-Micro,
Lens	NIKON	1 Nikkor 11-27.5mm f/3.5-5.6	FOP-251, H Hat-PK-Micro,
Lens	NIKON	1 Nikkor 18.5mm f1.8	FOP-251, H Hat-PK-Micro,
Lens	NIKON	NIKKOR Z 24-70mm f/4 S	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	NIKON	NIKKOR Z 35mm f/1.8 S	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	NIKON	NIKKOR Z 50mm f/1.8 S	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	NIKON	1 Nikkor 18.5mm f1.8	FOP-251, H Hat-PK-Micro,
Lens	NIKON	1 Nikkor 32mm f/1.2	FOP-301, Snoot-Mini, Fast Cap-52, Filter-Cap-52, H-Hat-Mini
Lens	NIKON	NIKKOR 500mm f/5.6E PF ED VR	H-Hat-L,
Lens	NIKON	1 Nikkor 6.7-13mm f/3.5-5.6 VR	FOP-251, H Hat-PK-Micro,
Lens	NIKON	1 Nikkor AW 10mm f/2.8	FOP_251,H_Hat_PK_Micro
Lens	NIKON	1 Nikkor AW 11-27.5mm f/3.5-5.6	FOP_253,H_Hat_PK_Micro
Lens	NIKON	1 Nikkor VR 10-100mm f/4.5-5.6	FOP-253, H-Hat-PK-Micro
Lens	NIKON	1 Nikkor VR 10-110mm f4.5-5.6 PD-Zoom	FOP-304, H-Hat-Mini, H-Hat-PK-Mini
Lens	NIKON	1 Nikkor VR 10-30mm f/3.5-5.6 PD-Zoom	FOP-251, H Hat-PK-Micro,
Lens	NIKON	1 Nikkor VR 30-110mm f3.8-5.6	FOP-253, H-Hat-PK-Micro,

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	NIKON	1 Nikkor VR 70-300mm f/4.5-5.6	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-62
Lens	NIKON	AF 14mm f/2.8 BI	FOP-354, H-Hat-S, LMC-Nikon
Lens	NIKON	AF 180mm f/2.8D EF-IF	FOP-306, Snoot-M, H-Hat-S, L-Filter-M, Cap-72, LMC-Nikon
Lens	NIKON	AF 18-35mm f/3.5-4.5 ED-IF	FOP-354, H-Hat-S, Cap-77, LMC-Nikon
Lens	NIKON	AF 18-35mm f/3.5-4.5 ED-IF HB-23	FOP 354,Snoot-WB-S,H_Hat_S,L_Filter_S,Filter_Cap-77
Lens	NIKON	AF 18mm f/2.8D HB-8	FOP-354, Snoot-WB-S, H-Hat-S, L-FilterS
Lens	NIKON	AF 20mm f/2.8D HB-4	FOP-303, H Hat-S, Snoot-Mini,
Lens	NIKON	AF 24-120mm f/4G ED VR	FOP-354, Snoot-S, H-Hat-S, L-Filter-S, Cap-77, LMC-Nikon
Lens	NIKON	AF 24-85mm f/2.8-4D IF	FOP-304, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-72
Lens	NIKON	AF 24mm f/2.8D HN-2	FOP-303, Snoot-WB-S, LF-S, H Hat-M, LS-3
Lens	NIKON	AF 28-100mm f/3.3-5.6G HB-27	FOP-303, H Hat-S,
Lens	NIKON	AF 28-105mm f/3.5-4.5D IF HB-18	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S, Cap-62
Lens	NIKON	AF 28-200mm f/3.5-5.6G ED-IF HB-30	FOP-303, H Hat-S,
Lens	NIKON	AF 28-80mm f/3.3-5.6G HB-20	FOP_303,Snoot_Mini,H_Hat_Mini,L_Filter_S,Filter_Cap_58mm, Fast_Cap_58mm,Filter_Pack
Lens	NIKON	AF 28mm f/1.4D HK-7	FOP-301, H-Hat-Pk-Mini
Lens	NIKON	AF 28mm f/2.8D HN-2	FOP-301, H Hat-S, Snoot-Mini,
Lens	NIKON	AF 35-70mm f/2.8D HB-1	FOP_304,Snoot_WB_S,H_Hat_S,L_Filter_S,Filter_Cap_62mm,Fast_Cap_62mm,Filter_Pack
Lens	NIKON	AF 35mm f/2D HN-3	H Hat-S, Snoot-Mini, FOP-301
Lens	NIKON	AF 50mm f/1.4D HR-2	H Hat-S, Snoot-Mini, Filter-Cap-52, Fast-Cap-52, FOP-301
Lens	NIKON	AF 50mm f/1.8D HR-2	H Hat-S, Snoot-Mini, Filter-Cap-52, Fast-Cap-52, FOP-301
Lens	NIKON	AF 70-300mm f/4-5.6	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_62mm,Fast_Cap_62mm
Lens	NIKON	AF 70-300mm f/4-5.6D ED HB-15	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_62mm,Fast_Cap_62mm
Lens	NIKON	AF 70-300mm f/4-5.6G HB-26	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_62mm,Fast_Cap_62mm
Lens	NIKON	AF 80-200mm f/2.8 ED	Snoot-L, H-Hat-M, L-Filter-L, Cap-77, LMC-Nikon
Lens	NIKON	AF 85mm f/1.4D HN-31	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77, LMC-Nikon
Lens	NIKON	AF 85mm f/1.8D HN-23	FOP-304, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-72, LMC-Nikon
Lens	NIKON	AF DC 105mm f/2D BI	FOP 354,Snoot-WB-M,H_Hat_M,L_Filter_M,Cap72
Lens	NIKON	AF DC 135mm f/2D BI	H-Hat-S, LS-6, Snoot-WB-XL
Lens	NIKON	AF DX 10.5mm f/2.8G ED-IF BI	Snoot-Mini, FOP-253
Lens	NIKON	AF Fisheye 16mm f/2.8	Snoot-Mini, FOP-253
Lens	NIKON	AF NIKKOR 28mm f/2.8D	FOP-301, Snoot-Mini, H Hat-Mini, Cap-52, LMC-Nikon
Lens	NIKON	AF PDA Micro 105mm f/2.8D HS-7	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-52
Lens	NIKON	AF PDA Micro 200mm f/4D ED-IF HB-14	FOP-306,Snoot-M, L/Filter-L, H Hat-Mini,
Lens	NIKON	AF PDA Micro 60mm f/2.8D HS-7	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-62
Lens	NIKON	AF VR 80-400mm f/4.5-5.6D ED HB-24	H Hat-L, Snoot-L,
Lens	NIKON	AF-P DX NIKKOR 10-20mm f/4.5-5.6G VR	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	NIKON	AF-P DX NIKKOR 18-55mm f/3.5-5.6G VR	FOP-253, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	NIKON	AF-P DX NIKKOR 70-300mm f/4.5-6.3G ED VR	Snoot-WB-M, H-Hat-S, L-Filter-M
Lens	NIKON	AF-P Nikkor 70-300mm F4.5-5.6E ED VR	Snoot-WB-L, H-Hat-S, Cap-67
Lens	NIKON	AF-S 17-35mm f/2.8D ED-IF HB-23	FOP 354,Snoot-WB-M,H_Hat_S,L_Filter_M,Filter_Cap-77
Lens	NIKON	AF-S 24-85mm f/3.5-4.5G ED-IF HB-28	FOP-303
Lens	NIKON	AF-S 28-70mm f/2.8D ED-IF HB-19	FOP 354,Snoot-WB-M,H_Hat_M,L_Filter_M,Cap-77
Lens	NIKON	AF-S 300mm f/2.8D ED-IF HK-25	H-Hat-XXXL, MSC-3, LMC-N
Lens	NIKON	AF-S 300mm f/4 ED-IF BI	H-Hat-XL, Snoot-WB-XXL
Lens	NIKON	AF-S 300mm f/4E PF ED VR	FOP-356, Snoot-WB-L, H-Hat-M, H-Hat-M, Lens-Filter-L
Lens	NIKON	AF-S 400mm f/2.8D ED-IF HK-24	H-Hat-L, MSC-1,
Lens	NIKON	AF-S 500mm f/4DED-IF HK-23	H-Hat-XXL, MSC-3, LMC-N, MSC-2
Lens	NIKON	AF-S 600mm f/4D ED-IF HK-29	H-Hat-XXXXL, MSC-1, LMC-N, MSC-1
Lens	NIKON	AF-S DX VR 18-200mm G ED HB-35	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Fast-Cap-72
Lens	NIKON	AF-S DX 12-24mm f/4G ED-IF HS-23	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77, LMC-Nikon
Lens	NIKON	AF-S DX 17-55mm f/2.8G ED-IF HB-31	FOP 354,Snoot-WB-M,H_Hat_S,L_Filter_M,Cap77
Lens	NIKON	AF-S DX 18-135mm f/3.5-5.6G ED-IF HB-32	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-67
Lens	NIKON	AF-S DX 18-140mm f/3.5-5.6 ED VR	FOP 354,Snoot-WB-S,H_Hat_S,L_Filter_S,Filter_Cap-67
Lens	NIKON	AF-S DX 18-55mm G HB-33	Snoot-Mini, FOP-303
Lens	NIKON	AF-S DX 18-70mm f/3.5-4.5G ED-IF HB-32	H Hat-S, Snoot-Mini, FOP-303
Lens	NIKON	AF-S DX 55-200mm f/4-5.6G ED HB-34	Snoot-Mini, FOP-303
Lens	NIKON	AF-S DX Micro NIKKOR 85mm f/3.5G ED VR	FOP-304, Snoot-S, H-Hat-S, L-Filter-S, Cap-52, LMC-Nikon
Lens	NIKON	AF-S DX NIKKOR 10-24mm f/3.5-4.5G ED	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77, LMC-Nikon
Lens	NIKON	AF-S DX Nikkor 16-80mm f/2.8-4E ED VR	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-72,

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	NIKON	AF-S DX NIKKOR 16-85mm f/3.5-5.6G ED VR	FOP-304, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-72, LMC-Nikon
Lens	NIKON	AF-S DX NIKKOR 18-105mm f/3.5-5.6G ED VR	FOP-304, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-67, LMC-Nikon
Lens	NIKON	AF-S DX NIKKOR 18-55mm f/3.5-5.6G VR	FOP-304, Snoot-WB-S, H-Hat-Mini, L-Filter-S, Cap-67, LMC-Nikon
Lens	NIKON	AF-S DX Nikkor 18-55mm f/3.5-5.6G VR II	FOP-253, Snoot-Mini, H-Hat-Micro, L-Filter-S, Cap-52
Lens	NIKON	AF-S DX Nikkor 18-55mm f/3.5-5.6G VR II	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-52, LMC-Nikon
Lens	NIKON	AF-S DX NIKKOR 35mm f/1.8G	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-58
Lens	NIKON	AF-S DX NIKKOR 35mm f/1.8G	FOP-303, Snoot-S, H-Hat-Mini, L-Filter-S, Cap-52, LMC-Nikon
Lens	NIKON	AF-S DX Nikkor 55-200mm f/4-5.6G VR II	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S, Caps-55mm
Lens	NIKON	AF-S DX NIKKOR 55-300mm f/4.5-5.6G ED VR	FOP-304, Snoot-S, H-Hat-S, L-Filter-S, Cap-58, LMC-Nikon
Lens	NIKON	AF-S DX VR 55-200mm f/4-5.6G VR II HB-37	FOP-304, Snoot-Mini, L-Filter-S, Cap-52, LMC-Nikon
Lens	NIKON	AF-S Fisheye NIKKOR 8-15mm f/3.5-4.5E ED	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	NIKON	AF-S Micro NIKKOR 60mm f/2.8G ED	FOP-304, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-62, LMC-Nikon
Lens	NIKON	AF-S NIKKOR 105mm f/1.4E ED	Snoot-WB-M, H-hat-M, L-Filter-M
Lens	NIKON	AF-S NIKKOR 14-24mm f/2.8G ED	Snoot-WB-M, L-Filter-M, LMC-Nikon
Lens	NIKON	AF-S NIKKOR 16-35mm f/4G ED VR	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-77, LMC-Nikon
Lens	NIKON	AF-S Nikkor 180-400mm F4E TC1.4 FL ED VR	H-Hat-XXL, MSC-3
Lens	NIKON	AF-S NIKKOR 200-500mm f/5.6E ED VR	Snoot-WB-XXL, H-Hat-XL, LMC-N
Lens	NIKON	AF-S NIKKOR 200mm f/2G ED VR II	Snoot-L, H-Hat-XXL, L-Filter-L, Cap-77, LMC-Nikon
Lens	NIKON	AF-S NIKKOR 24-70mm f/2.8E ED VR	FOP-356, Snoot-M, H-Hat-M, LMC-Nikon
Lens	NIKON	AF-S NIKKOR 24-70mm f/2.8G ED	FOP-356, H-Hat-L, Snoot-WB-L
Lens	NIKON	AF-S Nikkor 24-85mm F3.5-4.5G ED VR	Snoot-WB-M, LF-M, LM-Cap, Fast Cap-72
Lens	NIKON	AF-S NIKKOR 24mm f/1.8G ED	FOP-303, Snoot-WB-S, H-Hat-S, Cap-72, FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M,
Lens	NIKON	AF-S NIKKOR 28-300mm f/3.5-5.6G ED VR	Converter Cap 77mm, LMC-Nikon
Lens	NIKON	AF-S NIKKOR 28mm f/1.4E ED	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	NIKON	AF-S Nikkor 28mm f/1.8G	FOP-303, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-67
Lens	NIKON	AF-S NIKKOR 35mm f/1.4G	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-67, LMC-Nikon
Lens	NIKON	AF-S Nikkor 35mm f/1.8 ED	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-58,
Lens	NIKON	AF-S Nikkor 400mm f/2.8E FL ED VR	H-Hat-XXXL, MSC-1, LMC-N
Lens	NIKON	AF-S Nikkor 500mm f/4E ED VR	H-Hat-XXL, MSC-3, LMC-N, MSC-2
Lens	NIKON	AF-S NIKKOR 500mm f/4G ED VR	H-Hat-XXL, MSC-3, LMC-N, MSC-2
Lens	NIKON	AF-S NIKKOR 50mm f/1.4G	FOP-303, Snoot-Mini, H-Hat-Mini, Cap-58, LMC-Nikon
Lens	NIKON	AF-S Nikkor 58mm f/1.4G	Snoot_WB_S,H_Hat_S,L_Filter_S,Fast_Cap_72mm
Lens	NIKON	AF-S Nikkor 600mm f/4E ED VR	H-Hat-XXXL, MSC-1, LMC-N, MSC-1
Lens	NIKON	AF-S NIKKOR 600mm f/4G ED VR	H-Hat-XXXL, MSC-1, LMC-N, MSC-1
Lens	NIKON	AF-S NIKKOR 70-200mm f/2.8E FL ED VR	Snoot-WB-L, H-Hat-M, L-Filter-L
Lens	NIKON	AF-S Nikkor 70-200mm f/4G ED VR	Snoot-L, L/Filter-L, L-Mount-Cap, H-Hat-S, Fast-Cap-67, Filter-Cap-67, Filter-Pak
Lens	NIKON	AF-S Nikkor 800mm f/5.6 FL ED VR	MSC 2, H-Hat-XXXL, LMC-N
Lens	NIKON	AF-S Nikkor 80-400 f/4.5-5.6 ED VR	H-Hat-M, LS-6, Snoot-WB-XL
Lens	NIKON	AF-S NIKKOR 85mm f/1.4G	Snoot-WB-S, H-Hat-M, L-Filter-S, Cap-77, LMC-Nikon
Lens	NIKON	AF-S Nikkor DX 18-300mm F3.5-5.6G ED VR	FOP_354,Snoot-WB-M,H_Hat_M,L_Filter_M,Cap77
Lens	NIKON	AF-S Teleconverter TC-14E II	FOP-301
Lens	NIKON	AF-S Teleconverter TC-14E III	FOP-251,
Lens	NIKON	AF-S Teleconverter TC-17E II	FOP-301
Lens	NIKON	AF-S Teleconverter TC-20E II	FOP-303
Lens	NIKON	AF-S Teleconverter TC-20E III	FOP-301
Lens	NIKON	AF-S VR 200-400mm f/4G ED-IF HK-30	H-Hat-XXL, MSC_3, LMC-N
Lens	NIKON	AF-S VR 200mm f/2G IF-ED HK-31	H-Hat-XXL, L-Sleeve-6, Snoot-WB-XL
Lens	NIKON	AF-S VR 24-120mm f/3.5-5.6G ED-IF HB-25	FOP_304,Snoot_WB_S,H_Hat_S,L_Filter_S,Filter_Cap_62mm,Fast_Cap_62mm,Filter_Pack
Lens	NIKON	AF-S VR 300mm f/2.8G IF-ED	H-Hat-XL, Snoot-WB-XXL, MSC-3
Lens	NIKON	AF-S VR 70-200mm f/2.8G ED-IF HB-29	H-Hat-S, L-Sleeve-6, Snoot-WB-XL
Lens	NIKON	AF-S VR PDA Micro 105mm f/2.8G HB-38	FOP_354,Snoot-WB-M,H_Hat_M,L_Filter_M
Lens	NIKON	AI-S Nikkor 600mm f/4s IF-ED	Mega Shoot Cover
Lens	NIKON	Micro-NIKKOR 55mm f/2.8	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-52, LMC-Nikon
Lens	NIKON	NIKKOR 50mm f/1.2 AIS Manual Focus	FOP-301, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-52, LMC-Nikon
Lens	NIKON	NIKKOR 50mm f/1.4 Manual Focus	FOP-301, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-52, LMC-Nikon

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	NIKON	PC NIKKOR 19mm f/4E ED Tilt-Shift	Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	NIKON	PC PDA Micro 85mm f/2.8D HB-22	FOP_354,Snoot-WB-M,H_Hat_S,L_Filter_M,Filter_Cap-77
Lens	NIKON	PC-E Micro NIKKOR 45mm f/2.8D ED	Snoot-WB-M, H-Hat-S, L-Filter-M,
Lens	NIKON	PC-E Micro NIKKOR 85mm f/2.8D	Snoot-WB-M, H-Hat-S, L-Filter-M,
Lens	NIKON	PC-E NIKKOR 24mm f/3.5D ED	Snoot-WB-M, H-Hat-S, L-Filter-M,
Lens	OLYMPUS	E 11-22mm f/2.8-3.5	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-77
Lens	OLYMPUS	E 14-45mm f/3.5-5.6	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-58
Lens	OLYMPUS	E 14-54mm f/2.8-3.5	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-67
Lens	OLYMPUS	E 150mm f/2	
Lens	OLYMPUS	E 18-180mm f/3.5-6.3	
Lens	OLYMPUS	E 300mm f/2.8	H-Hat-XXL, Snoot-WB-XXL
Lens	OLYMPUS	E 35-100mm f/2	H Hat-M, LS-6, Snoot-WB-XL
Lens	OLYMPUS	E 40-150mm f/3.5-4.5	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-58
Lens	OLYMPUS	E 50-200mm f/2.8-3.5	FOP-356,
Lens	OLYMPUS	E 7-14mm f/4	FOP_354,Snoot-WB-M,H_Hat_M,L_Filter_M
Lens	OLYMPUS	E 8mm fisheye	
Lens	OLYMPUS	E 90-250mm f/2.8	H-Hat-XL, Snoot-WB-XXL
Lens	OLYMPUS	E PDA Macro 35mm f/3.5	Snoot-Mini, FOP-303
Lens	OLYMPUS	E PDA Macro 50mm f/2	Snoot-Mini, FOP-303, Cap-52, H-Hat-Mini
Lens	OLYMPUS	M. Zuiko Digital ED 12-40mm f2.8 Pro	FOP_303,Snoot_WB_S,H_Hat_Mini,L_Filter_S,Fast_Cap_62mm, Filter_Cap_62mm,Filter_Pack
Lens	OLYMPUS	M. Zuiko Digital ED 14-150mm f/4-5.6 II	FOP-253, Snoot-WB-S, H-Hat-Mini, Cap-58
Lens	OLYMPUS	M. Zuiko ED 75-300mm 1:4.8-6.7 II	FOP_304,Snoot_S,H_Hat_Mini,L_Filter_S,Filter_Cap_58mm,Fast_Cap_58mm
Lens	OLYMPUS	M.Zuiko Digital 14-42mm f3.5-5.6	Snoot-Mini
Lens	OLYMPUS	M.Zuiko Digital 17mm f/1.8	FOP_251,H_Hat_PK_Micro
Lens	OLYMPUS	M.Zuiko Digital 17mm f2.8	Snoot-Mini
Lens	OLYMPUS	M.Zuiko Digital 25mm f1.8	FOP-251, H-Hat-PK-Micro
Lens	OLYMPUS	M.Zuiko Digital 60mm f2.8 Macro	Snoot-Mini, FOP-253
Lens	OLYMPUS	M.Zuiko Digital ED 12mm f/2.0	FOP-251, H-Hat-PK-Micro
Lens	OLYMPUS	M.Zuiko Digital ED 14-150mm f4.0-5.6	Snoot-M
Lens	OLYMPUS	M.Zuiko Digital ED 14-42mm f3.5-5.6 EZ	FOP-251, H-Hat-PK-Micro
Lens	OLYMPUS	M.Zuiko Digital ED 17mm F1.2 Pro	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	OLYMPUS	M.ZUIKO DIGITAL ED 300mm f/4 PRO	
Lens	OLYMPUS	M.Zuiko Digital ED 40-150mm f/2.8 PRO	H-Hat-S, Snoot-WB-XL, L-Filter-L, Cap-72
Lens	OLYMPUS	M.Zuiko Digital ED 45mm f/1.8	FOP_251
Lens	OLYMPUS	M.Zuiko Digital ED 45mm F1.2 Pro	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	OLYMPUS	M.Zuiko Digital ED 7-14 f/2.8	FOP-354, Snoot-S, H-Hat-S, L-Filter-M,
Lens	OLYMPUS	M.Zuiko Digital ED 75-300mm f4.8-6.7	FOP-306,Snoot-M, L/Filter-L, H Hat-Mini,
Lens	OLYMPUS	M.Zuiko Digital ED 9-18mm f3.8-5.6	Snoot-Mini
Lens	OLYMPUS	M.Zuiko ED 14-150mm f/4-5.6 II	FOP-253, Snoot-WB-S, H-Hat-Mini, Cap-58
Lens	OLYMPUS	MC-14 1.4x Teleconverter	FOP-251,
Lens	OLYMPUS	Zuiko Digital 1.4x Teleconverter EC-14	FOP-301
Lens	OLYMPUS	Zuiko Digital 17.5-45mm F4.0-5.6	
Lens	OLYMPUS	Zuiko Digital 17mm F2.8 Pancake	FOP-251, H-Hat-PK-Micro
Lens	OLYMPUS	Zuiko Digital 2.0x Teleconverter EC-20	FOP-301
Lens	OLYMPUS	Zuiko Digital 25mm F2.8	Snoot-S
Lens	OLYMPUS	Zuiko Digital 25mm F2.8 Pancake	H-Hat-PK-Micro
Lens	OLYMPUS	Zuiko Digital ED 12-60mm F2.8-4.0 SWD	Snoot-Mini
Lens	OLYMPUS	Zuiko Digital ED 14-35mm F2.0 SWD	Snoot-Mini
Lens	OLYMPUS	Zuiko Digital ED 14-42mm F3.5-5.6	Snoot-S
Lens	OLYMPUS	Zuiko Digital ED 70-300mm F4.0-5.6	Snoot-Mini
Lens	OLYMPUS	Zuiko Digital ED 9-18mm F3.5-5.6	
Lens	Opteka	500mm f/8.0	H-Hat-S, Mega Shoot Cover 4
Lens	Opteka	420-800mm f/8.3 HD Telephoto Zoom	H-hat-Mini,
Lens	PANASONIC LEICA	D Summilux Asph 25mm f1.4	Snoot-S, L/Filter-S, H Hat-S,
Lens	PANASONIC LEICA	DG Macro-Element 45mm / F2.8 ASPH / Mega O.I.S.(Micro 4/3)	Snoot-Mini, FOP_253
Lens	PANASONIC LEICA	DG Elmarit 200mm F2.8	Snoot-L, H-Hat-M, L-Filter-M
Lens	PANASONIC LEICA	DG Macro-Elmarit 45mm f2.8 Asph (Micro 4/3)	Snoot-Mini, FOP_253
Lens	PANASONIC LEICA	DG Nocticron 42.5mm / F1.2 ASPH	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-67
Lens	PANASONIC LEICA	DG Summilux 15mm F1.7 ASPH	FOP_251,H_Hat_PK_Micro
Lens	PANASONIC LEICA	DG Summilux 25mm / F1.4 ASPH (Micro 4/3)	Snoot-Mini, FOP_253



OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	PANASONIC LEICA	DG Vario-Elmar 100-400mm f/4-6.3 ASPH. POWER O.I.S.	Snoot-WB-L, H-Hat-S, Cap-72,
Lens	PANASONIC LEICA	DG Vario-Elmarit 12-60mm f/2.8-4 ASPH	FOP-303, Snoot-S, L/Filter-M, H Hat-Mini, FOP-303, FC-62, Flt-Cap-62,
Lens	PANASONIC LEICA	DG Vario-Elmarit 12-60mm F2.8-4.0 ASPH	FOP-303, Snoot-S, H-Hat-Mini, L-Filter-S
Lens	PANASONIC LEICA	DG Vario-Elmarit 50-200mm F2.8-4.0 ASPH Power OIS	FOP-356, Snoot-WB-M, H-Hat-S, L-Filter-S
Lens	PANASONIC LEICA	DG Vario-Elmarit 8-18mm F2.8-4.0 ASPH	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	PANASONIC LEICA	Summilux DG 25mm f1.4 (Micro 4/3)	Snoot-Mini, FOP_253
Lens	PANASONIC Lumix	12-35mm f/2.8 Asph. (Micro 4/3)	Snoot-S, L/Filter-S, ", H Hat-Mini, Fast Cap-58, Filter Cap-58, FOP-303
Lens	PANASONIC Lumix	14-150mm F/3.5-5.6 Vario_Elmar Mega O.I.S. (Micro 4/3)	Snoot-S, L/Filter-M, H Hat-S, FC-72,
Lens	PANASONIC Lumix	14-50mm F2.8-3.5 Vario-Elmarit Asph. Mega O.I.S.	FOP_354,Snoot-WB-M,H Hat_S,L Filter_M,Filter_Cap-72
Lens	PANASONIC Lumix	14-50mm F3.8-5.6 Vario-Elmarit Asph. Mega O.I.S.	FOP_304,Snoot_WB_S,H_Hat_S,L_Filter_S,Filter_Cap_67mm,Fast_Cap_67mm,Filter_Pack
Lens	PANASONIC Lumix	DMW-LT55 55mm 1.7x Telephoto Conversion Lens	Snoot-Mini, H Hat-S, FOP-303,
Lens	PANASONIC Lumix	Fisheye Conversion Lens DMW-GFC1 (Micro 4/3)	FOP-251, H Hat-PK-Micro,
Lens	PANASONIC Lumix	G 12.5mm / F12 (Micro 4/3) 3-D	FOP-251, H Hat-PK-Micro,
Lens	PANASONIC Lumix	G 14mm / F2.5 ASPH (Micro 4/3)	FOP-251, H Hat-PK-Micro,
Lens	PANASONIC Lumix	G 20mm / F1.7 ASPH (Micro 4/3)	FOP-251, H Hat-PK-Micro,
Lens	PANASONIC Lumix	G 20mm f/1.7 II ASPH	FOP_251,H_Hat_PK_Micro
Lens	PANASONIC Lumix	G 25mm f/1.7 ASPH	FOP-253, H-Hat-PK-Micro
Lens	PANASONIC Lumix	G Fisheye 8mm / F3.5 (Micro 4/3)	FOP-251, H Hat-PK-Micro,
Lens	PANASONIC Lumix	G Vario 100-300mm / F4.0-5.6 / Mega O.I.S. (Micro 4/3)	FOP-356,Snoot-WB-M, L/Filter-M, H Hat-S, FC-67, Flt-Cap-67,
Lens	PANASONIC Lumix	G Vario 100-300mm F4-5.6 II Power OIS	FOP-356,Snoot-WB-M, L/Filter-M, H Hat-S, FC-67, Flt-Cap-67,
Lens	PANASONIC Lumix	G Vario 14-140mm f3.5-5.6 ASPH Power OIS	FOP-303, Snoot-WB-S, H-Hat-S
Lens	PANASONIC Lumix	G Vario 14-42mm F3.5-5.6 II ASPH Mega OIS	FOP-251, H Hat-PK-Micro,
Lens	PANASONIC Lumix	G Vario 14-45mm / F3.5-5.6 ASPH / Mega O.I.S. (Micro 4/3)	Snoot-Mini, H Hat-Mini, FC-52, Flt-Cap-52, FOP_253
Lens	PANASONIC Lumix	G Vario 45-150mm / F4.0-5.6 ASPH / Mega O.I.S. (Micro 4/3)	FOP_253, H Hat-Mini
Lens	PANASONIC Lumix	G Vario 45-200mm / F4.0-5.6 / Mega O.I.S. (Micro 4/3)	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-52
Lens	PANASONIC Lumix	G Vario 45-200mm F4-5.6 II Power OIS	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-52
Lens	PANASONIC Lumix	G Vario 7-14mm / f4.0 ASPH (Micro 4/3)	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	PANASONIC Lumix	G Vario HD 12-32mm F3.5-5.6 Mega OIS	FOP_251,H_Hat_PK_Micro
Lens	PANASONIC Lumix	G Vario HD 14-140mm / F4.0-5.8 ASPH / Mega O.I.S. (Micro 4/3)	FOP-303, Snoot-S, L/Filter-M, H Hat-Mini, FOP-303, FC-62, Flt-Cap-62,
Lens	PANASONIC Lumix	G X Vario 12-35mm / F2.8 Power O.I.S. (Micro 4/3)	Snoot-S, L/Filter-S, H Hat-Mini, FOP-303, FC-58, Flt-Cap-58,
Lens	PANASONIC Lumix	G X Vario 14-42mm / F3.5-5.6 ASPH / Mega O.I.S. (Micro 4/3)	Snoot-Mini, H Hat-Mini, FOP-253, FC-52, Flt-Cap-52,
Lens	PANASONIC Lumix	G X Vario 35-100mm / F2.8 / Power O.I.S.	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-58
Lens	PANASONIC Lumix	G X Vario 35-100mm F2.8 II Power OIS	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-58
Lens	PANASONIC Lumix	G X Vario PZ 14-42mm / F3.5-5.6 ASPH Power O.I.S. (Micro 4/3)	FOP-251, H Hat-PK-Micro,

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	PANASONIC Lumix	G X Vario PZ 45-175mm / F4.0-5.6mm ASPH / Power O.I.S.	Snoot-S, L/Filter-M, H Hat-Mini, FOP-253,
Lens	Panasonic Lumix	G. 42.5 f/1.7 ASPH. Power O.I.S. Lens	FOP-251, Snoot-Mini, H-Hat-Micro
Lens	Panasonic Lumix	G. Macro 30mm f/2.8 ASPH Mega O.I.S. Lens	FOP-253, Snoot-Mini, H-Hat-Micro,
Lens	PANASONIC Lumix	Macro Conversion Lens DMW-GMC1 (Micro 4/3)	FOP-251, H Hat-PK-Micro,
Lens	PANASONIC Lumix	Tele Conversion Lens DMW-GTC1 (Micro 4/3)	FOP-251, H Hat-PK-Micro,
Lens	PANASONIC Lumix	Wide Conversion Lens DMW-GWC1 (Micro 4/3)	FOP-251, H Hat-PK-Micro,
Lens	PENTAX	01 Standard Prime	FOP-251
Lens	PENTAX	02 Standard Zoom	FOP-253
Lens	PENTAX	03 Fish-Eye	FOP-251
Lens	PENTAX	04 Toy Lens Wide	FOP-251
Lens	PENTAX	05 Toy Lens Telephoto	FOP-251
Lens	PENTAX	06 Tele 15-45mm	Snoot-Mini, H-Hat-Micro, FOP_253
Lens	PENTAX	D FA 150-450MM f/4.5-6 ED DC AW	Snoot-WB-XXL, H-Hat-M
Lens	PENTAX	D FA 150-450mm f/4.5-5.6 DC AW Lens	H-Hat-M, LMC-Pentax
Lens	PENTAX	D FA 15-30mm f/2.8 ED SDM WR	Snoot-WB-L, H-Hat-L, L-Filter-M
Lens	PENTAX	D FA 28-105mm f/3.5-5.6 ED DC WR	FOP-303, Snoot-WB-S, H-Hat-S,
Lens	PENTAX	D FA* 50mm F1.4 SDM AW	FOP-301, H-Hat-Mini
Lens	Pentax	D FA* 70-200mm f/2.8 ED DC AW	H-Hat-M, LMC-Pentax
Lens	PENTAX	D FA645 35mm F3.5 AL [IF]	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	PENTAX	DA 10-17mm f/3.5-4.5	FOP-303
Lens	PENTAX	DA 12-24mm f/4.0	Snoot-WB-S, H-Hat-S, Lens-Filter-S
Lens	PENTAX	DA 14mm f/2.8	Snoot-WB-S, H-Hat-S, Lens-Filter-S
Lens	PENTAX	DA 16-45mm f/4.0	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-67
Lens	PENTAX	DA 18-270mm F3.5-6.3 ED SDM	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-62
Lens	Pentax	DA 18-50mm f/4.0-5.6 DC WR RE	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-58,
Lens	PENTAX	DA 18-50mm f/4.5-5.6 DC WR RE	FOP-251, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-58
Lens	PENTAX	DA 18-55mm f/3.5-5.6	FOP-303
Lens	PENTAX	DA 20-40mm f/2.8-4 ED	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-55
Lens	PENTAX	DA 21mm f/3.2	Filter-Cap-49, Fast-Cap-49, FOP-301
Lens	PENTAX	DA 40mm f/2.8	Filter-Cap-49, Fast-Cap-49, FOP-251
Lens	PENTAX	DA 50-200mm f/4.0-5.6	FOP-303
Lens	PENTAX	DA 560mm F5.6 ED AW	H-Hat-XXL, Lens-Mount-Cap-Pentax
Lens	PENTAX	DA 70mm f/2.4	Filter-Cap-49, Fast-Cap-49, FOP-301
Lens	PENTAX	DA* 11-18mm F2.8	Summer 2018 Availability
Lens	PENTAX	DA* 16-50mm f/2.8 ED AL	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	PENTAX	DA* 50-135mm F2.8 ED (IF) SDM	FOP-303, Snoot-S, H-Hat-S, L-Filter-S
Lens	PENTAX	DA645 28-45mm f/4.5 ED AW SR	Snoot-WB-L, H Hat-L, L-Filter-M,
Lens	PENTAX	DFA 100mm PDA Macro f/2.8	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S, Cap-49
Lens	PENTAX	DFA 50mm PDA Macro f/2.8	Snoot-Mini, FOP-303, Cap-49, H-Hat-Mini
Lens	PENTAX	DFA645 Macro 90mm F2.8 ED AW SR	FOP_354,Snoot-WB-M,H_Hat_M,L_Filter_M
Lens	PENTAX	FA 20-35mm f/4.0	FOP-303
Lens	PENTAX	FA 28-105mm f/3.5-5.6 ED DC WR	FOP-303, Snoot-WB-S, H-Hat-S,
Lens	PENTAX	FA 31mm f/1.8	FOP-303
Lens	PENTAX	FA 35-80mm f/4.0-5.6	Snoot-Mini, FOP-303
Lens	PENTAX	FA 77mm f/1.8	FOP-303
Lens	PENTAX	FA28-105mm f/3.2-4.5	Snoot-Mini, Cap-58, FOP-303
Lens	PENTAX	FAJ 18-35mm f/4.0-5.6	Snoot-Mini, FOP-303
Lens	PENTAX	FAJ 28-80mm f/3.5-5.6	Snoot-Mini, H-Hat-Micro, FOP_253
Lens	PENTAX	FAJ 75-300mm f/4.8-5.8	FOP_304,Snoot_S,H_Hat_Mini,L_Filter_S,Filter_Cap_58mm,Fast_Cap_58mm
Lens	PHOENIX	100-300mm f/5.6-6.7 Autofocus	Snoot-S
Lens	PHOENIX	100-300mm f/5.6-6.7 Manual Focus	Snoot-S
Lens	PHOENIX	100mm f/3.5 PDA Macro	Snoot-Mini
Lens	PHOENIX	19-35mm f/3.5-4.5 Autofocus	Snoot-Mini
Lens	PHOENIX	19-35mm f/3.5-4.5 Manual Focus	Snoot-Mini
Lens	PHOENIX	28-108mm f/2.8-3.8 Autofocus	Snoot-Mini
Lens	PHOENIX	28-210mm f/3.5-5.6 Autofocus	Snoot-S
Lens	PHOENIX	28-210mm f/3.5-5.6 Manual Focus	Snoot-S
Lens	PHOENIX	28-210mm f/4.2-6.5 Aspherical IF Autofocus	Snoot-S
Lens	PHOENIX	28-300mm f/4.0-6.3 Autofocus	Snoot-S
Lens	PHOENIX	28-80mm f/3.5-5.6 Autofocus	Snoot-Mini
Lens	PHOENIX	28-80mm f/3.5-5.6 Manual Focus	Snoot-Mini
Lens	PHOENIX	28mm f/2.8	Snoot-Mini

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	PHOENIX	500mm f/6.3 Mirror Manual Focus	Snoot-WB-M
Lens	PHOENIX	500mm f/8 Manual Focus	Snoot-S
Lens	PHOENIX	500mm f/8.0 Mirror (Reflex) Manual Focus	Snoot-S
Lens	PHOENIX	650-1300mm f/8-16 Manual Focus	
Lens	PHOENIX	70-210mm f/4.5-5.6	Snoot-Mini
Lens	PHOENIX	800mm f/8 Mirror Manual Focus	Snoot-WB-M
Lens	Rokinon	100mm f/2.8 Macro	FOP-304, Snoot-S, H-Hat-S, Cap-67, LMC-Canon
Lens	Rokinon	AF 85mm f/1.4 EF	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S, LMC-Canon
Lens	Rokinon	AF 14mm f/2.8	Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	Rokinon	SP 50mm f1.2	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-S, LMC-Canon
Lens	SAMSUNG	20mm F/2.8	Snoot-Mini
Lens	SAMSUNG	30mm F/2.0 Standard Pancake Lens	Snoot-Mini
Lens	SAMSUNG	45mm F1.8 2D/3D	FOP-251, H Hat-PK-Micro,
Lens	SAMSUNG	50-150mm F2.8 S ED OIS	Snoot-WB-L, H-Hat-S, Cap-72,
Lens	SAMSUNG	50-200mm F/4.0-5.6	Snoot-S
Lens	SAMSUNG	AF 85mm f/1.4 EF	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S, LMC-Canon
Lens	SAMSUNG	NX 16-50mm F2.0-2.8 S ED OIS	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-72
Lens	SAMSUNG	NX 16-50mm F3.5-5.6 ED OIS	FOP-301, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	SAMSUNG	NX 16mm F2.4 Pancake	FOP-251, H Hat-PK-Micro,
Lens	SAMSUNG	NX 20mm F2.8 Pancake	H-Hat-PK-Micro
Lens	SAMSUNG	NX 30mm F2 Pancake	FOP-251, H Hat-PK-Micro,
Lens	SAMSUNG	NX-M 17mm f/1.8 OIS	FOP-251, H Hat-PK-Micro,
Lens	SAMSUNG	NX-M 9-27mm f3.5-5.6 ED OIS	FOP-251, H Hat-PK-Micro,
Lens	SAMSUNG	NX-M 9mm f3.5 ED	FOP-251, H Hat-PK-Micro,
Lens	Samyang	100mm f/2.8 ED UMC	FOP-306, Snoot-M, H-Hat-S, L-Filter-M,
Lens	Samyang	12mm 1:2.0 NCS CS	Snoot-Mini, FOP-303
Lens	Samyang	AF 14mm f/2.8	Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	Samyang	50mm f/1.4 AS UMC	FOP-303, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	Samyang	8mm f/2.8 Fisheye II	FOP-253, Snoot-Mini, H-Hat-Micro,
Lens	Samyang	AF 14mm F2.8 EF / Rokinon AF 14mm F2.8 EF	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	Samyang	AF 35mm F2.8 FE	FOP-251, H-Hat-PK-Micro,
Lens	Samyang	XP 50mm F1.2	Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	SCHNEIDER	28mm f/2.8 PC Super-Angulon	Snoot-WB-S
Lens	SIGMA	1.4x EX DG Tele Converter	FOP-301
Lens	SIGMA	100-300mm f/4	H Hat-M, LS-6, Snoot-WB-XL
Lens	SIGMA	100-400mm f/5-6.3 DG OS HSM	Snoot-L, H-Hat-M, L-Filter-L
Lens	SIGMA	10-20mm f/4-5.6	FOP-354, Snoot-WB-S, LF-S, H Hat-S, LS-3, Cap-77
Lens	SIGMA	10-20mm F3.5	Snoot-WB-S, LF-S, H Hat-M, LS-3
Lens	SIGMA	105mm f/2.8	FOP_354,Snoot_WB_S,H_Hat_S,L_Filter_S,Cap-58
Lens	SIGMA	105mm F1.4 DG HSM Art	Snoot-WB-L, H-Hat-XL, L-Filter-M
Lens	SIGMA	10mm F2.8	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	SIGMA	120-300mm f/2/8	H-Hat-XL, Snoot-WB-XXL, MSC-4
Lens	SIGMA	120-300mm f/2/8 DG OS HSM	H Hat-XXL, MSC-4
Lens	SIGMA	120-400mm F4.5-5.6	na, LF-L, H Hat-M, Cap-77
Lens	SIGMA	12-24mm f/4 DG HSM Art	Snoot-WB-L, H-Hat-L, L-Filter-M
Lens	SIGMA	12-24mm F4.5-5.6 DG HSM II	FOP_354,Snoot-WB-M,H_Hat_M,L_Filter_M
Lens	SIGMA	12-24mm F4.5-5.6 EX DG ASP HSM	FOP_354,Snoot-WB-M,H_Hat_S,L_Filter_M
Lens	SIGMA	135-400mm f/4.5-5.6	na, LF-L, H Hat-M, Cap-77
Lens	SIGMA	135mm f/1.8 DG HSM Art	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SIGMA	14-24mm f/2.8 DG HSM Art Lens	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SIGMA	14mm f/2.8	FOP_354,Snoot-WB-M,H_Hat_S,L_Filter_M
Lens	SIGMA	14mm f/1.8 DG HSM Art	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SIGMA	150-500mm F5-6.3 APO DG OS HSM	H Hat-XL, Snoot-XXL, MSC-4, LMC
Lens	SIGMA	150-600mm f/5-6.3 DG OS HSM	Snoot-WB-XXL, H-Hat-L,
Lens	SIGMA	150-600mm f/5-6.3 DG OS HSM Sport	Snoot-WB-XXL, H-Hat-XL
Lens	SIGMA	150mm F2.8 EX APO DG HSM Macro	Snoot-WB-M, LF-M, H Hat-S, Cap-72
Lens	SIGMA	150mm F2.8 EX DG OS HSM APO Macro	Snoot-WB-L, LF-M, H Hat-S, Cap-72
Lens	SIGMA	15-30mm f/3.5-4.5	FOP_356,Snoot-WB-M,H_Hat_M,L_Filter_M
Lens	SIGMA	15mm F2.8 EX DG Diagonal Fisheye	Snoot-Mini, H Hat-M, FOP-303
Lens	SIGMA	16mm F1.4 DC DN	FOP-304, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SIGMA	170-500mm f/5-6.3	H Hat-M, LS-6, Snoot-WB-XL
Lens	SIGMA	17-35mm f/2.8-4	Snoot-WB-S, LF-L, H Hat-M, LS-3, Cap-77
Lens	SIGMA	17-50mm F2.8 EX DC OS HSM	FOP_354,Snoot_WB_S,H_Hat_S,L_Filter_S,Fast-Cap-72
Lens	SIGMA	17-70mm f/2.8-4 DC Macro HSM	Snoot-WB-S, LF-S, H Hat-S, LS-3, Cap-72
Lens	SIGMA	17-70mm F2.8-4 DC Macro OS HSM	Snoot-WB-S, LF-S, H Hat-S, LS-3, Cap-72
Lens	SIGMA	17-70mm F2.8-4.5 DC Macro	Snoot-WB-S, LF-S, H Hat-S, LS-3, Cap-72
Lens	SIGMA	180mm f/3.5	Snoot-L, LF-L, H-Hat-S, Cap-72
Lens	SIGMA	18-125mm f/3.5-5.6	Snoot-Mini, LF-S, H Hat-Mini, LS-3, Cap-62, FOP-303
Lens	SIGMA	18-125mm F3.8-5.6 DC OS HSM	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-67

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	SIGMA	18-200mm f/3.5-6.3	Snoot-Mini, LF-S, H Hat-Mini, LS-3, Cap-62, FOP-303
Lens	SIGMA	18-200mm F3.5-6.3 DC	Snoot-Mini, LF-S, H Hat-Mini, LS-3, Cap-62, FOP-303
Lens	SIGMA	18-200mm F3.5-6.3 DC (Motorized)	Snoot-Mini, LF-S, H Hat-Mini, LS-3, Cap-62, FOP-303
Lens	SIGMA	18-200mm F3.5-6.3 DC Macro OS HSM   C	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-62
Lens	SIGMA	18-200mm F3.5-6.3 DC OS	FOP_354,Snoot-S,H Hat_S,L_Filter_S,Filter_Cap-72
Lens	SIGMA	18-200mm F3.5-6.3 II DC OS HSM	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-62
Lens	SIGMA	18-250mm F3.5-6.3 DC OS HSM	FOP_354,Snoot-WB-M,H Hat_S,L_Filter_M,Filter_Cap-72
Lens	SIGMA	18-300 f/3.5-6.3 DC Macro OS HSM	FOP-354, Snoot-WB-Small, H-Hat-S, L-Filter-S, Cap-72, LMC
Lens	SIGMA	18-35mm f1.8 DC HSM	FOP_354,Snoot-WB-M,H Hat_M,L_Filter_M,Cap-72
Lens	SIGMA	18-50mm f/2.8	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S, Cap-67
Lens	SIGMA	18-50mm f/3.5-5.6	Snoot-Mini, H Hat-Mini, Cap-58, FOP-303
Lens	SIGMA	18-50mm F2.8 EX DC Macro	Snoot-WB-S, LF-S, H Hat-S, Cap-72
Lens	SIGMA	18-50mm F2.8-4.5 DC OS HSM	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-67
Lens	SIGMA	19mm F2.8 EX DN	FOP-251, H Hat-PK-Micro,
Lens	SIGMA	200-500mm F2.8 APO EX DG	na
Lens	SIGMA	20-40mm f/2.8	FOP_354,Snoot-WB-M,H Hat_S,L_Filter_M
Lens	SIGMA	20mm F1.4 DG HSM   A	FOP-356, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SIGMA	20mm F1.8 EX DG ASP RF	Snoot-WB-S, LF-S, H Hat-L, LS-3
Lens	SIGMA	24-35mm f/2 DG HSM   A	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SIGMA	24-60mm f/2.8	Snoot-WB-S, LF-S, H Hat-S, LS-3, Cap-72
Lens	SIGMA	24-70mm f/2.8	FOP_354,Snoot-WB-M,H Hat_M,L_Filter_M
Lens	SIGMA	24-70mm f/3.5-5.6	Snoot-Mini, LF-S, H Hat-Mini, LS-3, Cap-62, FOP-303
Lens	SIGMA	24-70mm f/2.8 DG OS HSM Art	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SIGMA	24-70mm F2.8 EX DG Macro	FOP_354,Snoot-WB-M,H Hat_M,L_Filter_M
Lens	SIGMA	24-70mm F2.8 IF EX DG HSM	FOP_354,Snoot_WB_S,H_Hat_M,L_Filter_S
Lens	SIGMA	24mm f/1.4 DG HSM Art	FOP-354, Snoot-WB-S, LF-S, H Hat-M, LS-3, Cap-77
Lens	SIGMA	24mm F1.8 EX DG ASP Macro	Snoot-WB-S, LF-L, H Hat-M, LS-3, Cap-77
Lens	SIGMA	28-200mm f/3.5-5.6	Snoot-Mini, LF-S, H Hat-Mini, LS-3, Cap-62, FOP-303
Lens	SIGMA	28-300mm F3.5-6.3 DG Macro	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S, Cap-62
Lens	SIGMA	28-70mm f/2.8	FOP-303, Snoot-WB-S, H-Hat-Mini, Cap-67
Lens	SIGMA	28-70mm f/2.8-4	Snoot-Mini, FOP-303, Cap-58, H-Hat-Mini
Lens	SIGMA	28-70mm F2.8-4 DG	Snoot-Mini, FOP-303, Cap-58, H-Hat-Mini
Lens	SIGMA	28mm F1.4 DG HSM   A	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SIGMA	28mm F1.8 EX DG ASP Macro	Snoot-WB-S, LF-L, H Hat-M, LS-3, Cap-77
Lens	SIGMA	2x EX DG Tele Converter	FOP-303
Lens	SIGMA	300-800mm F5.6 EX DG APO HSM	H Hat-3XL, MSC-2
Lens	SIGMA	300mm F2.8 EX APO DG HSM	H Hat-2XL, MSC-3
Lens	SIGMA	30mm f/1.4	Snoot-Mini, LF-S, H Hat-S, Cap-62, FOP-303
Lens	SIGMA	30mm F1.4 DC HSM	FOP_303,Snoot_Mini,H_Hat_Mini,L_Filter_S,Filter_Cap_62mm, Fast_Cap_62mm,Filter_Pack
Lens	SIGMA	30mm F1.4 EX DC HSM	Snoot-Mini, LF-S, H Hat-S, Cap-62, FOP-303
Lens	SIGMA	30mm F1.4 EX DC HSM	Snoot-Mini, LF-S, H Hat-S, Cap-62, FOP-303
Lens	SIGMA	30mm F2.8 EX DN	FOP-251, H Hat-PK-Micro,
Lens	SIGMA	35mm f1.4 DG HSM	FOP_304,Snoot_WB_S,H_Hat_S,L_Filter_S,Filter_Cap_67mm,Fa st_Cap_67mm,Filter_Pack
Lens	SIGMA	4.5mm F2.8 EX DC HSM Circular	FOP-303, Snoot-WB-S, LF-S, H Hat-M, LS-3
Lens	SIGMA	40mm F1.4 DG HSM   A	FOP-356, Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	SIGMA	500mm f/4 DG OS HSM Sports	H-Hat-3XL, MSC-2
Lens	SIGMA	500mm F4.5 EX DG APO HSM	H Hat-2XL
Lens	SIGMA	50-100mm f/1.8 DC HSM Art Lens	Snoot-L, H-Hat-M, L-Filter-L
Lens	SIGMA	50-150mm F2.8 EX DC APO HSM II	FOP-306,Snoot-WB-M, L/Filter-M, H Hat-S, FC-67, Flt-Cap-67,
Lens	SIGMA	50-200mm F4.5-6.3 DC OS HSM	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-55
Lens	SIGMA	50-500mm F4.5-6.3 APO DG OS HSM	H Hat-L
Lens	SIGMA	50-500mm F4-6.3 EX DG HSM	H Hat-L
Lens	SIGMA	50mm f/2.8	Snoot-Mini, H Hat-Mini, Cap-55, FOP-303
Lens	SIGMA	50mm F1.4 DG HSM   A	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-77
Lens	SIGMA	50mm F1.4 EX DG HSM	Snoot-WB-S, LF-L, H Hat-M, LS-3, Cap-77
Lens	SIGMA	50mm F2.8 EX DG Macro	Snoot-Mini, H Hat-Mini, Cap-55, FOP-303
Lens	SIGMA	55-200mm f/4-5.6	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S, Cap-55
Lens	SIGMA	56mm F1.4 DC DN   C	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	SIGMA	60-600mm F4.5-6.3 DG OS HSM   S	H-Hat-XL,
Lens	SIGMA	60mm F2.8 DN	FOP-253, H Hat-PK-Micro,
Lens	SIGMA	70-200 F2.8 DG OS HSM   S	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	SIGMA	70-200mm F2.8 EX DG APOMacro HSM II	Snoot-WB-S, LF-L, H Hat-M, Cap-77
Lens	SIGMA	70-300mm F4-5.6 APO DG Macro	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_58mm,Fast_C ap_58mm
Lens	SIGMA	70-300mm F4-5.6 DG Macro	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_58mm,Fast_C ap_58mm

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	SIGMA	70-300mm F4-5.6 DG OS	FOP-304,Snoot-WB-M, L/Filter-M, H Hat-S, FC-62, Flt-Cap-62,
Lens	SIGMA	70mm F2.8 DG Macro Art	FOP-354, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	SIGMA	70mm F2.8 EX DG Macro	FOP_304,Snoot_WB_S,H_Hat_S,L_Filter_S,Filter_Cap_62mm,Fast_Cap_62mm,Filter_Pack
Lens	SIGMA	800mm F5.6 EX APO DG HSM	H Hat-3XL
Lens	SIGMA	80-400mm f/4.5-5.6	na, LF-L, H Hat-M, Cap-77
Lens	SIGMA	8-16mm F4.5-5.6 DC HSM	FOP-304, Snoot-S, LFilter-M, H-Hat-S,
Lens	SIGMA	85mm f/1.4 DG HSM Art	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SIGMA	85mm F1.4 EX DG HSM	Snoot-WB-S, LF-S, H Hat-M, LS-3, Cap-77
Lens	SIGMA	8mm F3.5 EX DG Circular Fisheye	Snoot-Mini, H Hat-S, FOP-303
Lens	SIGMA	APO 50-150mm F2.8 EX DC OS HSM	Snoot-L, LF-L, H-Hat-M, Cap-77
Lens	SIGMA	APO 70-200mm F2.8 EX DG OS HSM	Snoot-L, LF-L, H-Hat-M, Cap-77
Lens	SIGMA	MC-11 Mount Adapter	FOP-251,
Lens	SLR Magic	26mm f/1.4 Toy	
Lens	SLR Magic	28mm f/2.8	
Lens	SLR Magic	28mm f/2.8 Bokeh morphic	
Lens	SLR Magic	35mm f/1.7	
Lens	SLR Magic	Pinhole	
Lens	SONY	100mm f/2.8 PDA Macro	FOP-304, Snoot-S, H-Hat-S, L-Filter-S, Cap-55, LMC-Sony, Filter-Pack
Lens	SONY	10-18mm f/4.0MM OSS	FOP-303, Snoot-S, L-Filter-S, H-Hat-Mini, Cap-62, Filter-Pack,
Lens	SONY	135mm f/2.8 [T4.5] STF	FOP-354, Snoot-S, H-Hat-S, L-filter-S
Lens	SONY	135mm F1.8 ZA Carl Zeiss Sonnar T*	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SONY	16-35mm f/2.8 ZA SSM II Vario-Sonnar T*	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M,
Lens	SONY	16-50mm f/3.5-5.6 PZ LENS	Snoot-Mini, H-Hat-Mini, Fast-Cap-49mm, Filter-Cap-49, Filter-Pack, FOP-253
Lens	SONY	16-70mm f/4 ZA OSS, Vario-Tessar T* E	FOP_303,Snoot_Mini,H_Hat_Mini,L_Filter_S,Filter_Cap_55mm, Fast_Cap_55mm,Filter_Pack
Lens	Sony	16mm f/2.8 Wide-Angle SEL16F28	FOP-251, Snoot-Mini, H-Hat-PK-Mini, Cap-49
Lens	Sony	20mm f/2.8 Alpha	FOP-303, Snoot-Mini, H-Hat-S
Lens	SONY	24-70mm f/2.8 ZA SSM II, Vario-Sonnar T*	FOP-354, Snoot-S, H-Hat-S, L-Filter-M,
Lens	SONY	24mm F2 SSM Carl Zeiss Distagon T*	FOP-303, Snoot-WB-S, H-Hat-S
Lens	SONY	28-75mm f/2.8	FOP-304, Snoot-S, H-Hat-S, L-Filter-S
Lens	SONY	28mm f/2.8	FOP-303, Snoot-Mini, H-Hat-Mini
Lens	SONY	300mm f/2.8 G SSM II	Snoot-WB-XXL, H-Hat-XL,
Lens	SONY	300mm f/2.8 G-Series	Snoot-WB-XXL, H-Hat-XL,
Lens	SONY	30mm f/2.8 PDA Macro	FOP-303, Snoot-Mini, H-Hat-Mini,
Lens	SONY	35mm f/1.8 OSS	Fop-251 ,Snoot-Mini, H-Hat-PK-Micro,
Lens	SONY	35mm f1.4 G-Series	FOP-253, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	SONY	500mm f/8 Reflex	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SONY	500mm f4 G SSM	H-Hat-XXL, MSC-3,
Lens	SONY	50mm f/1.4	FOP-253, H-Hat-Mini
Lens	SONY	50mm f/2.8 Macro	Snoot-Mini
Lens	SONY	70-200mm f/2.8 G	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	SONY	70-200mm F2.8 G SSM II	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	SONY	70-300mm f4.5-5.6 G SSM	FOP-356, Snoot-M, H-Hat-S, L-Filter-M,
Lens	SONY	70-300mm f4.5-5.6 G SSM II	FOP-356, Snoot-M, H-Hat-S, L-Filter-M,
Lens	SONY	70-400mm f/4-5.6	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	SONY	70-400mm f/4-5.6 GSSM II	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	SONY	75-300mm f/4-5.6	FOP-306, Snoot-S, H-Hat-Mini, L-Filter-S
Lens	SONY	85mm f/2.8 (SAL 85F28 Standard/Medium Telephoto)	FOP-303, Snoot-Mini, H-Hat-Mini,
Lens	SONY	Carl Zeiss 24-70mm f2.8	FOP-354, Snoot-S, H-Hat-S, L-Filter-M,
Lens	SONY	Carl Zeiss 85mm f/1.4	Snoot-Mini, H-Hat-S,
Lens	SONY	Carl Zeiss Planar T* 50mm F1.4 ZA SSM	FOP_354,Snoot_WB_S,H_Hat_S,L_Filter_S
Lens	SONY	Carl Zeiss Sonnar T* E 24mm F1.8 ZA	Snoot-Mini, L-Filter-S, H-Hat-Mini, Fast-Cap-49, Filter-Cap-49, FOP-253
Lens	Sony	Distagon T* FE 35mm f/1.4 ZA	FOP-304, Snoot-S, H-Hat-S, L-Filter-S
Lens	SONY	DT 11-18mm F4.5-5.6	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SONY	DT 16-105mm f/2.5-6.3	Snoot-WB-Small, H-Hat-Mini, L-Filter-S,
Lens	SONY	DT 16-80mm F3.5-4.5 ZA Carl Zeiss Vario-Sonnar T*	FOP-303, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	SONY	DT 18-135mm F3.5-5.6 SAM	FOP-303, Snoot-S, H-Hat-S, L-Filter-S
Lens	SONY	DT 18-200mm f3.5-6.3	FOP-303, Snoot-S, H-Hat-S, L-Filter-S
Lens	SONY	DT 18-250mm f/3.5-6.3	FOP-303, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SONY	DT 18-55mm f/3.5-5.6 SAM II	FOP_304,Snoot_Mini,
Lens	SONY	DT 35mm f/1.8 (SAL-35F18 Wide Angle Lens)	FOP-303, Snoot-Mini, H-Hat-Mini,
Lens	SONY	DT 35mm F1.8 SAM	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	SONY	DT 50mm f/1.8 SAM	Snoot-Mini
Lens	SONY	DT 55-200mm f/4-5.6	FOP-303, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SONY	DT 55-300mm F4.5-5.6 SAM	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	SONY	E 16-50mm F3.5-5.6 PZ OSS	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SONY	E 16mm F2.8 Pancake	H-Hat-PK-Micro
Lens	SONY	E 18-135mm F3.5-5.6 OSS	FOP-303, Snoot-S, H-Hat-Mini, L-Filter-S
Lens	SONY	E 18-135mm F3.5-5.6 OSS	FOP-303, Snoot-Mini, H-Hat-S, L-Filter-S
Lens	SONY	E 18-200mm f/3.5-6.3 OSS	FOP-304, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SONY	E 18-55mm F3.5-5.6 OSS	Snoot-Mini, L-Filter-S, H-Hat-Mini, FOP-253
Lens	SONY	E 20mm F2.8	FOP-251, H-Hat-PK-Micro
Lens	SONY	E 30mm F3.5 Macro	FOP-253, Snoot-Mini, H-Hat-Mini
Lens	SONY	E 50mm f/1.8 OSS	FOP-253, Snoot-Mini, H-Hat-Mini
Lens	SONY	E 55-210 F4.5-6.3 OSS	FOP-254, Snoot-S, L-Filter-S, H-Hat-Mini
Lens	SONY	E PZ 18-105mm f/4 G OSS	FOP_354,Snoot-WB-M,H_Hat_S,L_Filter_M,Cap-72
Lens	SONY	E PZ 18-200mm F3.5-6.3 OSS	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	SONY	FE 1.4x Teleconverter	FOP-251,
Lens	SONY	FE 100-400mm F4.5-5.6 GM OSS	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	SONY	FE 100mm f/2.8 STF GM OSS	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-S
Lens	SONY	FE 12-24mm F4 G	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	SONY	FE 16-35mm f/4 ZA OSS Vario-Tessar T*	FOP-354, H-Hat-Mini, Snoot-S,
Lens	SONY	FE 16-35mm F2.8 GM	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	SONY	FE 2.0x Teleconverter	FOP-251,
Lens	SONY	FE 24-105mm F4 G OSS	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M,
Lens	SONY	FE 24-240mm f/3.5-6.3 OSS	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Fast-Cap-72, Filter-Pack
Lens	SONY	FE 24-70mm f/2.8 GM	FOP-356, Snoot-M, H-Hat-M, L-Filter-M
Lens	SONY	FE 24-70mm F4 ZA OSS	FOP_304,Snoot_WB_S,H_Hat_S,L_Filter_S
Lens	SONY	FE 24mm F1.4 GM	FOP-303, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SONY	FE 24mm F1.4 GM	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SONY	FE 28-70mm F3.5-5.6 OSS	FOP-304, Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	SONY	FE 28mm f/2	FOP 253, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-49, Filter Pack
Lens	SONY	FE 35mm F1.4 ZA, Distagon T*	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	SONY	FE 35mm F2.8 ZA Carl Zeiss Sonnar T*	FOP_251,H_Hat_PK_Micro,
Lens	SONY	FE 400mm F2.8 GM OSS	H-Hat-3XL
Lens	SONY	FE 50mm f/1.8	FOP-303, Snoot-Mini, H-hat-Mini, L-Filter-S
Lens	SONY	FE 50mm F2.8 Macro	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	SONY	FE 55mm F1.8 ZA	FOP_253,Snoot_Mini,H_Hat_Mini,L_Filter_S,Fast_Cap_49mm,Filter_Cap_49mm
Lens	SONY	FE 70-200mm f/2.8 GM OSS	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	SONY	FE 70-200mm F4 G OSS	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	SONY	FE 70-300mm f/4.5-5.6 G OSS	Snoot-M, H-Hat-S, L-Filter-M
Lens	SONY	FE 85mm f/1.4 GM	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S
Lens	SONY	FE 85mm f/1.8	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	SONY	FE 90mm f/2.8 Macro G OSS	Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-62, Filter-Pack
Lens	Sony	FE 90mm f/2.8 Macro G OSS	FOP-354, Snoot-M, H-Hat-S, L-Filter-M, Cap-62
Lens	SONY	FE PZ 28-135mm f/4 G OSS	Snoot-WB-L, H-Hat-L, L-Filter-L,
Lens	SONY	Planar T* FE 50mm F1.4 ZA	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-S
Lens	SONY	QX1	FOP-303, Snoot-Mini, H-Hat-S, L-Filter-S
Lens	SUNEX	5.6mm f/5.6 SuperFisheye	Snoot-Mini
Lens	TAMRON	100-400mm f/4.5-6.3 Di VC USD	H Hat-M, Snoot-WB-XL
Lens	TAMRON	10-24mm f/3.5-4.5	H Hat-L, Snoot-WB-S
Lens	TAMRON	10-24mm f/3.5-4.5 Di II VC HLD	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	TAMRON	18-270mm f/3.5-6.3 Di II VC PZD	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	TAMRON	11-18mm	H Hat-M, Snoot-WB-S
Lens	TAMRON	14-150mm F/3.5-5.8 Di III (Micro 4/3)	FOP_253,Snoot_Mini,H_Hat_Mini,Filter_Cap_52mm,Fast_Cap_52mm,Filter_Pack
Lens	TAMRON	14-150mm F/3.5-5.8 Di III VC (Micro 4/3)	FOP_253,Snoot_Mini,H_Hat_Mini,Filter_Cap_52mm,Fast_Cap_52mm,Filter_Pack
Lens	TAMRON	16-300mm f/3.5-6.3 Di II VC PZD Macro	FOP-304, Snoot-S, H-Hat-S, Cap-67
Lens	TAMRON	17-35mm f/2.8-4 DI OSD	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S,
Lens	TAMRON	17-50mm	H Hat-S, Snoot-Mini
Lens	TAMRON	17-50mm w/VC	H Hat-M, Snoot-WB-S
Lens	TAMRON	18-200mm f/3.5-6.3	H Hat-S, Snoot-Mini
Lens	TAMRON	18-200mm F3.5-6.3 Di III VC	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-62
Lens	TAMRON	18-250mm	H Hat-S, Snoot-Mini
Lens	TAMRON	18-270mm w/VC	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-72
Lens	TAMRON	18-270mm f/3.5-6.3 Di II VC PZD	FOP-304, Snoot-WB-S, H-Hat-Mini, L-Filter-S

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	TAMRON	18-400mm F3.5-6.3 Di II VC HLD	Snoot-WB-M, H-Hat-S, L-Filter-M
Lens	TAMRON	200-500mm f5-6.3	H Hat-L, LS-6, Snoot-WB-XL
Lens	TAMRON	24-135mm f/3.5-5.6	H Hat-M, Snoot-WB-S
Lens	TAMRON	24mm f/2.5	FOP-301, Snoot-Mini, H-Hat-Mini, Filter-Cap-55, Fast-Cap-55
Lens	TAMRON	28-105mm f/2.8	FOP_354,Snoot-WB-M,H_Hat_S,L_Filter_M
Lens	TAMRON	28-200mm f/3.8-5.6 IF	H Hat-M, Snoot-WB-S, FOP-303
Lens	TAMRON	28-300mm f/3.5-6.3 w/VC	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-67
Lens	TAMRON	28-300mm f/3.5-6.3 Di VC PZD	FOP-304, Snoot-S, H-Hat-S, Cap-67
Lens	TAMRON	28-70mm f/3.5-4.5	Snoot-Mini, FOP-253
Lens	TAMRON	28-75mm F2.8 Di III RXD	Not published yet
Lens	TAMRON	28-80mm f/3.5-5.6	H Hat-S, ", FOP-303
Lens	TAMRON	300mm f/2.8	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-55
Lens	TAMRON	55-200mm F/4-5.6	Snoot-Mini,
Lens	TAMRON	60mm f/2	H Hat-S, Snoot-Mini
Lens	TAMRON	70-200mm f/2.8 Di LD Macro	H Hat-L, LS-6, Snoot-WB-XL, MSC-4
Lens	TAMRON	70-200mm f/2.8 DI VC USD	Snoot-L, LF-L, H-Hat-M, MSC-4
Lens	TAMRON	70-210mm f/3.5	FOP-306,Snoot-M, L/Filter-L, H Hat-Mini, FC-67, Flt-Cap-62,
Lens	TAMRON	70-210mm f/4-5.6	FOP-303
Lens	TAMRON	70-210mm F4 Di VC USD	Snoot-L, H-Hat-S, L-Filter-L
Lens	TAMRON	75-300mm f/4-5.6	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_62mm,Fast_Cap_62mm
Lens	TAMRON	90mm f/2.8	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-55
Lens	TAMRON	90mm f/2.8 DI MACRO VC	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-55
Lens	TAMRON	DI 17-35mm f/2.8-4	H Hat-L, Snoot - WB-S
Lens	TAMRON	DI 180mm f/3.5	H Hat-M, Snoot-M,
Lens	TAMRON	DI 200-500mm f/5.6-6.3	H Hat-M, LS-6, Snoot-WB-XL
Lens	TAMRON	DI 28-200mm f/3.8-5.6	H Hat-S, Snoot-Mini
Lens	TAMRON	DI 28-300mm f/3.5-6.3	H Hat-S, Snoot-Mini
Lens	TAMRON	DI 28-75mm f/2.8	H Hat-S, Snoot-Mini
Lens	TAMRON	DI 70-300mm f/4-5.6	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-M, Cap-62
Lens	TAMRON	DI 90mm f/2.8	FOP-304, Snoot-S, LFilter-M, H-Hat-S, Cap-55
Lens	TAMRON	SP 150-600mm f/5-6.3 Di VC USD G2	Snoot-WB-XXL, H-Hat-XL, MSC-4
Lens	TAMRON	SP 150-600mm f/5-6.3 VC USD	H-Hat-L, Snoot-WB-XXL, MSC-4
Lens	Tamron	SP 15-30mm f/2.8 Di VC USD	Snoot-WB-L, H-Hat-M, L-Filter-M, LMC-Canon
Lens	TAMRON	SP 24-70mm f/2.8 Di VC USD	FOP_354,Snoot-WB-M,H_Hat_S,L_Filter_M
Lens	TAMRON	SP 24-70mm F2.8 Di VC USD G2	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	TAMRON	SP 35mm F1.8 Di VC USD	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	TAMRON	SP 45mm F1.8 Di VC USD	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	TAMRON	SP 70-200mm f/2.8 Di VC USD G2	Snoot-WB-XL, H-Hat-M, L-Filter-L
Lens	TAMRON	SP 85mm f/1.8 Di VC USD	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	TAMRON	SP 90mm f/2.8 Di Macro 1:1 VC USD	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	TAMRON	Teleconverter 1.4x	FOP-301
Lens	TAMRON	Teleconverter 2.0x	FOP-303
Lens	TOKINA	AF 100mm f/2.8 PDA Macro AT-X M100 AF PRO D	Snoot-S
Lens	TOKINA	AF 10-17mm f/3.5-4.5 AT-X 107 AF DX Fish-Eye	Snoot-Mini
Lens	TOKINA	AF 11-16mm f/2.8 AT-X 116 PRO DX	FOP_354,Snoot-WB-S,H_Hat_S,L_Filter_S,Filter_Cap-77
Lens	TOKINA	AF 12-24mm f/4	Snoot-WB-S
Lens	TOKINA	AF 16.5-135mm f/3.5-5.6	Snoot-WB-S
Lens	TOKINA	AF 16-28mm f/2.8	Snoot-WB-M
Lens	TOKINA	AF 16-50mm f/2.8 AT-X 165 PRO DX	Snoot-WB-S
Lens	TOKINA	AF 35mm f/2.8 PDA Macro AT-X M35 PRO DX	Snoot-Mini
Lens	TOKINA	AF 80-400 f/4-5.6 AT-X 840 AF D	Snoot-S
Lens	TOKINA	AF-X Pro 16-50mm f/2.8 DX	FOP_354,Snoot-WB-S,H_Hat_S,L_Filter_S,Filter_Cap-77
Lens	TOKINA	AT-X 11-16mm T3.0	FOP_354,Snoot-WB-S,H_Hat_S,L_Filter_S,Filter_Cap-77
Lens	Tokina	AT-X 11-20mm f/2.8 PRO DX	FOP-354, Snoot-WB-S, H-Hat-M, L-Filter-S, LMC-Canon
Lens	TOKINA	AT-X 12-28mm f/4 Pro DX	FOP_354,Snoot_WB_S,H_Hat_S,L_Filter_S,Converter-77
Lens	TOKINA	AT-X 124 AF PRO DX II	FOP_354,Snoot_WB_S,H_Hat_S,L_Filter_S,Converter-77
Lens	TOKINA	AT-X 14-20mm f/2 PRO DX	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	TOKINA	AT-X 16.5-135mm DX	FOP_354,Snoot_WB_S,H_Hat_S,L_Filter_S,Converter-77
Lens	TOKINA	AT-X 16-28mm F2.8 PRO FX	FOP_356, Snoot-M, H-Hat-M, L-Filter-M,
Lens	TOKINA	AT-X 16-28mm T3.0	H-Hat-XL, Snoot-WB-M
Lens	TOKINA	AT-X 17-35mm f/4 Pro FX	FOP_306, Snoot-M, H-Hat-M, L-Filter-M,
Lens	Tokina	AT-X 24-70mm f/2.8 Pro FX	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-M, LMC-Canon
Lens	TOKINA	AT-X 70-200mm F4 Pro FX VCM-S	FOP-306, Snoot-M, H-Hat-M, L-Filter-M, Cap-67
Lens	TOKINA	AT-X 80-400mm f/4.5-5.6	FOP-306, Snoot-M, H-Hat-M, L-Filter-M, Cap-72
Lens	TOKINA	AT-X Pro 100mm f/2.8 Macro	FOP-304, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-55

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	TOKINA	AT-X Pro 11-16mm f/2.8 DX II	FOP_354,Snoot_WB_S,H_Hat_S,L_Filter_S,Converter-77
Lens	TOKINA	AT-X Pro 35mm f/2.8 Macro DX	FOP-303, H-Hat-S, L-Filter-S, Cap-52
Lens	TOKINA	AT-X Pro 50-135mm f/2.8 DX	FOP-306, Snoot-M, H-Hat-M, L-Filter-M, Cap-67
Lens	TOKINA	Firin 20mm F2 FE MF	Snoot-WB-S, H-Hat-Mini, L-Filter-S
Lens	TOKINA	Opera 50mm F1.4	na
Lens	TOKINA	Reflex 300mm f/6.3 MF Macro	FOP-253, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	VENUS	Laowa 25mm F2.8 2.5-5X Ultra Macro	FOP-354, Snoot-WB-S, H Hat-S, L-Filter-S,
Lens	VENUS	Laowa 105mm F2 Smooth Trans Focus	FOP-354, Snoot-WB-S, H-hat-S, L-Filter-S
Lens	VENUS	Laowa 9mm F2.8 Zero-D	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S
Lens	VIVITAR	13mm F/2.8 Aspherical (Manual Focus)	Snoot-Mini
Lens	VIVITAR	19-35mm F/3.5-4.5	Snoot-S
Lens	VIVITAR	500mm MR F/6.3	Snoot-WB-M
Lens	VIVITAR	500mm MR F/8	Snoot-S
Lens	VIVITAR	650-1300mm F/8-16	
Lens	VIVITAR	70-210 f/4.5-5.6	Snoot-S
Lens	VIVITAR	7mm Fisheye F/3.5	
Lens	VIVITAR	800mm MR F/8	Snoot-WB-M
Lens	VIVITAR	85mm F1.4 Aspherical	Snoot-S
Lens	Voigtlander	10.5mm f/0.95 Nokton	FOP-303, Snoot-WB-S, H-Hat-S, L-Filter-S, Cap-72,
Lens	VOIGTLANDER	12 mm / F5,6 UltraWide Heliar	Snoot-Mini
Lens	VOIGTLANDER	15 mm / F 4,5 Super Wide Heliar	Snoot-Mini
Lens	VOIGTLANDER	20 mm / F3,5 Color Skopar SL II	Snoot-Mini
Lens	VOIGTLANDER	21 mm / F 4,0 Color Skopar	Snoot-Mini
Lens	VOIGTLANDER	21mm / F4,0 Color Skopar Pancake II	Snoot-Mini
Lens	VOIGTLANDER	25 mm / F 4,0 Color Skopar Pancake	Snoot-Mini
Lens	VOIGTLANDER	25mm F0.95 Nokton MFT	
Lens	VOIGTLANDER	28 mm / F2,0 Ultron	Snoot-Mini
Lens	VOIGTLANDER	35 mm / F 1,2 Nokton	Snoot-Mini
Lens	VOIGTLANDER	35 mm / F 1,4 Nokton	Snoot-Mini
Lens	VOIGTLANDER	35 mm / F 2,5 Color Skopar Classic	Snoot-Mini
Lens	VOIGTLANDER	40 mm / F 1,4 Nokton	Snoot-Mini
Lens	VOIGTLANDER	40 mm F 2.0 Ultron SLII	Snoot-Mini
Lens	VOIGTLANDER	50 mm / F 1,1 Nokton	Snoot-Mini
Lens	VOIGTLANDER	50 mm / F 2,0 Heliar	
Lens	VOIGTLANDER	58 mm F 1,4 Nokton SLII	Snoot-Mini
Lens	VOIGTLANDER	75 mm / F 1,8 Heliar	
Lens	VOIGTLANDER	75 mm / F 2,5 Color Heliar	Snoot-Mini
Lens	VOIGTLANDER	90 mm / F 3,5 Apo Lanthar	Snoot-Mini
Lens	VOIGTLANDER	90 mm / F3,5 SL II APO-Lanthar	Snoot-Mini
Lens	Voigtlander	Super Wide-Heliar 15mm f/4.5 Aspherical III	FOP-303, Snoot-Mini, H-Hat-Mini, L-Filter-S, Cap-58,
Lens	VOIGTLANDER	Ultron 40mm f/2 SL IIS Aspherical	FOP-251, H Hat-PK-Micro
Lens	Yongnuo	50mm f/1.8	FOP-303, Snoot-Mini, H-Hat-S, L-Filter-S, Cap-52,
Lens	Yongnuo	YN 14mm f/2.8	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-S, LMC-Nikon
Lens	Yongnuo	YN 40mm f/2.8N	FOP-303, Snoot-Mini, H-Hat-S, L-Filter-S, Cap-58,
Lens	Yongnuo	YN 50mm f/1.4	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	Yongnuo	YN 60mm f/2 MF	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	Zeiss	35mm f/1.4 Distagon T* ZM	FOP-253, Snoot-Mini, H-Hat-Mini,
Lens	ZEISS	Batis 25mm f/2	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S,
Lens	ZEISS	Batis 40mm F2 CF	FOP-354, Soot-WB-S, H-Hat-M, L-Filter-S,
Lens	ZEISS	Batis 85mm f/1.8	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S,
Lens	ZEISS	DA 55-300mm F4.0-5.8 ED WR	FOP_304,Snoot_S,H_Hat_S,L_Filter_S,Filter_Cap_58mm,Fast_C ap_58mm
Lens	ZEISS	Distagon T* 1,4/35	Snoot-S
Lens	ZEISS	Distagon T* 2,8/21	Snoot-WB-S
Lens	ZEISS	Distagon T* 2,8/25	Snoot-Mini
Lens	ZEISS	Distagon T* 2/28	Snoot-Mini
Lens	ZEISS	Distagon T* 2/35	Snoot-S
Lens	ZEISS	Distagon T* 3,5/18	Snoot-WB-S
Lens	ZEISS	Loxia 21mm f/2.8	FOP-253, Snoot-Mini, H-Hat-S, L-Filter-S,
Lens	ZEISS	Loxia 25mm F2.4	FOP-253, Snoot-Mini, H-Hat-S, L-Filter-S,
Lens	ZEISS	Loxia 35mm f/2 Biogon T	FOP-253, H-hat-Mini
Lens	ZEISS	Loxia 50mm f/2	FOP-253, H-hat-Mini
Lens	ZEISS	Loxia 85mm f/2.4	FOP-304, Snoot-S, H-Hat-Mini
Lens	ZEISS	Makro-Planar T* 2/100	Snoot-S
Lens	ZEISS	Makro-Planar T* 2/50	Snoot-Mini
Lens	ZEISS	Milvus 100mm f/2M ZE (Lens Only)	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	ZEISS	Milvus 100mm f/2M ZE (With Hood)	Snoot_M, H-Hat-S, L-Filter-L
Lens	ZEISS	Milvus 135mm f/2 ZE	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	ZEISS	Milvus 15mm f/2.8 ZE	Snoot-WB-M, H-Hat-L, L-Filter-M, MSC-4



OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens	ZEISS	Milvus 21mm f/2.8 ZE (Lens Only)	Snoot-WB-S, H-hat-M, L-Filter-S
Lens	ZEISS	Milvus 21mm f/2.8 ZE (With Hood)	FOP-356, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	ZEISS	Milvus 25mm f/1.4 ZE	Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	ZEISS	Milvus 35mm f/2 ZE (Lens Only)	FOP-303, Snoot-S, H-Hat-S, L-Filter-S
Lens	ZEISS	Milvus 35mm f/2 ZE (With Hood)	FOP-354, Snoot-S, H-Hat-S, L-Filter-S
Lens	ZEISS	Milvus 35mm F1.4	FOP-356, Snoot-WB-M, H-Hat-M, L-Filter-M
Lens	ZEISS	Milvus 50mm f/1.4 ZE (Lens Only)	FOP-354, Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	ZEISS	Milvus 50mm f/1.4 ZE (With Hood)	FOP-356, Snoot-M, H-Hat-S, L-Filter-S,
Lens	ZEISS	Milvus 50mm f/2M ZE (Lens Only)	Snoot-WB-S, H-Hat-S, L-Filter-S
Lens	ZEISS	Milvus 50mm f/2M ZE (With Hood)	FOP-354, Snoot-WB-M, H-Hat-S, L-Filter-S
Lens	ZEISS	Milvus 85mm f/1.4 ZE (Lens Only)	FOP-354, Snoot-WB-M, H-Hat-M, L-Filter-S
Lens	ZEISS	Milvus 85mm f/1.4 ZE (With Hood)	FOP-356, Snoot-WB-L, H-Hat-M, L-Filter-M
Lens	ZEISS	Otus 1.4/55	FOP-356, Snoot_WB_M,H_Hat_M,L_Filter_M
Lens	ZEISS	Otus 28mm f/1.4 ZE (Lens Only)	Snoot-WB-M, H-Hat-L, L-Filter-M, MSC-4
Lens	ZEISS	Otus 28mm f/1.4 ZE (With Hood)	Snoot-WB-L, H-Hat-L, L-Filter-L, MSC-4
Lens	ZEISS	Planar T* 1,4/50	Snoot-Mini
Lens	ZEISS	Planar T* 1,4/85	Snoot-S
Lens	ZEISS	Touit 2.8/50M	FOP-303, Snoot-S, H-Hat-Mini, Cap-52
Lens Hood	Sony	ALC-SH120	H-Hat-L
Lens Hood	Sony	ALC-SH121	H-Hat-XL
Lens Hood	Canon	ES-84	H-Hat-M
Lens Hood	Canon	ET-83E	H-Hat-M
Lens Hood	Canon	ET-88	H-Hat-M
Lens Hood	Sony	ALC-SH122	H-Hat-M
Lens Hood	Sony	ALC-SH123	H-Hat-S
Lens Hood	Sony	ALC-SH124	H-Hat-S
Lens Hood	Nikon	HB-84 (Nikkor 500mm f/5.6)	H-Hat-L
Lens Hood	Nikon	HB-85 (Nikkor Z 24-70mm f/4 S)	H-Hat-S
Lens Hood	Nikon	HB-89 (NIKKOR Z 35mm f/1.8 S)	H-Hat-S
Lens Hood	Nikon	HB-90 (NIKKOR Z 50mm f/1.8 S)	H-Hat-S
Lens Hood	Sony	ALC-SH125	H-Hat-XL
Lens Hood	Sony	ALC-SH126	H-Hat-M
Lens Hood	Sony	ALC-SH127	H-Hat-S
Lens Hood	Sony	ALC-SH128	H-Hat-M
Lens Hood	Sony	ALC-SH129	H-Hat-Micro
Lens Hood	Sony	ALC-SH130	H-Hat-S
Lens Hood	Sony	ALC-SH131	H-Hat-S
Lens Hood	Sony	ALC-SH132	H-Hat-S
Lens Hood	Sony	ALC-SH133	H-Hat-M
Lens Hood	Sony	ALC-SH134	H-Hat-M
Lens Hood	Sony	ALC-SH135	H-Hat-XXL
Lens Hood	Sony	ALC-SH136	H-Hat-M
Lens Hood	Sony	ALC-SH137	H-Hat-M

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Lens Hood	Sony	ALC-SH138	H-Hat-M
Lens Hood	Sony	ALC-SH140	H-Hat-M
Lens Hood	Sony	ALC-SH141	H-Hat-L
Lens Hood	Sony	ALC-SH142	H-Hat-L
Lens Hood	Sony	ALC-SH143	H-Hat-M
Lens Hood	Sony	ALC-SH144	H-Hat-M
Lens Hood	Sony	ALC-SH145	H-Hat-L
Lens Hood	Sony	ALC-SH146	H-Hat-S
Netbook	Acer	Aspire one 10.1	S-SL 841, Computer-S 11.5
Netbook	Acer	Aspire one 11.6	Computer-S 11.5
Netbook	ASUS	10.1 inch	S-SL 841, Computer-S 11.5
Netbook	HP	Mini 110, 210	S-SL 841, Computer-S 11.5
Phone	Apple	iPhone 4/4S	Snap-H-M, Euro-M
Phone	Apple	iPhone 4/4S w/Cover	Snap-H-M, Euro-M, S-SL 335
Phone	Apple	iPhone 6s	S-SL 356
Phone	Apple	iPhone 7	S-SL 356
Phone	Apple	iPhone 7 Plus	S-SL-387
Phone	Apple	iPhone SE	S-SL-335
Phone	Apple	iPhone 8	S-SL 356
Phone	Apple	iPhone 8 Plus	S-SL-387
Phone	Apple	iPhone X	S-SL 387
Phone	Apple	iPhone 5 w/Heavy Cover	S-SL 356
Phone	Apple	iPhone 5S	Snap-H-M, Euro-M, S-SL 335, SSK 5S
Phone	Apple	iPhone 6	S-SL 356, SSK 6
Phone	Apple	iPhone 6 Plus	S-SL 387, SSK 6Plus
Phone	Blackberry	Bold 9930	S-SL 335
Phone	Blackberry	Curve 3G	S-SL 324
Phone	Blackberry	Q10	S-SL-355, Snap-H-L
Phone	Blackberry	Storm 2	S-SL 335
Phone	Blackberry	Torch 9800	S-SL-355, Snap-H-L, PE-Euro-Med
Phone	Blackberry	Torch 9850	S-SL-355, Snap-H-L
Phone	Blackberry	Z10	S-SL-356
Phone	Blu	Advance 4.0	S-SL-335
Phone	Blu	Life One	S-SL-356
Phone	Blu	Life Pro	S-SL-356
Phone	Blu	Life Pure	S-SL-356
Phone	Blu	Life View	na
Phone	Blu	Studio 5.5	na
Phone	Blu	Vivo 4.8	S-SL-356
Phone	HTC	DNA	S-SL 356
Phone	HTC	Incredible 2	S-SL 335
Phone	HTC	One	S-SL-356
Phone	HTC	Rhyme	S-SL 335, Snap-H-L
Phone	HTC	Thunderbolt	S-SL 335
Phone	HTC	Trophy	S-SL 335, Snap-H-L
Phone	HTC	Windows 8x	S-SL 356
Phone	LG	Enlighten	S-SL 335
Phone	LG	G2	S-SL-356
Phone	LG	G3	S-SL-376
Phone	LG	G6	S-SL-376
Phone	LG	Intuition	na
Phone	LG	Revolution	S-SL 335
Phone	LG	Spectrum 2	S-SL 356
Phone	Motorola	Atrix 2	S-SL 335
Phone	Motorola	Bionic	S-SL 335
Phone	Motorola	Droid 3	S-SL 335
Phone	Motorola	Electrify	na
Phone	Motorola	Global	S-SL 335
Phone	Motorola	Milestone	S-SL 335
Phone	Motorola	Photon	S-SL 335
Phone	Motorola	Pro	S-SL-335, Snap-H-L

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Phone	Motorola	RAZR	S-SL 335
Phone	Motorola	RAZR HD	S-SL 356
Phone	Motorola	Titanium	S-SL 335
Phone	Motorola	Triumph	S-SL 335
Phone	Motorola	X2	S-SL 335
Phone	Nokia	520	S-SL-335
Phone	Nokia	720	S-SL-335
Phone	Nokia	925	S-SL-335
Phone	Nokia	928	S-SL-356
Phone	Samsung	Captivate Glide	S-SL-335
Phone	Samsung	Charge	S-SL-356
Phone	Samsung	Galaxy A5	S-SL-356
Phone	Samsung	Galaxy A7	S-SL-387
Phone	Samsung	Galaxy Ace 3	S-SL-335
Phone	Samsung	Galaxy Alpha	S-SL-356
Phone	Samsung	Galaxy Exhilarate	S-SL-335
Phone	Samsung	Galaxy Fame	S-SL-335
Phone	Samsung	Galaxy Grand	S-SL-356
Phone	Samsung	Galaxy Mega 5.8	S-SL-387
Phone	Samsung	Galaxy Mega 6.3	S-SL-387
Phone	Samsung	Galaxy Note	S-SL-387
Phone	Samsung	Galaxy Note 3	S-SL-387
Phone	Samsung	Galaxy Note 4	S-SL-387
Phone	Samsung	Galaxy Note 4	S-SL-387
Phone	Samsung	Galaxy Note 5	S-SL-387
Phone	Samsung	Galaxy Note II	S-SL-387
Phone	Samsung	Galaxy S	S-SL-335
Phone	Samsung	Galaxy S Duos	S-SL-335
Phone	Samsung	Galaxy S III	S-SL-356
Phone	Samsung	Galaxy S III & S4 w/Cover	S-SL 376
Phone	Samsung	Galaxy S Mini	S-SL-335
Phone	Samsung	Galaxy S4	S-SL-356
Phone	Samsung	Galaxy S5	S-SL-356
Phone	Samsung	Galaxy S5 Mini	S-SL-356
Phone	Samsung	Galaxy S6	S-SL-356
Phone	Samsung	Galaxy S6 Active	S-SL-356
Phone	Samsung	Galaxy S6 Edge	S-SL-356
Phone	Samsung	Galaxy S6 edge+	S-SL-387
Phone	Samsung	Galaxy S7	S-SL-356
Phone	Samsung	Galaxy S7 Active	S-SL-387
Phone	Samsung	Galaxy S7 edge	S-SL-387
Phone	Samsung	Galaxy S8	S-SL-387
Phone	Samsung	Galaxy S8+	S-SL-387
Phone	Samsung	Galaxy S9	S-SL-387
Phone	Samsung	Galaxy S9	S-SL-387
Phone	Samsung	Galaxy S9+	S-SL-387
Phone	Samsung	Galaxy Y Duos	S-SL-335
Phone	Sony	Xperia L	na
Phone	Sony	Xperia M	S-SL-335
Phone	Sony	Xperia SP	S-SL-356
Phone	Sony	Xperia Z 1	S-SL-356
Phone	Sony	Xperia Z L	S-SL-335
Phone	Sony	Xperia Z Ultra	na
Phone	Sony	Xperia ZR	S-SL-356
Tablet	Acer	Iconia	S-SL 751
Tablet	Amazon	Kindle	S-SL 528, Computer-S 8
Tablet	Amazon	Kindle DX	S-SL 751
Tablet	Amazon	Kindle Fire	S-SL 528, Computer-S 8
Tablet	Amazon	Kindle Fire HD	S-SL 528, Computer-S 8
Tablet	Amazon	Kindle Fire HD 8.9"	Computer-S 9
Tablet	Amazon	Kindle Paper White	
Tablet	Apple	iPad 2	S-SL 770, Computer-S 10
Tablet	Apple	iPad 3	S-SL 770, Computer-S 10
Tablet	Apple	iPad 4	S-SL 770, Computer-S 10
Tablet	Apple	ipad Air	S-SL 770, Computer-S 10
Tablet	Apple	iPad Mini	S-SL 598, Computer-S 9
Tablet	Apple	Touch	
Tablet	Asus	EzePad	S-SL 751
Tablet	ASUS	Transformer	S-SL 751

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Tablet	Blackberry	Playbook	S-SL 528
Tablet	Dell	Latitude 10	S-SL-802, Computer Sleeve 11.5
Tablet	Dell	Streak 5	
Tablet	Dell	Streak 7	S-SL 528, Computer-S 8
Tablet	Dell	XPS 10	S-SL-802, Computer Sleeve 11.5
Tablet	Dell	XPS 10 + Dock	S-SL-802, Computer Sleeve 11.5
Tablet	HTC	Flyer	S-SL 528, Computer-S 8
Tablet	Lenovo	IdeaPad Tablet A1	S-SL 528, Computer-S 8
Tablet	Lenovo	IdeaPad Tablet K1	
Tablet	Lenovo	ThinkPad Tablet	
Tablet	Microsoft	Surface Pro	S-SL 770, Computer-S 10
Tablet	Microsoft	Surface RT	S-SL 770, Computer-S 10
Tablet	Motorola	Xoom	Computer-S 10
Tablet	Nook	Color	
Tablet	Samsung	Galaxy Tab 10.1	S-SL 751
Tablet	Samsung	Galaxy Tab 7	S-SL 598
Tablet	Samsung	Galaxy Tab 8	S-SL 598
Tablet	T Mobile	G State	
Tablet	Toshiba	Thrive	S-SL 751
Tablet	ViewSonic	G Tablet	S-SL 751
Tripod	GIOTTOS	MT 7350	Tripod 1"
Tripod	GIOTTOS	MT 7351	Tripod 1"
Tripod	GIOTTOS	MT 7360	Tripod 1"
Tripod	GIOTTOS	MT 7361	Tripod 1"
Tripod	GIOTTOS	MT 7370	Tripod 1.25"
Tripod	GIOTTOS	MT 7371	Tripod 1.25"
Tripod	GIOTTOS	MT 8350	Tripod 1"
Tripod	GIOTTOS	MT 8351	Tripod 1"
Tripod	GIOTTOS	MT 8360	Tripod 1"
Tripod	GIOTTOS	MT 8361	Tripod 1"
Tripod	GIOTTOS	MT 8370	Tripod 1.25"
Tripod	GIOTTOS	MT 8371	Tripod 1.25"
Tripod	GIOTTOS	MT 9350	Tripod 1"
Tripod	GIOTTOS	MT 9351	Tripod 1"
Tripod	GIOTTOS	MT 9360	Tripod 1"
Tripod	GIOTTOS	MT 9361	Tripod 1"
Tripod	GIOTTOS	MT 9370	Tripod 1.25"
Tripod	GIOTTOS	MT 9371	Tripod 1.25"
Tripod	GITZO	Cremaillere 2 - 212	Tripod 1"
Tripod	GITZO	Cremaillere 3 - 312	Tripod 1.25"
Tripod	GITZO	Cremaillere 3 - 328	Tripod 1.25"
Tripod	GITZO	G1320	Tripod 1.25"
Tripod	GITZO	G1340	Tripod 1.25"
Tripod	GITZO	G1340V	Tripod 1.25"
Tripod	GITZO	G1410	Tripod 1.5"
Tripod	GITZO	G1500	Tripod 1.5"
Tripod	GITZO	G1504	Tripod 1.5"
Tripod	GITZO	G1505	Tripod 1.5"
Tripod	GITZO	G2220	Tripod 1"
Tripod	GITZO	GT1530	Tripod 1"
Tripod	GITZO	GT1540	Tripod 1"
Tripod	GITZO	GT1540G	Tripod 1"
Tripod	GITZO	GT1540T	Tripod 1"
Tripod	GITZO	GT1550T	Tripod 1"
Tripod	GITZO	GT1931	Tripod 1"
Tripod	GITZO	GT2330	Tripod 1"
Tripod	GITZO	GT2340L	Tripod 1"
Tripod	GITZO	GT2530	Tripod 1"
Tripod	GITZO	GT2530EX	Tripod 1"
Tripod	GITZO	GT2530LVL	Tripod 1"
Tripod	GITZO	GT2540	Tripod 1"
Tripod	GITZO	GT2540EX	Tripod 1"
Tripod	GITZO	GT2540G	Tripod 1"
Tripod	GITZO	GT2540LVL	Tripod 1"
Tripod	GITZO	GT2541L	Tripod 1"
Tripod	GITZO	GT2931	Tripod 1"
Tripod	GITZO	GT2931EX	Tripod 1"
Tripod	GITZO	GT2941	Tripod 1"
Tripod	GITZO	GT2941L	Tripod 1"

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Tripod	GITZO	GT2941LVL	Tripod 1"
Tripod	GITZO	GT3530	Tripod 1.25"
Tripod	GITZO	GT3530LSV	Tripod 1.25"
Tripod	GITZO	GT3530S	Tripod 1.25"
Tripod	GITZO	GT3540	Tripod 1.25"
Tripod	GITZO	GT3540L	Tripod 1.25"
Tripod	GITZO	GT3540LS	Tripod 1.25"
Tripod	GITZO	GT3540XLS	Tripod 1.25"
Tripod	GITZO	GT5530S	Tripod 1.5"
Tripod	GITZO	GT5540LS	Tripod 1.5"
Tripod	GITZO	GT5560SGT	Tripod 1.5"
Tripod	GITZO	Inter Pro Studex 340	Tripod 1.25"
Tripod	GITZO	Inter Pro Studex 341	Tripod 1.25"
Tripod	GITZO	Inter Pro Studex 342	Tripod 1.25"
Tripod	GITZO	Inter Pro Studex 345	Tripod 1.25"
Tripod	GITZO	Inter Pro Studex 346	Tripod 1.25"
Tripod	GITZO	Inter Pro Studex 347	Tripod 1.25"
Tripod	GITZO	Monopod 222	Tripod 1"
Tripod	GITZO	Monopod 322	Tripod 1.25"
Tripod	GITZO	Moun taineer G1228	Tripod 1"
Tripod	GITZO	Moun taineer G1338	Tripod 1.25"
Tripod	GITZO	Moun taineer G1348	Tripod 1.25"
Tripod	GITZO	Pro Reporter 241	Tripod 1"
Tripod	GITZO	Pro Reporter 242	Tripod 1"
Tripod	GITZO	Pro Reporter 246	Tripod 1"
Tripod	GITZO	Pro Reporter 247	Tripod 1"
Tripod	GITZO	Pro Studex 410C	Tripod 1.5"
Tripod	GITZO	Pro Studex 410R	Tripod 1.5"
Tripod	GITZO	Pro Studex 413C	Tripod 1.5"
Tripod	GITZO	Pro Studex 413R	Tripod 1.5"
Tripod	GITZO	Pro Studex 415C	Tripod 1.5"
Tripod	GITZO	Pro Studex 415R	Tripod 1.5"
Tripod	GITZO	Pro Studex 418C	Tripod 1.5"
Tripod	GITZO	Pro Studex 418R	Tripod 1.5"
Tripod	GITZO	Reporter 201	Tripod 1"
Tripod	GITZO	Reporter 204	Tripod 1"
Tripod	GITZO	Reporter 206	Tripod 1"
Tripod	GITZO	Reporter 220	Tripod 1"
Tripod	GITZO	Reporter 224	Tripod 1"
Tripod	GITZO	Reporter 226	Tripod 1"
Tripod	GITZO	Safari S220	Tripod 1"
Tripod	GITZO	Safari S320	Tripod 1.25"
Tripod	GITZO	Safari S323	Tripod 1.25"
Tripod	GITZO	Series 1	Tripod 1"
Tripod	GITZO	Series 2	Tripod 1"
Tripod	GITZO	Series 3	Tripod 1.25"
Tripod	GITZO	Series 4	Tripod 1.5"
Tripod	GITZO	Series 5	Tripod 1.5"
Tripod	GITZO	Studex 301	Tripod 1.25"
Tripod	GITZO	Studex 302	Tripod 1.25"
Tripod	GITZO	Studex 304	Tripod 1.25"
Tripod	GITZO	Studex 320	Tripod 1.25"
Tripod	GITZO	Studex 323	Tripod 1.25"
Tripod	GITZO	Studex 325	Tripod 1.25"
Tripod	GITZO	Studex 326	Tripod 1.25"
Tripod	GITZO	Tele Studex 500C	Tripod 1.5"
Tripod	GITZO	Tele Studex 500R	Tripod 1.5"
Tripod	GITZO	Tele Studex 501	Tripod 1.5"
Tripod	GITZO	Tele Studex 502	Tripod 1.5"
Tripod	GITZO	Tele Studex 504C	Tripod 1.5"
Tripod	GITZO	Tele Studex 504R	Tripod 1.5"
Tripod	GITZO	Tele Studex 505C	Tripod 1.5"
Tripod	GITZO	Tele Studex 505R	Tripod 1.5"
Tripod	GITZO	Tele Studex 506	Tripod 1.5"
Tripod	GITZO	Tele Studex 507	Tripod 1.5"
Tripod	GITZO	Tele Studex 508C	Tripod 1.5"
Tripod	GITZO	Tele Studex 508R	Tripod 1.5"
Tripod	GITZO	Tele Studex 509	Tripod 1.5"
Tripod	GITZO	Tele Studex 510C	Tripod 1.5"

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Tripod	GITZO	Tele Studex 510R	Tripod 1.5"
Tripod	GITZO	Tele Studex 515	Tripod 1.5"
Tripod	Manfrotto / Bogen	3000	Tripod 1"
Tripod	Manfrotto / Bogen	3001	Tripod 1"
Tripod	Manfrotto / Bogen	3002	Tripod 1"
Tripod	Manfrotto / Bogen	3003	Tripod 1"
Tripod	Manfrotto / Bogen	3004	Tripod 1"
Tripod	Manfrotto / Bogen	3005	Tripod 1"
Tripod	Manfrotto / Bogen	3010	Tripod 1.25"
Tripod	Manfrotto / Bogen	3011	Tripod 1.25"
Tripod	Manfrotto / Bogen	3012	Tripod 1.25"
Tripod	Manfrotto / Bogen	3013	Tripod 1.25"
Tripod	Manfrotto / Bogen	3014	Tripod 1.25"
Tripod	Manfrotto / Bogen	3015	Tripod 1.25"
Tripod	Manfrotto / Bogen	3020	Tripod 1"
Tripod	Manfrotto / Bogen	3021	Tripod 1"
Tripod	Manfrotto / Bogen	3022	Tripod 1"
Tripod	Manfrotto / Bogen	3023	Tripod 1"
Tripod	Manfrotto / Bogen	3024	Tripod 1"
Tripod	Manfrotto / Bogen	3132	Tripod 1"
Tripod	Manfrotto / Bogen	3177	Tripod 1"
Tripod	Manfrotto / Bogen	3199	Tripod 1"
Tripod	Manfrotto / Bogen	3200	Tripod 1"
Tripod	Manfrotto / Bogen	3204	Tripod 1"
Tripod	Manfrotto / Bogen	3205	Tripod 1"
Tripod	Manfrotto / Bogen	3208	Tripod 1"
Tripod	Manfrotto / Bogen	3209	Tripod 1"
Tripod	Manfrotto / Bogen	3210	Tripod 1.25"
Tripod	Manfrotto / Bogen	3211	Tripod 1.25"
Tripod	Manfrotto / Bogen	3212	Tripod 1.25"
Tripod	Manfrotto / Bogen	3213	Tripod 1.25"
Tripod	Manfrotto / Bogen	3214	Tripod 1.25"
Tripod	Manfrotto / Bogen	3220	Tripod 1.25"
Tripod	Manfrotto / Bogen	3221	Tripod 1.25"
Tripod	Manfrotto / Bogen	3222	Tripod 1.25"

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Tripod	Manfrotto / Bogen	3223	Tripod 1.25"
Tripod	Manfrotto / Bogen	3224	Tripod 1.25"
Tripod	Manfrotto / Bogen	3227	Tripod 1.25"
Tripod	Manfrotto / Bogen	3228	Tripod 1.25"
Tripod	Manfrotto / Bogen	3410	Tripod 1"
Tripod	Manfrotto / Bogen	3411	Tripod 1"
Tripod	Manfrotto / Bogen	3412	Tripod 1"
Tripod	Manfrotto / Bogen	3413	Tripod 1"
Tripod	Manfrotto / Bogen	3414	Tripod 1"
Tripod	Manfrotto / Bogen	3430	Tripod 1"
Tripod	Manfrotto / Bogen	3431	Tripod 1"
Tripod	Manfrotto / Bogen	3433	Tripod 1"
Tripod	Manfrotto / Bogen	3434	Tripod 1"
Tripod	Manfrotto / Bogen	3440	Tripod 1.25"
Tripod	Manfrotto / Bogen	3441	Tripod 1.25"
Tripod	Manfrotto / Bogen	3442	Tripod 1.25"
Tripod	Manfrotto / Bogen	055CLB	Tripod 1"
Tripod	Manfrotto / Bogen	055DB	Tripod 1"
Tripod	Manfrotto / Bogen	055MF3	Tripod 1"
Tripod	Manfrotto / Bogen	055MF4	Tripod 1"
Tripod	Manfrotto / Bogen	055PROB	Tripod 1"
Tripod	Manfrotto / Bogen	15B	Tripod 1"
Tripod	Manfrotto / Bogen	190MF3	Tripod 1"
Tripod	Manfrotto / Bogen	190MF4	Tripod 1"
Tripod	Manfrotto / Bogen	190XB	Tripod 1"
Tripod	Manfrotto / Bogen	190XPROB	Tripod 1"
Tripod	Manfrotto / Bogen	3021BN	Tripod 1"
Tripod	Manfrotto / Bogen	3021BPRO	Tripod 1"
Tripod	Manfrotto / Bogen	715B	Tripod 1"
Tripod	Manfrotto / Bogen	715SHB	Tripod 1"
Tripod	Manfrotto / Bogen	718B	Tripod 1"
Tripod	Manfrotto / Bogen	718SHB	Tripod 1"
Tripod	Manfrotto / Bogen	725B	Tripod 1"
Tripod	Manfrotto / Bogen	728B	Tripod 1"

OP/TECH USA Master Gear Fit List

ITEM	Camera	Model	OP/TECH USA Pouch Recommendation
Tripod	Manfrotto / Bogen	745B	Tripod 1"
Tripod	Manfrotto / Bogen	755B	Tripod 1"
Tripod	Manfrotto / Bogen	755MF3	Tripod 1"
Tripod	Manfrotto / Bogen	756B	Tripod 1"
Tripod	Manfrotto / Bogen	756MF3	Tripod 1"
Tripod	SLIK	322	Tripod 1"
Tripod	SLIK	333 - SPORT	Tripod 1"
Tripod	SLIK	444 - SPORT	Tripod 1"
Tripod	SLIK	GRAND MASTER	Tripod 1"
Tripod	SLIK	GRAND PRO CF-4"	Tripod 1.25"
Tripod	SLIK	MASTER CLASSIC	Tripod 1"
Tripod	SLIK	PRO 500 DX	Tripod 1"
Tripod	SLIK	PRO 500 DXII	Tripod 1"
Tripod	SLIK	PRO 700 DX	Tripod 1"
Tripod	SLIK	THE PROFESSIONAL	Tripod 1.25"
Tripod	SLIK	THE PROFESSIONAL 4	Tripod 1.25"
Tripod	SLIK	THE PROFESSIONAL II	Tripod 1.25"
Tripod	SLIK	THE PROFESSIONAL SP	Tripod 1.5"
Tripod	VELBON	Sherpa 200R	Tripod 1"
Tripod	VELBON	Sherpa 250R	Tripod 1"
Tripod	VELBON	Sherpa 435	Tripod 1"
Tripod	VELBON	Sherpa 450R	Tripod 1"
Tripod	VELBON	Sherpa 538	Tripod 1"
Tripod	VELBON	Sherpa 550R	Tripod 1"
Tripod	VELBON	Sherpa 600R	Tripod 1"
Tripod	VELBON	Sherpa 750R	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-435	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-530	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-535	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-540	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-545	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-630	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-635	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-640	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-645	Tripod 1"
Tripod	VELBON	Sherpa PRO CF-730	Tripod 1.25"
Tripod	VELBON	Sherpa PRO CF-740	Tripod 1.25"
Tripod	VELBON	Sherpa PRO CF-830	Tripod 1.25"
Tripod	VELBON	Sherpa PRO CF-840	Tripod 1.25"
Video	CANON	Optura 300	Hip-XL
Video	CANON	Optura Xi	None available at this time.
Video	CANON	ZR80/ ZR85/ ZR90	Hip-XL
Video	CONCORD	DV2020	P/E WB-Mini, Zip-M, Hip-M, Snap-M
Video	POLAROID	PDV-3180	P/E WB-S, Zip-M, Hip-M
Video	SONY	CCD-TRV118/ CCD-TRV318	None available at this time.
Video	SONY	CCD-TRV128/ CCD-TRV328	None available at this time.
Video	SONY	DCR-HC20/ DCR-HC30/ DCR-HC40	Hip-XL
Video	SONY	DCR-HC65/ DCR-HC85	None available at this time.
Video	SONY	DCR-IP1	Zip-M, Hip-M
Video	SONY	DCR-IP220	None available at this time.
Video	SONY	DCR-IP55	Hip-XL
Video	SONY	DCR-PC105/ PC109	Hip-XL
Video	SONY	DCR-PC330	None available at this time.
Video	SONY	DCR-TRV19/ TRV22	Hip-XL
Video	SONY	DCR-TRV250/ TRV350	None available at this time.
Video	SONY	DCR-TRV260	None available at this time.
Video	SONY	DCR-TRV33	Hip-XL
Video	SONY	DCR-TRV460	None available at this time.
Video	SONY	DCR-VX2100	None available at this time.
Video	SONY	DRC-DVD100/ DVD200	Hip-XL
Video	SONY	DRC-DVD300	Hip-XL
Video	SONY	DRC-TRV38	None available at this time.
Video	SONY	DRC-TRV70/ DRC-TRV80	None available at this time.
Video	SONY	DRC-TRV950	None available at this time.