

304 Andrea Dr., Belgrade, MT 59714 USA Tel: 406-388-1377 or fax: 406-388-2063 web site: www.optechusa.com

Gimme Grip Strap™ Instructions











The Gimme Grip Strap™ consists of the following components: A) An elastic wrist strap, B) Two (2)Uni-Loop™ Connectors, C) a leather tab, screw and post, D) a male quick disconnect, and E) an Adapt-It™ Connector. Please note that not all hardware will be used for all applications.

There are two options for attaching to the upper right camera connection area:

Option 1: Standard fit [Uses 1 Uni-Loop (B)]







Thread the Uni-Loop[™] (B)

2. Thread quick disconnect through connection point on through opening of Uni- Loop™.

3. Pull quick disconnect to tighten knot.

camera. **Option 2: Tighter fit or for Smaller Hands** [Uses Parts (C & D) or (C, D & E) in lieu of the upper Uni-Loop™ Connector]



 Slip the Adapt-It™ connector (E) through the camera's strap lug. If your camera has a split ring connector (ie. Nikon) you will not need the Adapt-It™.



2. Slip the leather tab (C) through the slot on the quick disconnect and fold it in half to align the two holes.



3. Locate the post through the leather tab and Adapt-It Connector or split ring.



4. Using two screwdrivers, drive the screw into the post. There will be some resistance. This is what keeps the screw from coming unfastened unexpectedly.

There are two options for attaching to the lower connector:



 Attach the 2nd Uni-Loop™ Connector (B) to a base plate (not included) which features a connection area.



OR

2 For cameras with a third connection area located on the lower grip, use the Uni-Loop™ Connector.

Attaching the Main GIMME GRIP STRAP™









1. Attach the elastic strap (A) to the Uni-Loop™ Connectors. The female quick disconnect which is attached directly to the elastic goes to the top of the camera. The female guick disconnect which is attached directly to the leather tab goes to the bottom of the camera

Additional options



The GIMME GRIP STRAP™ is compatible with the base plate that comes with the OP/TECH USA GRIP STRAP™ or the E-Z GRIP STRAP™

Rev B: 5-24-18 - 02029270